



-power in control



Advanced Wind turbine Controller AWC 500



IEC61131-3 programming



DEIF A/S · Frisenborgvej 33 · DK-7800 Skive

Tel.: +45 9614 9614 · Fax: +45 9614 9615

info@deif.com · www.deif.com

Document no.: 4189340738

Revision

Revision	Author	Date	Description
A	SJE	2012-06-26	Initial release
B	LVI	2012-08-14	Frequency input description updated
C	LVI	2012-10-23	CAN telegram debug logging added
D	SJE	2013-06-24	Added IOM5·2 and DIM5·1 module descriptions

Contents

Revision	i
Contents	ii
1 IEC61131-programming guide	1
1.1 Introduction	1
1.2 CoDeSys Standard libraries	5
1.3 DEIF Libraries	6
1.4 Watchdog	7
1.5 Default output state	8
1.6 Hardware monitoring	9
1.7 Monitoring programming load	13
1.8 EtherCAT	18
1.9 Persistent variables	18
1.10 Handling Division by zero	19
1.11 Creating dynamic language switching in HMI	20
1.12 Extending visualisation memory	20
1.13 Distributing applications	20
2 AWC 500 module configurations	26
2.1 PCM5·1 – Power and Control Module	26
2.2 IOM5.1 – Input and Output Module	27
2.3 IOM5·2 – Input and Output Module	38
2.4 DIM5·1 – Input and Output Module	42
2.5 GPM5·1 – Grid Protection Module	44
2.6 IFM5·1 – Interface and Fieldbus Module	51
3 Communication	61
3.1 Creating a CANopen slave interface	61
3.2 AWC 500 Inter system communication	67
3.3 Demo	69
3.4 Setting up a CANopen master	69
3.5 Usage of CANopen SDOs	77
3.6 Doing CAN layer II communication	79
3.7 CAN telegrams debug logging	80
3.8 Setting up OPC connection interface	81
3.9 Creating a MODBUS TCP/IP slave interface	93
3.10 Setting up a MODBUS TCP/IP master	99
3.11 Setting up NTP (Network Time Protocol) client	111
4 Adding Multilanguage support to visualisations	118
4.1 Set Chinese as default startup language	122
4.2 Webvisualisation or Panel PC HMI preparations	123
5 Using boot application dUpdate builder	125
5.1 Step 1: Delete existing CoDeSys boot application files	125
5.2 Step 2: Create new boot application from CoDeSys in offline mode (Online→Create boot application)	127

5.3	Step 3) Run build_dupdate.py script from CoDeSys (Tools→Scripting→ExecuteScript File...)	129
5.4	Step 4) Test the build of application.dupdate before distribution.	131
6	Using DEIF VisuLoader	134
6.1	Purpose of the VisuLoader	134
6.2	Installing the VisuLoader	134
6.3	VisuLoader features	135
6.4	Using the VisuLoader	135

1 IEC61131-programming guide

The PLC feature is provided by the CoDeSys environment used in other brand PLCs known from the industrial automation. DEIF has chosen to provide a PLC feature based on CoDeSys V3 on its rugged AWC 500 for users convenience.

1.1 Introduction

CoDeSys is the common name for the IEC61131-3 programming system, called CoDeSys IDE. The IDE is installed on your development computer see Figure 1.1.




Figure 1.1: The CoDeSysV3 Editor

CoDeSys supports all five programming languages of the IEC 61131-3 programming standard are supported.

- Instruction List
- Sequential Function Chart
- Function Block Diagram
- Structured Text
- Ladder Diagram
- Continuous Function Chart

The entire programming kit including a manual and online assistance is available in English, German and Chinese.




Figure 1.2: Example of the Chinese online help

The following features are included:

- Monitoring of all variables
- Writing and forcing of receipts (sets of variables) into the PLC
- Debugging your complete project (breakpoints, stepping, single cycle, call stack)
- Interrupt-free online changes of POU's and data
- Sampling Trace
- Library management for user defined libraries
- Offline simulation
- Graphic PLC configuration
- OPC Server

The other part the PLC runtime system, called CoDeSys SP (SoftPLC), has DEIF installed on the AWC 500 , so you can run your new or existing programs written with CoDeSys or other CoDeSys based products. When moving from other PLCs.




Figure 1.3: DEIF AWC 500 platform with CoDeSys Runtime

Often only small changes related to a transition is expected. Examples on things to change in the transition from a other PLC's to AWC 500 will most likely focus on that DEIF does not have matching library functions, e.g. communication drivers. The HMI is directly compatible other time the entire HMI requires rework. PLC programs written in CoDeSys V2 can be imported in CoDeSys V3, minor conversions are required. These conversion tools are build-in CoDeSys V3 to guide the user through this. DEIF also assist client getting started with using the AWC 500 and audits the clients PLC code. Figure 1.4 displays an example turbine application.




Figure 1.4: Example configuration for Wind Turbine with Tower base, Nacelle and Hub (via EtherCAT)

AWC 500 features:

- Distributed IO configuration matching common turbine configurations
- Automatic startup. The PLC runtime is able to start(restart) without user interaction.
- Boot projects. Possible to make CoDeSys boot projects, that is application projects that start up automatically.
- Web visualisation. CoDeSys web server implementation can be accessed on [http://\[ip\]:8080/webvisu.htm](http://[ip]:8080/webvisu.htm)
- SD card access.
- Retain / persistent variables.

Figure 1.5 presents an Web visualisation example.




Figure 1.5: Example HMI for Pitch Motion Controller.

1.2 CoDeSys Standard libraries




Figure 1.6: CoDeSys Library manager

The following libraries are provided with CoDeSys V3:

Library	Functionality
SysCom.library	Serial synchronous communication with a target device
SysComAsync.library	Serial asynchronous communication with a target device
SysCpuHandling.library	IEC function call, test and reset of bits
SysDir.library	Handling of a file system on the target device (synchron)
SysDirAsync.library	Handling of a file system on the target device (asynchronous)
SysEvent.library	Synchronisation and controlling the processing between two (IEC-) tasks
SysFile.library	Handling of a file system (synchronous accesses) on the target device
SysFileAsync.library	Handling of a file system (asynchronous accesses) on the target device
SysInt.library	Applying an interrupt handler on a function
SysMem.library	Memory management
SysPci.library	Access on PCI-cards connected to the system
SysPort.library	Communication with external hardware modules via their port addresses, e.g. realtime clock, graphic controller etc. (synchronous)
SysPortAsync.library	Communication with external hardware modules via their port addresses, e.g. realtime clock, graphic controller etc. (asynchronous)
SysProcess.library	Process handling on a single-processing target system
SysSem.library	Creating and using semaphores for task synchronization
SysSemProcess.library	Using semaphores for process synchronisation
SysShm.library	Creating and accessing a Shared Memory

Table 1.1: CoDeSys V3 libraries (1 of 2)

Library	Functionality
SysSocket.library	Access on sockets for the communication via TCP/IP and UDP (synchronous)
SysSocketAsync.library	Asynchronous access on sockets for the communication via TCP/IP and UDP (asynchronous)
SysTask.library	Task management (see also SysIECTasks.library)
SysTime.library	Additional functions for reading the realtime clock of the computer (see also SysRtc.library); is needed in addition to the SysTask-Info.library for displaying the task time evaluation in the CoDeSys Task Configuration
SysTimer.library	Implementing a timer for triggering an event of calling a function
SysTypes.library	Platform comprehensive constants and file types for the runtime system

Table 1.2: CoDeSys V3 libraries (2 of 2)

Detailed documentation of each library can be found under
 C:\Program Files\3S CoDeSys\CoDeSys\Documentation\en

1.2.1 CoDeSys V2 compliant libraries

Under Add Library → SysLibs23 a number of libraries exists that helps ensuring that existing PLC projects that have been running under CoDeSys version 2, executes under CoDeSys V3. Include these in the project if required or if you are familiar with the use:




Figure 1.7: CoDeSys V2 compliant libraries

1.3 DEIF Libraries

1.3.1 CmpPcm51Clib.library

Disk space monitoring from CoDeSys.

Pcm51DiskFree: The function Pcm51DiskFree will return how many bytes are free on a mounted device.

```
2 | space 63635456 := Pcm51DiscFree('/app'); RETURN
```

/app : Root of the application file system

/mmc : Root of the MMC/SDCARD file system

/tmp : Root of the /tmp (RAM)

Pcm51Exit: Exits the CoDeSys runtime. It will be restarted by the Operating System

Pcm51Reboot: Reboot the PCM51 Operating System

1.3.2 Writing CoDeSys log

CmpLog can be used to write to the CoDeSys log. Example:

```
result := CmpLog.LogAdd2( STD_LOGGER, 16#1000, LogClass.LOG_INFO, 0, 0 ,
    'This_is_added_to_the_CoDeSys_log' );
```

1.4 Watchdog

To control handling on CPU overload (a task taking too long time execute in a certain program) the Watchdog can be enabled using the following steps:




Figure 1.8: Enabling watchdog

In Task Configuration, see Figure 1.8

1. Select Watchdog: Enable
2. Set Time: t#20ms
3. Sensitivity: 10

The CoDeSys will then cause a Watchdog exception, and the state of the Digital output will be set to default state. Initialization code can be protected against the watchdog with:

After declaring an appropriate variable for the handle of the task (of type RTS_IEC_HANDLE),

hIecTask : RTS_IEC_HANDLE; the disabling (and succeeding reenabling) can be handled by employing the interface functions in the following manner:

```
hIecTask := IecTaskGetCurrent(0);
IecTaskDisableWatchdog(hIecTask);
... // Code that is protected against watchdog
IecTaskEnableWatchdog(hIecTask);
```

1.4.1 Support for runtime reboot upon exception error

This goes for both FPU, Watchdog, Segmentation fault and more. Once a fault occurs the runtime will reboot and be up and running within 5 seconds. All implementation is location in the "ApplicationEventHandler" function block in the "0 TASKS" folder. The functions block is instantiated in the MAIN_TASK(PRG) (WatchdogExceptions: ApplicationEventHandler;) and you may choose to disable the auto runtime reboot functionality by setting the restartRuntimeOnException to FALSE.

Add the FUNCTION BLOCK ApplicationEventHandler IMPLEMENTS IcmpEventCallback to the project.




Figure 1.9: The ApplicationEventHandler function block

1.5 Default output state

Digital Output can be set to default state on exceptions:

In Device→PLC Settings, see Figure 1.8

1. Enable "Update IO while in stop"
2. Set "Behaviour for outputs in Stop" to "Set all outputs to default".





Figure 1.10: Setting Digital Output default state

1.6 Hardware monitoring

Functionblock	Parameter/Property	Results
IoDrvEtherCAT	NumberActiveSlaves	<p>This property returns the number of the actually connected slaves. If StartConfigWithLessDevice is TRUE, then the number of real devices can be determined.</p> <p>Example:</p> <pre> VAR startWithLessDevice : BOOL; END_VAR Program : startWithLessDevice := EtherCAT_Master . StartConfigWithLessDevice ; </pre>
IoDrvEtherCAT	xConfigFinished	<p>If this parameter is TRUE, the transfer of all configuration parameters has been finished successfully. The communication is running.</p> <p>Example:</p> <pre> VAR configFinished : BOOL; END_VAR Program : EtherCAT_Master (); configFinished := EtherCAT_Master . xConfigFinished ; </pre>
IoDrvEtherCAT	xError	<p>This output will get TRUE if an error is detected during the start of the EtherCAT stack or if during operation the communication with the slaves gets interrupted because no more messages can be received (for example due to a cable break). The error cause can be made out with the help of the logging list resp. via the error string. Thereby "Ethercat_Master.LastMessage" is the instance of the master.</p> <p>Example:</p> <pre> VAR error : BOOL; END_VAR Program : EtherCAT_Master (); EtherCAT_Master . xError ; </pre>
IoDrvEtherCAT	LastMessage	<p>This property returns a string with the latest message of the EtherCAT Stacks. If the start has been done successfully, "All slaves done" should be returned. The string is the same as used for the diagnostic message shown in the EtherCAT Master device editor in online mode</p> <p>Example:</p> <pre> VAR lastMesage : STRING(255); END_VAR Program : lastMesage := EtherCAT_Master . LastMessage ; </pre>

Functionblock	Parameter/Property	Results												
ETCSlave	VendorID	<p>After the start of the EtherCAT stack, this property returns the Vendor ID read from the device. Example:</p> <pre> VAR productID : DWORD; END_VAR Program : vendorID := PCM51.VendorID; </pre>												
ETCSlave	ProductID	<p>After the start of the EtherCAT stack this property returns the Product ID read from the device. Example:</p> <pre> VAR serialID : DWORD; END_VAR Program : serialID := PCM51.SerialID; </pre>												
ETCSlave	wState	<p>The current state of the slave is returned. Possible values: 0: ETC_SLAVE_BOOT 1: ETC_SLAVE_INIT 2: ETC_SLAVE_PREOPERATIONAL 4: ETC_SLAVE_SAVEOPERATIONAL 8: ETC_SLAVE_OPERATIONAL Example: Declaration: pSlave : POINTER TO ETCSlave; Program: pSlave := Ethercat_Master.FirstSlave; WHILE pSlave <> 0 DO pSlave ^(); IF pSlave^.wState = ETC_SLAVE_STATE.ETC_SLAVE_OPERATIONAL THEN ; END_IF pSlave := pSlave^.NextInstance; END_WHILE</p>												
Input / Output														
PCM51 PDM51 PDM52	Power Primary	<p>This signal whether the Primary Power on the rack is OK.</p> <table border="1"> <tr> <td>Application: IES1_pcm51.pcm_input</td> <td>Digital Input</td> <td>%I1.1</td> <td>BIT</td> <td>0</td> <td>Digital Input</td> </tr> <tr> <td>Application: TEST_PCM51.pcm_psu_pri</td> <td>Power Primary</td> <td>%I1.1</td> <td>BIT</td> <td>0</td> <td>Power Primary</td> </tr> </table>	Application: IES1_pcm51.pcm_input	Digital Input	%I1.1	BIT	0	Digital Input	Application: TEST_PCM51.pcm_psu_pri	Power Primary	%I1.1	BIT	0	Power Primary
Application: IES1_pcm51.pcm_input	Digital Input	%I1.1	BIT	0	Digital Input									
Application: TEST_PCM51.pcm_psu_pri	Power Primary	%I1.1	BIT	0	Power Primary									

Functionblock	Parameter/Property	Results
IOM51	DO STATUS	<p>Digital output status diagnostics</p>  <p>Bit 0 indicate the status of the digital outputs 0: An error is indicated if one of the following conditions is filled:</p> <ul style="list-style-type: none"> • Supply voltage is below 8V • Supply voltage is above 37V • Error is reported on one of the digital output drivers. (Over-current or over-temperature) <p>After power-up the digital output (EnableDO) has to be enabled before error-bit is reset.</p> <p>If an over-current or over-temperature status has occurred, the digital outputs (EnableDO) have to be disabled and then enabled again to clear the error state. 1 : Digital Outputs are OK</p> <p>Bit 1 indicates state of IOM calibration. 0 : NOT calibrated, 1 : Calibrated</p>
IFM51	SSI Status	<p>This signal should be 0 if things are OK.</p>  <p>Bit0: high if SSI line error Bit1: high if Frame error</p>
IFM51	CAN Status	<p>Monitor the status of the CAN bus via the following inputs:</p> 

CANopen																										
Functionblock	Parameter/Property	Results																								
CANopen Manager	stkGetInfo	<p>ENUM STK_STATE</p> <table border="1"> <thead> <tr> <th>Name</th> <th>Type</th> <th>Inherited from</th> </tr> </thead> <tbody> <tr> <td>NO_STATE</td> <td>INT</td> <td></td> </tr> <tr> <td>INITALISATION</td> <td>INT</td> <td></td> </tr> <tr> <td>RESET_APPLICATION</td> <td>INT</td> <td></td> </tr> <tr> <td>RESET_COMMUNICATION</td> <td>INT</td> <td></td> </tr> <tr> <td>PRE_OPERATIONAL</td> <td>INT</td> <td></td> </tr> <tr> <td>OPERATIONAL</td> <td>INT</td> <td></td> </tr> <tr> <td>STOPPED</td> <td>INT</td> <td></td> </tr> </tbody> </table> <p>Declaration:</p> <pre> getstate : CS.PROC_STATE; oError : CS.ERROR; (* Information from GetInfo *) infoStk : CS.STK_INFO; infoNet : CS.NET_INFO; infoError : CS.ERROR; (* Work variables *) getdataexcecute : CS.PROC_CMD; </pre> <p>Program:</p> <pre> (* Function call for getting canopen stack info *) CANopen_Manager.StkGetInfo(stkGetInfo => getstate, eCmd := getdataexcecute, pStkInfo := ADR(infoStk), pNetInfo := ADR(infoNet), eError => infoError); (* Get data for the current canopen stack on 'CANopen_Manager' *) IF getdata = TRUE THEN getdataexcecute := CS.PROC_CMD.EXECUTE; getdata := FALSE; END_IF (* handles stopping the modules on error or OK *) IF (getstate <> CS.PROC_STATE.BUSY) THEN getdataexcecute := CS.PROC_CMD.NONE; IF (infoStk.eState = CS.STK_STATE.OPERATIONAL) (* stack is operational *) END_IF END_IF </pre>	Name	Type	Inherited from	NO_STATE	INT		INITALISATION	INT		RESET_APPLICATION	INT		RESET_COMMUNICATION	INT		PRE_OPERATIONAL	INT		OPERATIONAL	INT		STOPPED	INT	
Name	Type	Inherited from																								
NO_STATE	INT																									
INITALISATION	INT																									
RESET_APPLICATION	INT																									
RESET_COMMUNICATION	INT																									
PRE_OPERATIONAL	INT																									
OPERATIONAL	INT																									
STOPPED	INT																									

CANopen																				
Functionblock	Parameter/Property	Results																		
CANRemote-Device	nCanOpenState	<p>CIA405.DEVICE_STATE the states:</p> <table border="1"> <thead> <tr> <th>Name</th> <th>Type</th> </tr> </thead> <tbody> <tr> <td>INIT</td> <td>INT</td> </tr> <tr> <td>RESET_COMM</td> <td>INT</td> </tr> <tr> <td>RESET_APP</td> <td>INT</td> </tr> <tr> <td>PRE_OPERATIONAL</td> <td>INT</td> </tr> <tr> <td>STOPPED</td> <td>INT</td> </tr> <tr> <td>OPERATIONAL</td> <td>INT</td> </tr> <tr> <td>UNKNOWN</td> <td>INT</td> </tr> <tr> <td>NOT_AVAIL</td> <td>INT</td> </tr> </tbody> </table> <p>Example:</p> <pre> PowerConverter (); State := PowerConverter.CANOpenState IF (state = CIA405.DEVICE_STATE.OPERATIONAL) THEN (* Power converter is Operational *) bValidData_CAN_Converter := TRUE; END_IF </pre>	Name	Type	INIT	INT	RESET_COMM	INT	RESET_APP	INT	PRE_OPERATIONAL	INT	STOPPED	INT	OPERATIONAL	INT	UNKNOWN	INT	NOT_AVAIL	INT
Name	Type																			
INIT	INT																			
RESET_COMM	INT																			
RESET_APP	INT																			
PRE_OPERATIONAL	INT																			
STOPPED	INT																			
OPERATIONAL	INT																			
UNKNOWN	INT																			
NOT_AVAIL	INT																			

1.7 Monitoring programming load

In CoDeSys you can see the task cycle times and statistics under Task→Monitoring:




Figure 1.11: Monitoring tasks

Else you can measure execution time of each subsystem with time, E.g.:

```

start:=Time();
PRG_Subsystem1();
PRG_Subsystem2();
PRG_Subsystem3();
diff:=TIME()-start;
                    
```

Important for ensuring Realtime operation is that none of the Cycle times exceed the Task interval e.g. that Last Cycle Time 4724 us is less than the Task Interval 20000 us, and does not exceed it.

Task	Status	IEC-Cycle Count	Cycle Count	Last Cycle Time (µs)	Average Cycle Time (µs)	Max. Cycle Time (µs)	Min. Cycle Time (µs)	Jitter (µs)	Min. Jitter (µs)	Max. Jitter (µs)
DEIF_MAIN	Valid	4580	4580	4724	4813	8141	4588	-913	-1505	
EtherCAT_Master	Valid	9553	9553	3806	3784	6660	3326	9	-37	

Figure 1.12: Monitoring tasks

Two methods for measuring the cycle time via CoDeSys Task configuration or via Systemtime.

PROGRAM MAIN_20ms

VAR

(* CoDeSys Task cycle time configuration and measurement *)

```

Result          : ISystemTypes.RTS_IEC_RESULT;
                    
```

```

hTask      : ISysTypes.RTS_IEC_HANDLE;
pTaskInfo2 : POINTER TO CmplecTask.Task_Info2;
dwInterval : DWORD;
dwCycleTime : DWORD;
dwMinCycleTime : DWORD;
dwMaxCycleTime : DWORD;
dwAvgCycleTime : DWORD;

(* Execution time measurement *)
start : SysTimeCore.SYSTIME;
end : SysTimeCore.SYSTIME;
cyclotime : SysTimeCore.SYSTIME;
END_VAR
(* START OF FUNCTION_BLOCK / PROGRAM *)
SysTimeCore.SysTimeGetUs(pUsTime := start); (* Start time *)

(* CoDeSys Task cycle time configuration and measurement *)
hTask := CmplecTask.IecTaskGetCurrent(pResult:=ADR(Result));
IF hTask <> ISysTypes.RTS_INVALID_HANDLE THEN
    pTaskInfo2 := CmplecTask.IecTaskGetInfo3(hIecTask:=hTask, pResult:=ADR(Result));
    dwInterval:= pTaskInfo2^.dwInterval;
    gdwTaskIntervalDEIF_MAIN_20ms_usec:= dwInterval;
    dwCycleTime := pTaskInfo2^.dwCycleTime;
    gdwCycleTime_DEIF_MAIN := dwCycleTime;
    dwMinCycleTime := pTaskInfo2^.dwMinCycleTime;
    dwMaxCycleTime := pTaskInfo2^.dwMaxCycleTime;
    dwAvgCycleTime := pTaskInfo2^.dwAverageCycleTime;
END_IF

(lineN)
(lineN+1)
...
(lineN+?)

(* Task measurement *)
SysTimeCore.SysTimeGetUs(pUsTime := end); (* Measure end time *)
cyclotime := end - start; (* Calculate Cycle time *)

(* END OF FUNCTION_BLOCK / PROGRAM *)

```

Task load is defined as $CycleTime/TaskInterval$. This can be cal:

PROGRAM MonitorTasks

VAR

bReset : **BOOL**;

END_VAR

(* START OF FUNCTION_BLOCK / PROGRAM *)

(* Cycle-Times *)

```

gdwCycleTime_DEIF_MAIN_min := MIN(gdwCycleTime_DEIF_MAIN_min, gdwCycleTime_DEIF_MAIN);
gdwCycleTime_DEIF_MAIN_max := MAX(gdwCycleTime_DEIF_MAIN_max, gdwCycleTime_DEIF_MAIN);

```

(* Cycle-Exceed *)

IF gdwTaskIntervalDEIF_MAIN_20ms_usec <> 0 **THEN**

IF gdwCycleTime_DEIF_MAIN > gdwTaskIntervalDEIF_MAIN_20ms_usec **THEN**

gbDEIF_MAIN_CycleTimeExceeded := **TRUE**;

guiDEIF_MAIN_CycleTimeExceedCounter := guiDEIF_MAIN_CycleTimeExceedCounter + 1;

END_IF

END_IF

```
(* Reset *)
```

```
IF bReset THEN
  guiDEIF_MAIN_CycleTimeExceedCounter := 0;
  gdwCycleTime_DEIF_MAIN_min := 1000000;
  gdwCycleTime_DEIF_MAIN_max := 0;
  gbDEIF_MAIN_CycleTimeExceeded := FALSE;
  bReset := FALSE;
END_IF
```

```
(* Task Load *)
```

```
IF gdwTaskIntervalDEIF_MAIN_20ms_usec <> 0 THEN
  (* Calculate task load in [%] *)
  grTaskLoad_20ms_Percent := LIMIT(0, DWORD_TO_REAL(gdwCycleTime_DEIF_MAIN) /
    DWORD_TO_REAL(gdwTaskIntervalDEIF_MAIN_20ms_usec) *
    100.0, 100);
END_IF
```

END_IF

```
(* END OF FUNCTION_BLOCK / PROGRAM *)
```

1.7.1 Monitoring load via CoDeSys PLC shell

Another indication about the PLC load can be found via the CoDeSys PLC shell (Device->PLC shell).




Figure 1.13: Example of PLC load via CoDeSys PLC shell

1.7.2 Monitoring Processor load via variable

The above PLC load measurement can be monitored with

```
VAR
  Result          : ISysTypes.RTS_IEC_RESULT;
  ProcessorLoad_Percent : REAL;
END_VAR

(* Processor Load *)
ProcessorLoad_Percent := UDINT_TO_REAL( SchedGetProcessorLoad(pResult:=ADR(Result)) );
```

1.7.3 Monitoring load via Linux

You can log in to the unit and via the SSH and run the command top see the CPU load.

```

Mem: 15588K used, 111220K free, 0K shrd, 0K buff, 5692K cached
CPU:  6.3% usr  2.9% sys  0.0% nic 90.7% idle  0.0% io  0.0% irq  0.0% sirq
Load average: 0.00 0.00 0.00 1/78 759

```

PID	PPID	USER	STAT	VSZ	%MEM	%CPU	COMMAND
645	397	root	S	90252	71.0	3.1	./codesyscontrol
759	756	default	R	2356	1.8	0.5	top
101	2	root	SW	0	0.0	0.2	[appwd_wdm]
12	2	root	SW	0	0.0	0.2	[sirq-rcu/0]
754	377	root	S	2436	1.9	0.0	/usr/sbin/dropbear -r /etc/dropbear/dr
395	1	root	S	2356	1.8	0.0	runsvdir /app/service
756	754	default	S	2356	1.8	0.0	-sh
386	1	root	S	2356	1.8	0.0	/bin/sh /etc/init.d/rcS
1	0	root	S	2352	1.8	0.0	init
424	1	root	S	2352	1.8	0.0	/usr/sbin/crond
366	1	root	S	2352	1.8	0.0	syslogd -S -O /app/log/syslog -s 100 -
369	1	root	S	2352	1.8	0.0	klogd -c 5
380	1	root	S	2352	1.8	0.0	inetd
422	1	root	S	2352	1.8	0.0	init
377	1	root	S	2328	1.8	0.0	/usr/sbin/dropbear -r /etc/dropbear/dr
404	1	root	S	2220	1.7	0.0	watchdog -t 5 /dev/watchdog0
397	395	root	S	2220	1.7	0.0	runsv codesys
387	386	root	S	2160	1.7	0.0	/usr/sbin/vsftpd /etc/vsftpd.conf
410	1	root	S	2064	1.6	0.0	/usr/sbin/tlogd /dev/tlog
384	1	root	S	1808	1.4	0.0	/usr/sbin/dupdate --dir /tmp/fwupdates

Figure 1.14: Example of top output

1.7.4 Description of the "top" command

Memory Usage
Total memory usage in AWC500
Here 28MB are used and 98MB are free

Memory Usage


Load Average (CPU)
This is the linux way of measuring CPU load if load average is below 1.00 it means that the CPU can keep up. The numbers displayed are: <5min> <10min> <15min> measured load average

Normally a load average below 0.7 is considered acceptable load. Load average of linux but during startup of linux may settle within 5 minutes.

Process ID this can be used to kill a process.
ex: 'kill -9 498' for restarting codesys in this example.
The process ID will change on each startup.

Description of the linux 'top' command

This CPU line are describes were the CPU is used not how much.
usr = user space (ex. codesys), sys, nic, io, irq = linux/system/network, idle = idle (not doing anything).
This line will/should always be 98-100% even if the CPU load is only 20%



The total CPU load of each thread. The total load is all the CPU % added together
A better way to measure CPU load in linux is the load average.

How much of the Total memory is used by each task.
Ex. codesys is using 98.6% of the 28692K used in this example
The VSZ value is not important since it deals in virtual memory usage.

The status of the task.
R = Running
S = Sleeping (normal mode, waiting for interrupt or cyclic task tick)
W = Waiting (normal mode, waiting for event)
Z = Zombi mode, task did not exit correctly

1.8 EtherCAT

Please note the CoDeSys Runtime must be stopped before EtherCAT Scan is possible.

1.9 Persistent variables

The AWC 500 has 128kB non-volatile memory, the parameters are saved instantly on assignment, so on the event of a power down no further actions need to be taken for storing the variables.




Figure 1.15: Adding persistent variables to the project




Figure 1.16: Modifying global variables to become persistent variables

Or simply add "PERSISTENT RETAIN" to the global variables VAR declaration.

This simple test shows the persistent variables:




Figure 1.17: Testing persistant variables

It is recommended to read default parameters from a text file on the flash instead e.g.:

```
rMyVar:= DEIFReadLREALParameter('Parameter.txt', 'MyVariable');
DEIFWriteLREALParameters('Parameter.txt', rMyVar);
```

The following presents the format of the Parameter.txt file:

```
[MyVariable = 1.232]
```

1.10 Handling Division by zero

You should always check if the divisor is zero before making a division, and else signal a flag and skip the division.

However some build in features are available on AWC 400 and AWC 500 :

If you define functions in your project with the names CheckDivByte, CheckDivWord, CheckDivDWord and CheckDivReal, CheckDivLReal, you can use them to check the value of the divisor if you use the operator DIV, for example to avoid a division by 0. The functions must have the above listed names.

AWC 500 : Use the Add Object → POU for implicit checks

```
FUNCTION CheckDivLReal : REAL
VAR_INPUT
divisor:REAL;
END_VAR
```

```
IF divisor = 0 THEN
CheckDivLReal:=1;
(* Adding the following line allows to identify in which POU division by zero occurs. *)
(* Set gCurrentPOU in beginning of each POU. *)
(* gDivisionByZeroOccuredAt:=gCurrentPOU; *)
```

```
ELSE
CheckDivLReal:=divisor;
END_IF;
```

1.11 Creating dynamic language switching in HMI

All static texts added to visualization during development of a project are automatically added to a Global Text list with an incremented ID, under a "default" language. These can only be edited in the visualization. Additional languages can be added to this list as new columns.

1.12 Extending visualisation memory

When using much visualization on one page, the memory can be extended.




Figure 1.18: Extending visualisation memory

1.13 Distributing applications

Binary boot project package of files can be created to distribute CoDeSys application projects. The files can then be uploaded via FTP/SFTP remotely. The advantage is that binary files and not the source PLC project is distributed.

1.13.1 Creating a boot project (for remote upload)

Start with the working PLC project in CoDeSys.
Go to Online→Create Boot Application




Figure 1.19: Create Boot Application




Figure 1.20: Select Yes to generate new code.




Figure 1.21: Here the project is named "Application"

Additional files are also saved for visualization.




Figure 1.22: Save all the proposed files

Changing boot application name

If the generated application is named something else than Application, it must be changed in CoDeSysControl.cfg located in /app/service/codesys/ and rename "Application" under PLC Logic in CoDeSys.




Figure 1.23: Edit application name in CoDeSysControl.cfg

If the PLC application name is changed and used as a Boot application, then the application name must be changed in the /app/service/codesys/CoDeSys.cfg file also, E.g.:

```

[CmpApp]
Bootproject.RetainMismatch.Init=1
RetainType.Applications=InSRAM
#RetainType.Applications=OnPowerfail
#Application.FirstLoadInitRetains=1
#Bootproject.CreateOnDownload=0
Application.1= MY_APPLICATION_NAME
  
```

Change MY_APPLICATION_NAME to the specific name used in CoDeSys.

```
Application.1= Application
```

Please note by default "Application" is used as name for the application.

Instead of using the node id or hostname to identify the AWC 500 , then an additional Nodename can be set.

Add the lines:

```
[SysTarget]
NodeName=MY_NODE_NAME
```

Eg:

```
[SysTarget]
NodeName=awc500pcm-test-rack-c
```

Note: Do no change other settings in the codesys.cfg file, as it may harm the AWC 500 unit.

1.13.2 Generated boot project package

The generated boot project package now looks like:

\release\visu	Visualization files.
\release\Application.*	Visualization files
\release\Application.app	Boot project application
\release\Application.crc	Check sum file




Figure 1.24: Contents of the "visu" folder




Figure 1.25: Contents of the "release" folder

1.13.3 Remote upload procedure

1. Stop existing turbine application to pause/idling state.
2. Login via SFTP to the AWC 500 .
3. Upload the boot project package
4. Delete all files under /app/service/codesys/app (right pane Figure 1.26)
5. Upload all files (right pane Figure 1.26) under \release to /app/service/codesys/app




Figure 1.26: Remote upload procedure




Figure 1.27: Uploaded files

6. On the AWC 500 change folder to /app/service/codesys/visu
7. Delete all existing files
8. Upload the new visualization files from \release\visu to /app/service/codesys/visu, see Figure 1.28




Figure 1.28: Remote upload procedure, "visu" folder




Figure 1.29: Uploaded files

9. Finally do a remote reboot via SSH

2 AWC 500 module configurations

For each AWC 500 module physical inputs and outputs are linked under the "EtherCAT I/O Mapping" pane. Additional for each module start-up parameters can be set, to configure the module.

2.1 PCM5-1 – Power and Control Module

2.1.1 PCM5-1 – Terminal Description

Terminal	CoDeSys Process Variable	Terminal	CoDeSys Process Variable
6	Power supply Primary	10	Power supply Secondary
7	Power supply Primary	11	Power supply Secondary
8	In	12	Out
9	In	13	Out
	Digital Input		Relay output

2.1.2 PCM5-1 – EtherCAT I/O Mapping




Figure 2.1: PCM5-1 – EtherCAT I/O Mapping

Channel	IEC Address	Type	Description
Relay out	%QX*	BIT	Relay out
Relay feedback	%IX*	BIT	Relay feedback
Digital Input	%IX*	BIT	Digital Input
Power Primary	%IX*	BIT	Power Primary

2.1.3 PCM5-1 – Startup parameters

Currently none.

2.2 IOM5.1 – Input and Output Module

2.2.1 IOM5.1 – Terminal Description

Terminals		CODESYS Process Variable	Description
1–4	T1	Temp1	Temperature 1
5–8	T1	Temp2	Temperature 2
9–12	T1	Temp3	Temperature 3
41–44	T1	Temp4	Temperature 4
45–48	T1	Temp5	Temperature 5
49–42	T1	Temp6	Temperature 6
13–15	AI1	AI 1	Analogue Input 1. 13–14 using -20...20 mA input, 14–15 using -10...10 V input
16–18	AI2	AI 2	Analogue Input 2. 16–17 using -20...20 mA input, 17–18 using -10...10 V input
53–55	AI3	AI 3	Analogue Input 3. 53–54 using -20...20 mA input, 54–55 using -10...10 V input
56–58	AI4	AI 4	Analogue Input 4. 56–57 using -20...20 mA input, 57–58 using -10...10 V input
19–20	AO1	AO 1	Analogue Output -20...20 mA
21–22	AO2	AO 2	Analogue Output -20...20 mA
59–60	AO3	AO 3	Analogue Output -20...20 mA
61–62	AO4	AO 4	Analogue Output -20...20 mA
23	DI1	DI 1	Digital input 1
24	DI2	DI 2	Digital input 2
25	DI3	DI 3	Digital input 3
26	DI4	DI 4	Digital input 4
27	DI5	DI 5	Digital input 5
28	DI6	DI 6	Digital input 6
29	DI COM		Digital common input reference supply (DI1–DI12). 24 V for NPN input signal, GND for PNP input signal. Note: Terminal 29 and 69 are internally connected
63	DI7	DI 7	Digital input 7
64	DI8	DI 8	Digital input 8
65	DI9	DI 9	Digital input 9
66	DI10	DI 10	Digital input 10
67	DI11	DI 11	Digital input 11
68	DI12	DI 12	Digital input 12
69	DI COM		Digital common input reference supply (DI1–DI12). 24 V for NPN input signal, GND for PNP input signal. Note: Terminal 29 and 69 are internally connected
30–31	FI1	DIF 1 Tper1	Frequency input 1, NPN or PNP coupling Digital input 13, 30+, 31-
32–33	FI2	DIF 2 Tper2	Frequency input 2, NPN or PNP coupling Digital input 14, 32+, 33-
70–71	FI3	DIF 3 Tper3	Frequency input 3, NPN or PNP coupling Digital input 15, 70+, 71-
72–73	FI4	DIF 4 Tper4	Frequency input 4, NPN or PNP coupling Digital input 16, 72+, 73-
34	DO SUP+		24 V digital output supply. Note: Terminals 34 and 74 are internally connected
35	DO1	DO1	Digital Output 1
36	DO2	DO2	Digital Output 2
37	DO3	DO3	Digital Output 3
38	DO4	DO4	Digital Output 4
39	DO5	DO5	Digital Output 5
40	DO SUP-		GND digital output supply. Note: Terminals 40 and 80 are internally connected
74	DO SUP+		24 V digital output supply. Note: Terminals 34 and 74 are internally connected
75	DO6	DO6	Digital Output 6
76	DO7	DO7	Digital Output 7
77	DO8	DO8	Digital Output 8
78	DO9	DO9	Digital Output 9
79	DO10	DO10	Digital Output 10
80	DO SUP-		GND digital output supply. Note: Terminals 40 and 80 are internally connected

2.2.2 IOM5.1 –EtherCAT I/O Mapping




Figure 2.2: IOM5.1 – EtherCAT I/O Mapping

Channel	IEC Address	Type	Value range	Description
Digital Inputs				
DI 1...12	%IX*	BIT	0/1	Filtered state of digital inputs 1...12
DIF 1...4	%IX*	BIT	0/1	Filtered state of digital inputs 13...16
DO Status	%IB*	BYTE	0...3	<p>Digital output status diagnostics</p> <p>Bit 0 indicate the status of the digital outputs. 0: An error is indicated if one of the following conditions is filled:</p> <ul style="list-style-type: none"> • Supply voltage is below 8 V • Supply voltage is above 37 V • Error is reported on one of the digital output drivers. (Over-current or over-temperature) <p>After power-up the digital output (EnableDO) has to be enabled before error-bit is reset.</p> <p>If an over-current or over-temperature status has occurred, the digital outputs (EnableDO) have to be disabled and then enabled again to clear the error state.</p> <p>1 : Digital Outputs are OK</p> <p>Bit 1 indicates state of IOM calibration. 0 : NOT calibrated, 1 : Calibrated</p>

The digital inputs do not require any further configuration.

Channel	IEC Address	Type	Value range	Description
Digital Frequency Inputs				
Tper1...4	%ID*	UDINT	0...4294967295	Number of 800ns counts for one set of pulses (see: number of pulses in Digital Frequency Input configuration in Module Parameters)
Freqcount1...4	%ID*	UDINT	0...4294967295	Value in Freqcount is incremented each time a new pulse is detected.
Omega1	%ID*	DINT	±2147483647	Actual rotational speed normalized to $\pm 2^{31}$ corresponds to +/-1047.197551 rad/s
Alpha1	%ID*	DINT	±2147483647	Actual rotational acceleration normalized to $\pm 2^{31} = +/-1047.197551 \text{ rad/s}^2$

The Freqcount channel should be used to verify if the eg. the generator shaft is moving or not. If Freqcount is not increased for a time corresponding to the minimum speed of the shaft then the Tper channel should be dismissed and the RPM set to 0. For frequency input 1 on each IMO5.1 two additional values are offered directly: Omega1 offers the actual rotational speed and Alpha1 offers the acceleration. They can for example be used to detect or filter any physically impossible/unplanned speeds, accelerations or de-accelerations.

Channel	IEC Address	Type	Value range	Description
Analog Inputs				
AI 1...4	%IW*	INT	-25000...+25000	Actual reading (3-samples average) of analog input channel (±10 V or ±20 mA)

The Analog inputs type is configured with startup parameters Analog input 1...4 config.

Channel	IEC Address	Type	Value range	Description
Temperature Inputs				
Temp1...6	%IW*	INT	-25000...+25000	Actual temperature channel 1...6 average of last second's samples Temperature diagnostics: -32768 : Indicates a shortcircuit sensor 32767 : indicates an open sensor-input 0: indicates 0.0 °C -500...10000 (PT100) : indicates the actual temperature in 0.1 °C units

The Temperature input type is configured with startup parameters Temperature 1...6 config.

Channel	IEC Address	Type	Value range	Description
Digital outputs				
DO 1...10	%QX*	Bit	0/1	0 = sink(default), 1= source
Enable DO	%QX*	Bit		Enables digital outputs(default disabled)



Please note each cycle **EnableDO** must be set **TRUE** via a variable assigned **TRUE**.
eg. `IOM51_EnableDO := TRUE;` to enable the digital output.

Channel	IEC Address	Type	Value range	Description
Analogue output				
AO 1...4	%QW*	INT	-25000...+25000	New setpoint for Analogue Output channel 1...4 -25000: sets the output to -20 mA sink 0 :sets the Output as close as possible to 0 mA +25000 sets the Output to +20 mA
Enable AO	%QX*	BIT		Enables analogue outputs(default disabled)

2.2.3 IOM5.1 – Startup parameters

Analog input 1...4 config




Figure 2.3: Analog input 1...4 config

Channel	Type	Value range	Description
Analog input 1...4 config			
AI Config Bit0: Input type	USINT	0...1	Selects input type: Current(0):-20...+20mA Voltage(1): -10...+10V

DIF 1...4 config




Figure 2.4: DIF 1 config

Channel	Type	Value range	Description
DIF 1...4 config			
Pulses per revolution: (1...12)	BYTE	1...12 129(1+128)...140(1+128)	Number of pulses per revolution for frequency input channel 1...4 Bit 7: 0 = HW divider is disabled, 1 = HW divider is enabled
HW divider: (0...255) 0 means division = 1	BYTE	0...255	HW divider setting of frequency input channel 1 to 4 0 : the divider is disabled

The working principal is illustrated on the figure below:




Figure 2.5: Frequency input signal patch

Optocoupler : The highspeed optocoupler reacts on input voltages above 9V.

HW filter : Filters unwanted signals.

HW divider : The HW divider divides down the input frequency to a signal below 1kHz.

SW Filter : Removes all pulses (positive or negative) of the signal after the divider <200us.

Capturer : At a low to high transaction an internal free-running counter is read and stored. Tper1...4 is calculated and Freqcount1...4 increased each pulse or on each N number of pulses.

See below examples on how to use the parameters based on different sensor types.

IOM5-1 – Frequency Input conversion example 2048 pulse encoder

In this example two physical speed measurements, rotor and generator speed are to be captured:

Rotor speed settings:

The physical range is 0..20 [RPM]

At 20 RPM the pulses per seconds are then :

$$f = 20 \text{ [RPM]} / 60 * 2048 \text{ (encoder pulses per revolution)} = 682 \text{ [Hz]}$$

This is less than 1 kHz thus we can use the parameters

Pulses per revolution: (1...12): 1

(Meaning it measure between every one pulse)

HW divider: (0...255): 0

Generator speed settings:

Physical range is ca. 0..2000 [RPM]

At 2000 RPM the pulses per seconds are then :

$$f = 2000 \text{ [RPM]} / 60 * 2048 \text{ (encoder pulses per revolution)} = 68200 \text{ [Hz]}$$

This is higher than 1 kHz thus we need to use the HW divider settings - easiest is to use highest settings for HW divider:

Pulses per revolution: (1... 12) : 129 (1+128) as adding 128 to enable the HW divider.

(Meaning it measure between every one pulse)

HW divider: (0... 255) : 128 (Divides the input frequency up to 125 kHz by 128)

Line	IndexSubindex	Name	Value	Bitlength	Abort if error	Jump to line if error	Next line	Comment
1	16#8030:16#01	Pulses per revolution: (1...12)	1	8	<input type="checkbox"/>	<input type="checkbox"/>	0	
2	16#8030:16#02	HW divider: (0...255) 0 means division = 1	1	8	<input type="checkbox"/>	<input type="checkbox"/>	0	
3	16#8031:16#01	Pulses per revolution: (1...12)	129	8	<input type="checkbox"/>	<input type="checkbox"/>	0	
4	16#8031:16#02	HW divider: (0...255) 0 means division = 1	128	8	<input type="checkbox"/>	<input type="checkbox"/>	0	

Figure 2.6: Startup parameters

The Encoder pulses per revolution(here 2048 encoder pulses per revolution) are changed in the code in the conversion from measured frequency to rotational speed [rpm] calculation.

The Frequency counter input TperX from the IOM 5.1 card returns a count of 800 ns. To convert this to a frequency [Hz] or a rotational speed in [RPM], the calculation follows :

To get a frequency [Hz] the formular is :

(* PPR : Pulses per revolution: (1...12)*)

(* HWD : HW divider: (0...255) *)

$$f \text{ [Hz]} = 1 / (TperX * 800 * 10^{-9}) * PPR * HWD$$

or

```
(* PPR : Pulses per revolution: (1...12)*)
(* HWD : HW divider: (0...255) *)
f [Hz] = 1250000.0 / TperX * PPR * HWD
```

To get a [rpm] then multiply with 60:

$$\Omega_{\text{RPM}} = f * 60 / \text{EPPR} \quad (* \text{EPPR} = \text{encoder pulses per revolution} *)$$

Program example:

```
VAR
    rRotorSpeed_Hz          : LREAL;
    rRotorSpeed_RPM        : LREAL;
    udiPrevFreqcount1      : UDINT;
    uiRotorTimeOutCnt      : UINT;

    rGeneratorSpeed_Hz     : LREAL;
    rGeneratorSpeed_RPM    : LREAL;
    udiPrevFreqcount2      : UDINT;
    uiGeneratorTimeOutCnt  : UINT;
END_VAR

(* Rotor speed *)
IF IOM51_Freqcount1 <> udiPrevFreqcount1 THEN
    IF IOM51_Tper1 <> 16#FFFFFF AND IOM51_Tper1 <> 16#00000000 THEN
        (* PPR: Pulses per revolution 1...12: 1 Measure Tper over each pulse *)
        (* HWD: HW divider 0...255: 1 Divides the input frequency up to 125 kHz by 1 *)
        rRotorSpeed_Hz := 1250000.0 / UDINT_TO_LREAL(IOM51_Tper1) * 1.0 (*PPR*) * 1.0 (*HWD*); (*[Hz]*)
        rRotorSpeed_RPM := 60.0 * rRotorSpeed_Hz / 2048.0 (* encoder pulses per revolution *); (*[RPM]*)
    END_IF
    uiRotorTimeOutCnt := 50; (* Reset timeout for pulses, 50 * 0.020 sec = 1 sec *)
ELSE
    IF uiRotorTimeOutCnt > 0 THEN
        uiRotorTimeOutCnt := uiRotorTimeOutCnt - 1;
    ELSE
        rRotorSpeed_RPM := 0.0;
    END_IF
END_IF

(* Generator speed *)
IF IOM51_Freqcount2 <> udiPrevFreqcount2 THEN
    IF IOM51_Tper2 <> 16#FFFFFF AND IOM51_Tper2 <> 16#00000000 THEN
        (* PPR: Pulses per revolution 1...12: 129 1 + 128, measure Tper over each pulse, and adding 128 to enable the HW divider. *)
        (* HWD: HW divider 0...255: 128 Divides the input frequency up to 125 kHz by 128 *)
        rGeneratorSpeed_Hz := 1250000.0 / UDINT_TO_LREAL(IOM51_Tper2) * 1.0 (*PPR*) * 128.0 (*HWD*); (*[Hz]*)
        rGeneratorSpeed_RPM := 60.0 * rGeneratorSpeed_Hz / 2048.0 (* encoder pulses per revolution *); (*[RPM]*)
    END_IF
    uiGeneratorTimeOutCnt := 50; (* Reset timeout for pulses, 50 * 0.020 sec = 1 sec *)
ELSE
    IF uiGeneratorTimeOutCnt > 0 THEN
        uiGeneratorTimeOutCnt := uiGeneratorTimeOutCnt - 1;
    ELSE
        rGeneratorSpeed_RPM := 0.0;
    END_IF
END_IF

udiPrevFreqcount1 := IOM51_Freqcount1;
udiPrevFreqcount2 := IOM51_Freqcount2;
```

Variable	Mapping	Channel	Address	Type	Current Value	Prepared Value	Unit	Description
D1 6		DI 6	%IX580.5	BIT	FALSE			DI 6
D1 7		DI 7	%IX580.6	BIT	FALSE			DI 7
D1 8		DI 8	%IX580.7	BIT	FALSE			DI 8
D1 9		DI 9	%IX581.0	BIT	FALSE			DI 9
D1 10		DI 10	%IX581.1	BIT	FALSE			DI 10
D1 11		DI 11	%IX581.2	BIT	FALSE			DI 11
D1 12		DI 12	%IX581.3	BIT	FALSE			DI 12
DIF 1		DIF 1	%IX581.4	BIT	FALSE			DIF 1
DIF 2		DIF 2	%IX581.5	BIT	TRUE			DIF 2
DIF 3		DIF 3	%IX581.6	BIT	FALSE			DIF 3
DIF 4		DIF 4	%IX581.7	BIT	FALSE			DIF 4
DO STATUS		DO STATUS	%IW291	INT	0			DO STATUS
AI 1		AI 1	%IW292	INT	-16			AI 1
AI 2		AI 2	%IW293	INT	-16			AI 2
AI 3		AI 3	%IW294	INT	-16			AI 3
AI 4		AI 4	%IW295	INT	-15			AI 4
IOM51_POSS30A1_Tper1		Tper1	%ID148	UDINT	62380			Tper1
IOM51_POSS30A1_Freqcount1		Freqcount1	%ID149	UDINT	133344			Freqcount1
		Omega1	%ID150	DINT	258193776			Omega1
		Alpha1	%ID151	DINT	0			Alpha1
IOM51_POSS30A1_Tper2		Tper2	%ID152	UDINT	7984677			Tper2
IOM51_POSS30A1_Freqcount2		Freqcount2	%ID153	UDINT	35809			Freqcount2
		Tper3	%ID154	UDINT	4294967295			Tper3
		Freqcount3	%ID155	UDINT	0			Freqcount3
		Tper4	%ID156	UDINT	4294967295			Tper4
		Freqcount4	%ID157	UDINT	0			Freqcount4
		Temp1	%IW316	INT	32767			Temp1
		Temp2	%IW317	INT	32767			Temp2
		Temp3	%IW318	INT	32767			Temp3
		Temp4	%IW319	INT	32767			Temp4
		Temp5	%IW320	INT	32767			Temp5
		Temp6	%IW321	INT	32767			Temp6

Figure 2.7: Startup parameters

Recommended setting - when using encoder with 2048 pulses per revolution Number of pulses (1...12) : 129 (1 + 128) HW divider (0...255) : 128




Figure 2.8: Wire setup

IOM – Frequency Input conversion example for inductive sensor based speed detection with 8 holes per revolution

Number of pulses (1...12) : 129 (1 + 128) HW divider (0...255) : 0 (or 1)




Figure 2.9: Wire setup

The Tper is updated and Freqcount is increased by 1, at each detected pulse.

Here the recommended settings for inductive sensor based speed detection with 8 holes per revolution are to change the "Number of pulses" to 8. The advantage by setting the update with the detection by each 8 holes, is that Tper is updated each revolution. Number of pulses (1...12) : 136 (8 + 128) HW divider (0...255) : 0 (or 1)




Figure 2.10: Wire setup

Temperature 1...6 config




Figure 2.11: Wire setup




Figure 2.12: Sensor type

Channel	Type	Value range	Description
Temperature 1...6 config			
Wire setup	USINT	0...3	2_Wire: PT100/1000 2 wire 3_Wire: PT100/1000 3 wire 4_Wire: PT100/1000 4 wire
Sensor type	USINT	0...2	Pt100: PT100 sensor Pt1000: PT1000 sensor NiCr: NiCr sensor

Analog output 1...4 config

Channel	Type	Value range	Description
Analog output 1...4 config			
AO Config.	UINT	0...1000	Linear Interpolation in ms for DA Output channel




Figure 2.13: Analog output config

The linear interpolation can be set individually for the outputs. This means that the outputs can be changed linear over time instead of a step.

See example below, where output 1 is changed from 10 to 20 mA in a step and output 2 is changed from 10 to 20 mA linear over time.




Figure 2.14: Linear interpolation

2.3 IOM5.2 – Input and Output Module

2.3.1 IOM5.2 – Terminal Description

Terminals	CODESYS Process Variable	Description
23	DI1	DI 1
24	DI2	DI 2
25	DI3	DI 3
26	DI4	DI 4
27	DI5	DI 5
28	DI6	DI 6
29	DI COM	Digital common input reference supply (DI1–DI12). 24 V for NPN input signal, GND for PNP input signal. Note: Terminal 29 and 69 are internally connected
63	DI7	DI 7
64	DI8	DI 8
65	DI9	DI 9
66	DI10	DI 10
67	DI11	DI 11
68	DI12	DI 12
69	DI COM	Digital common input reference supply (DI1–DI12). 24 V for NPN input signal, GND for PNP input signal. Note: Terminal 29 and 69 are internally connected
30	DI13+	DI 13
31	DI13-	DI 13
32	DI14+	DI 14
33	DI14-	DI 14
70	DI15+	DI 15
71	DI15-	DI 15
72	DI16+	DI 16
73	DI16-	DI 16
34	DO SUP+	24 V digital output supply. Note: Terminals 34 and 74 are internally connected
35	DO1	DO1
36	DO2	DO2
37	DO3	DO3
38	DO4	DO4
39	DO5	DO5
40	DO SUP-	GND digital output supply. Note: Terminals 40 and 80 are internally connected
74	DO SUP+	24 V digital output supply. Note: Terminals 34 and 74 are internally connected
75	DO6	DO6
76	DO7	DO7
77	DO8	DO8
78	DO9	DO9
79	DO10	DO10
80	DO SUP-	GND digital output supply. Note: Terminals 40 and 80 are internally connected

2.3.2 IOM5.2 –EtherCAT I/O Mapping




Figure 2.15: IOM5.2 – EtherCAT I/O Mapping

Channel	IEC Address	Type	Value range	Description
Digital Inputs				
DI 1... 16	%IX*	BIT	0/1	Filtered state of digital inputs 1... 16
DO Status	%IW*	INT	0... 3	<p>Digital output status diagnostics</p> <p>Bit 0 indicate the status of the digital outputs.</p> <p>0: An error is indicated if one of the following conditions is filled:</p> <ul style="list-style-type: none"> • Supply voltage is below 8 V • Supply voltage is above 37 V • Error is reported on one of the digital output drivers. (Over-current or over-temperature) <p>After power-up the digital output (EnableDO) has to be enabled before error-bit is reset.</p> <p>If an over-current or over-temperature status has occurred, the digital outputs (EnableDO) have to be disabled and then enabled again to clear the error state.</p> <p>1 : Digital Outputs are OK</p> <p>Bit 1 indicates state of IOM calibration.</p> <p>0 : NOT calibrated, 1 : Calibrated</p>

The digital inputs do not require any further configuration.

Channel	IEC Address	Type	Value range	Description
Digital outputs				
DO 1... 10	%QX*	Bit	0/1	0 = sink(default), 1= source
Enable DO	%QX*	Bit		Enables digital outputs(default disabled)

Please note each cycle EnableDO must be set TRUE via a variable assigned TRUE.
eg. IOM52_EnableDO := TRUE; to enable the digital output.

2.3.3 IOM5.2 – Startup parameters




Figure 2.16: IOM5.2 enable digital outputs from startup parameters

The digital outputs can be enabled from the startup parameters by setting Enable DO to TRUE, see Figure 2.16.

2.4 DIM5-1 – Input and Output Module

2.4.1 DIM5-1 – Terminal Description

Terminals		CODESYS Process Variable	Description
1	DO A SUP+		24 V digital output supply for DO1-DO8; Group A
2	DO1	DO1	Digital Output 1
3	DO2	DO2	Digital Output 2
4	DO3	DO3	Digital Output 3
5	DO4	DO4	Digital Output 4
6	DO5	DO5	Digital Output 5
7	DO6	DO6	Digital Output 6
8	DO7	DO7	Digital Output 7
9	DO8	DO8	Digital Output 8
10	DO A SUP-		GND digital output supply for DO1-DO8; Group A
38	DO A SUP+		24 V digital output supply for DO9-D16; Group B
39	DO9	DO9	Digital Output 9
40	DO10	DO10	Digital Output 10
41	DO11	DO11	Digital Output 11
42	DO12	DO12	Digital Output 12
43	DO13	DO13	Digital Output 13
44	DO14	DO14	Digital Output 14
45	DO15	DO15	Digital Output 15
46	DO16	DO16	Digital Output 16
47	DO A SUP-		GND digital output supply for DO9-D16; Group B
21	DI1	DI 1	Digital input 1
22	DI2	DI 2	Digital input 2
23	DI3	DI 3	Digital input 3
24	DI4	DI 4	Digital input 4
25	DI5	DI 5	Digital input 5
26	DI6	DI 6	Digital input 6
27	DI7	DI 7	Digital input 7
28	DI8	DI 8	Digital input 8
29	DI A COM		Digital common input reference supply (DI1-DI8). 24 V for NPN input signal, GND for PNP input signal.
58	DI9	DI 9	Digital input 9
59	DI10	DI 10	Digital input 10
60	DI11	DI 11	Digital input 11
61	DI12	DI 12	Digital input 12
62	DI13	DI 13	Digital input 13
63	DI14	DI 14	Digital input 14
64	DI15	DI 15	Digital input 15
65	DI16	DI 16	Digital input 16
66	DI B COM		Digital common input reference supply (DI9-DI16). 24 V for NPN input signal, GND for PNP input signal.
30	DI17	DI 17	Digital input 17
31	DI18	DI 18	Digital input 18
32	DI19	DI 19	Digital input 19
33	DI20	DI 20	Digital input 20
34	DI21	DI 21	Digital input 21
35	DI22	DI 22	Digital input 22
36	DI23	DI 23	Digital input 23
37	DI C COM		Digital common input reference supply (DI17-DI23). 24 V for NPN input signal, GND for PNP input signal.
67	DI24	DI 24	Digital input 24
68	DI25	DI 25	Digital input 25
69	DI26	DI 26	Digital input 26
70	DI27	DI 27	Digital input 27
71	DI28	DI 28	Digital input 28
72	DI29	DI 29	Digital input 29
73	DI30	DI 30	Digital input 30
74	DI D COM		Digital common input reference supply (DI24-D30). 24 V for NPN input signal, GND for PNP input signal.

2.5 GPM5.1 – Grid Protection Module

2.5.1 GPM5.1 – Terminal Description

Terminal	Description	CoDeSys Process Variable
1 S1	Current L1	IL1
2 S2		
3 S1	Current L2	IL2
4 S2		
5 S1	Current L3	IL3
6 S2		
7 L1	Voltage L1	UgUN
8 L2	Voltage L2	UgVN
9 L3	Voltage L3	UgWN
10 N	Neutral	
11 L1	Voltage L1	UL1N
12 L2	Voltage L2	UL2N
13 L3	Voltage L3	UL3N
14 N	Neutral	
	Breaker ON/OFF	
15	Breaker On	SyncOK
16		
17	Breaker Off	
18		
	Feedback	
19 ON	Breaker FB On	
20 COM.	Common	
21 OFF	Breaker FB Off	

2.5.2 GPM5-1 - EtherCAT I/O Mapping




Figure 2.18: GPM5-1 - EtherCAT I/O Mapping

Channel	IEC Address	Type	Value range	Description
EnableProtectionMask	%QW*	UINT		EnableProtectionMask
RouteThroughMask	%IW*	UINT		RouteThroughMask

Channel	IEC Address	Type	Value range	Description
Generator voltages (Star)				Voltages UgU,V,WN : a value of 27027 means Un (either 240/sqr(3)Vrms or 690/sqr(3)Vrms is present)
UgUN	%IW*	UINT	0...65535	Normalized Voltage between Generator U-N
UgVN	%IW*	UINT	0...65535	Normalized Voltage between Generator V-N
UgWN	%IW*	UINT	0...65535	Normalized Voltage between Generator W-N

Channel	IEC Address	Type	Value range	Description
Generator currents				Currents IL1,2,3 : a value of 15604 means In (either 1 Arms or 5 Arms) is present
IL1	%IW*	UINT		Normalized current in UN/L1
IL2	%IW*	UINT		Normalized current in VN/L2
IL3	%IW*	UINT		Normalized current in WN/L3

Channel	IEC Address	Type	Value range	Description
Active and reactive power				Real/Blindpower Psum, Qsum : a value of 365218308 means $U_n * I_n * \sqrt{3}$ is present in all 3 phases together
P	%ID*	DINT	$-2^{31} \dots 2^{31}-1$	Normalized Realpower in all 3 Phases ($U_{gUN} * I_{UL1} * \cos(\text{Phi UI}) + U_{gVN} * I_{VL2} * \cos()2 + U_{gWN} * I_{WL3} * \cos()3$) / ($\sqrt{3} * U_n * I_n$) * 365218308
Q	%ID*	DINT	$-2^{31} \dots 2^{31}-1$	Normalized Blindpower in all 3 Phases ($U_{gUN} * I_{UL1} * \sin(\text{Phi UI})1 + U_{gVN} * I_{VL2} * \sin()2 + U_{gWN} * I_{WL3} * \sin()3$) / ($\sqrt{3} * U_n * I_n$) * 365218308
FreqDiff	%IW*	INT	-32768...32767	Normalized frequency difference between Bus Bar measurement and nominal frequency (50 Hz or 60 Hz) -32768 : frequency too low for measurement 0 : frequency is equal nominal frequency (either 50 Hz or 60 Hz) +32767 : indicates double frequency (either 100 Hz or 120 Hz), frequency is too high to be measured correct

Channel	IEC Address	Type	Value range	Description
Active power				P1,2,3, Q1,2,3 : 121739436 : $U_n / \sqrt{3} * I_n$ is present
P1	%ID*	DINT	$-2^{31} \dots 2^{31}-1$	Normalized Realpower in Phase 1 ($U_{gUN} * I_{UL1} * \cos(\text{Phi UI})1 / (U_n * I_n) * 121739436$)
P2	%ID*	DINT	$-2^{31} \dots 2^{31}-1$	Normalized Realpower in Phase 2
P3	%ID*	DINT	$-2^{31} \dots 2^{31}-1$	Normalized Realpower in Phase 3
Reactive power				
Q1	%ID*	DINT	$-2^{31} \dots 2^{31}-1$	Normalized Blindpower in Phase 1 ($U_{gUN} * I_{UL1} * \sin(\text{Phi UI})1 / (U_n * I_n) * 121739436$)
Q2	%ID*	DINT	$-2^{31} \dots 2^{31}-1$	Normalized Blindpower in Phase 2
Q3	%ID*	DINT	$-2^{31} \dots 2^{31}-1$	Normalized Blindpower in Phase 3

Channel	IEC Address	Type	Value range	Description
Generator voltages Phase-Phase				46811 : U_n (either 240 Vrms or 690 Vrms is present)
UgUV	%IW*	UINT	0...65535	Normalized Voltage between Generator U-V
UgVW	%IW*	UINT	0...65535	Normalized Voltage between Generator V-W
UgWU	%IW*	UINT	0...65535	Normalized Voltage between Generator W-U

Channel	IEC Address	Type	Value range	Description
Busbar Voltages (Star)				UL1,L2,L3 N : a value of 27027 means Un (either 240/sqr(3)Vrms or 690/sqr(3)Vrms is present)
UL1N	%IW*	UINT	0...65535	Normalized Voltage between BusBar L1-N
UL2N	%IW*	UINT	0...65535	Normalized Voltage between BusBar L2-N
UL3N	%IW*	UINT	0...65535	Normalized Voltage between BusBar L3-N
Busbar Voltages (Delta)				A value of 46811 means Un (either 240 Vrms or 690 Vrms is present
UL1L2	%IW*	UINT	0...65535	Normalized Voltage between BusBar L1 and L2
UL2L3	%IW*	UINT	0...65535	Normalized Voltage between BusBar L2 and L3
UL3L1	%IW*	UINT	0...65535	Normalized Voltage between BusBar L3 and L1

Channel	IEC Address	Type	Value range	Description
Synchronization				UdiffL1U,L2V,L3W : a value of 46811 means Un (either 240 Vrms or 690 Vrms is present) Value -32768 means, frequency too low for measurement 0 means frequency is equal nominal frequency (either 50 Hz or 60 Hz) +32767 indicates double frequency (either 100 Hz of 120 Hz) and means, frequency is too high to be measured correct
UdiffL1U	%IW*	UINT	0...65535	Normalized Voltage between BusBar L1 and Generator U
UdiffL2V	%IW*	UINT	0...65535	Normalized Voltage between BusBar L2 and Generator V
UdiffL3W	%IW*	UINT	0...65535	Normalized Voltage between BusBar L3 and Generator W
PhiGenUBBL1	%IW*	INT	-32768...32767	Normalized Phaseangle between BusBar L1 and Generator U based upon zero-cross
PhiGenVBBL2	%IW*	INT	-32768...32767	Normalized Phaseangle between BusBar L2 and Generator V based upon zero-cross
PhiGenWBBL3	%IW*	INT	-32768...32767	Normalized Phaseangle between BusBar L3 and Generator W based upon zero-cross
FreqDiffL1	%IW*	INT		FreqDiffL1
FreqDiffL2	%IW*	INT		FreqDiffL2
FreqDiffL3	%IW*	INT		FreqDiffL3
PhiBBL1L2	%IW*	INT		PhiBBL1L2
PhiBBL2L3	%IW*	INT		PhiBBL2L3
PhiBBL3L1	%IW*	INT		PhiBBL3L1
BreakerFeedback	%IW*	UINT		BreakerFeedback
TripFeedback	%IW*	UINT		TripFeedback

2.5.3 GPM5-1 – Startup parameters

Transducers




Figure 2.19: Transducers

Parameter	Type	Value range	Description
Transducer	UINT	0...64	Bit 0: AC nominal Input Voltage: 0= Un<=690 V; 1= Un<=240 V Bit 1 : nominal Input Current: 0= In=5 Arms; 1=In = 1 Arms Bit 2 : nominal frequency: 0=50 Hz; 1=60 Hz N.A Bit 3: polarity of trip output: 0=ND; 1 = NE (Not implemented) N.A Bit 4: DC nominal Input Voltage: 0= Un=400 V; 1= Un=140 V N.A Bit 5: Enable Direct Relay Handling - Relay 1: 0= Not enable; 1= Enable N.A Bit 6: Enable Direct Relay Handling - Relay 2: 0= Not enable; 1= Enable Bit 7...Bit 15 : not used

2.5.4 GPM5-1 – Conversion source code

PROGRAM PRG_CalculateGridValues
VAR

```

rFactorVoltage : LREAL;
rFactorCurrent : LREAL;
rFactorPower   : LREAL;
rTempValue     : LREAL;

rUL1N : LREAL; (* star voltage L1 N in [V] *)
rUL2N : LREAL; (* star voltage L2 N in [V] *)
rUL3N : LREAL; (* star voltage L3 N in [V] *)

rIL1 : LREAL; (* measurement grid Current L1 in [A] *)
rIL2 : LREAL; (* measurement grid Current L2 in [A] *)
    
```

```

rIL3   : LREAL;      (* measurement grid Current L3 in [A] *)

rPsum  : LREAL;      (* active Power in all 3 Phases in [W] *)
rPL1   : LREAL;      (* active Power in L1 in [W] *)
rPL2   : LREAL;      (* active Power in L2 in [W] *)
rPL3   : LREAL;      (* active Power in L3 in [W] *)

rQsum  : LREAL;      (* reactive Power in all 3 Phases in [VAR] *)
rQL1   : LREAL;      (* reactive Power in L1 in [VAR] *)
rQL2   : LREAL;      (* reactive Power in L2 in [VAR] *)
rQL3   : LREAL;      (* reactive Power in L3 in [VAR] *)

rSsum  : LREAL;      (* apparent Power in all 3 Phases in [VAR] *)

rFreq  : LREAL;      (* average Frequency of voltage on the 3 phases , range
                      0...100 Hz *)

rCosPhi : LREAL;

END_VAR
VAR CONSTANT
rNOMINAL_FREQUENCY : LREAL := 50.000; (* nominal frequency = 50.000 mHz = 50 Hz*)
END_VAR

(* volt per bit = 690 V per 46811bit bits = 14.740125184251564F *)
rFactorVoltage := 690.0/46811.0; (* Volt per bit raw reading from GPM *)

(*current per bit = 2000 A per 15604 bits = 128.17226352217380158933F *)
rFactorCurrent := 2000.0/15604.0; (* A per bit raw reading from GPM *)

(*power per bit = 2000 A * 400 V * 3 per 365218308 bits = 0.006571412077184257696F*)
rFactorPower := (SQRT(3.0)* 2000.0 * 400.0)/365218308.0; (* W per bit raw reading

rUL1N:= rFactorVoltage * UINT_TO_LREAL(guiGPM_UgUN); (* star voltage L1 N in V *)
rUL2N:= rFactorVoltage * UINT_TO_LREAL(guiGPM_UgVN);
rUL3N:= rFactorVoltage * UINT_TO_LREAL(guiGPM_UgWN);

(* Delta voltages not used
:= rFactorVoltage * UINT_TO_LREAL(guiGPM_UgUV); (* delta Voltage L1 L2 in V *)
:= rFactorVoltage * UINT_TO_LREAL(guiGPM_UgVW);
:= rFactorVoltage * UINT_TO_LREAL(guiGPM_UgWU);
*)

(* CURRENTS : all currents are calculated in unit mArms ( miliampere rms )
CT ratio is 2000 / 1 and GPM delivers 15604 as DU16, when 2000 A are apparent, so the
factor is 2000.000 A / 15604 bit *)
rIL1 := rFactorCurrent * UINT_TO_LREAL(guiGPM_IUL1); (* measurement grid Current *)
rIL2 := rFactorCurrent * UINT_TO_LREAL(guiGPM_IVL2);
rIL3 := rFactorCurrent * UINT_TO_LREAL(guiGPM_IWL3);

(* Power measurement : unit for all values is 1 W FOR realpower and 1 VAR for
Reactivepower GPM delivers 365218308 when 690 V * 2000 A * SQRT(3) is apparent, so the
factor is 2390230.11444 W / 365218308 bit *)
(* active Power in all 3 Phases in W *)
rPsum:= rFactorPower * DINT_TO_LREAL(gdiGPM_Psum) ;
rPL1 := rFactorPower * DINT_TO_LREAL(gdiGPM_P1) ; (* active Power in L1 in W *)
rPL2 := rFactorPower * DINT_TO_LREAL(gdiGPM_P2) ; (* active Power in L2 in W *)
rPL3 := rFactorPower * DINT_TO_LREAL(gdiGPM_P3) ; (* active Power in L3 in W *)

(* reactive Power in all 3 Phases in VAR *)
rQsum := rFactorPower * DINT_TO_LREAL(gdiGPM_Qsum);
rQL1 := rFactorPower * DINT_TO_LREAL(gdiGPM_Q1) ; (* reactive Power in L1 in VAR *)
rQL2 := rFactorPower * DINT_TO_LREAL(gdiGPM_Q2) ; (* reactive Power in L2 in VAR *)
rQL3 := rFactorPower * DINT_TO_LREAL(gdiGPM_Q3) ; (* reactive Power in L3 in VAR *)

(* Frequency measurement : Nominal Frequency 50,000 Hz *)
rFreq := rNOMINAL_FREQUENCY +
        ( rNOMINAL_FREQUENCY * INT_TO_LREAL(giGPM_FreqDiff) * 1.0/32768.00 );

(* Calculate CosPhi


$$\text{CosPhi} = \frac{P}{\text{sprt}( P^2 + Q^2 )}$$


*)
rTempValue := rPsum+rPsum + rQsum+rQsum;
IF ( rTempValue > 0.0 ) THEN
    rSsum := SQRT(rTempValue);
    rCosPhi := rPsum/SQRT(rTempValue);
ELSE
    rCosPhi := 0.0;
    rSsum := 0.0;
END_IF

```

2.6 IFM5.1 – Interface and Fieldbus Module

2.6.1 IFM5.1 – EtherCAT I/O Mapping

SSI – EtherCAT I/O Mapping




Figure 2.20: SSI – EtherCAT I/O Mapping

Channel	IEC Address	Type	Description
Status	%IB*	BYTE	Status
Data	%ID*	UDINT	Data
Count	%IW*	UINT	Count

SSI – Startup parameters




Figure 2.21: SSI – Startup parameters

SSI state




Figure 2.22: SSI state

SSI feature bits




Figure 2.23: SSI feature bits

SSI coding




Figure 2.24: SSI coding

2.6.2 IFM5.1 – Startup parameters




Figure 2.25: IFM5.1 – Startup parameters

RS485 UART – EtherCAT I/O Mapping




Figure 2.26: RS485 UART – EtherCAT I/O Mapping

Channel	IEC Address	Type	Description
Ctrl	%QW*	UINT	Ctrl
Data out 0	%QB*	BYTE	Data out 0
...
Data out 21	%QB*	BYTE	Data out 21

Table 2.1: Transmit

Channel	IEC Address	Type	Description
Status	%IW*	UINT	Status
Data out 0	%IB*	BYTE	Data out 0
...
Data out 21	%IB*	BYTE	Data out 21

Table 2.2: Recieve

RS485 UART – Start-up parameters




Figure 2.27: Baudrate




Figure 2.28: Dataframe




Figure 2.29: Duplex

Rx Trigger level: For the RX SW circular buffer of the IFM.

A warning is given when the trigger level is reached on the RX in the UART. If the level is set to 0 the warning is disabled, if the trigger level is set to 2000 a warning is raised if there are more than 2000 bytes in the RX buffer on IFM5·1 (ie EtherCAT takes bytes of too slow.) There is 2048 bytes reserved for RX.

HW FIFO mode: Setup the number of bytes for the UART FIFO.

Valid options are none, 16 or 64 bytes. If none is selected an interrupt of the IFM CPU will occur each time a byte is received. The default value is 16 bytes.

HW FIFO Trigger: Trigger is used in combination with mode to tell when the FIFO must tell IFM CPU that it has to empty the FIFO. E.g. Mode is set to 16 bytes and trigger to 8 bytes, then the FIFO will be emptied every time there are 8 bytes in it.

In general it is suggested that the trigger level is set to 0, the fifo to 16 and the trigger to 8 (default)

Any other case is for surveillance purposes, or if it is required to run at baudrates larger than 115200.

CAN – EtherCAT I/O Mapping




Figure 2.30: CAN – EtherCAT I/O Mapping

Channel	IEC Address	Type	Description
TxCounter	%QW*	UINT	TxCounter
RxCounter	%QB*	UINT	RxCounter
NumTxMessages	%QB*	UINT	NumTxMessages
TxMsg1_CobId	%QW*	UINT	TxMsg1_CobId
TxMsg1_Byte1	%QB*	BYTE	TxMsg1_Byte1
...
TxMsg1_Byte8	%QB*	BYTE	TxMsg1_Byte8
TxMsg2_CobId	%QW*	UINT	TxMsg2_CobId
...
...
TxMsg10_CobId	%QW*	UINT	TxMsg10_CobId
TxMsg10_Byte1	%QB*	BYTE	TxMsg10_Byte1
...
TxMsg10_Byte8	%QB*	BYTE	TxMsg10_Byte8
AutoResetWhenBusOff	%QX*	BUT	AutoResetWhenBusOff

Table 2.3: Transmit

Channel	IEC Address	Type	Description
TxCounter	%QW*	UINT	TxCounter
RxCounter	%QB*	UINT	RxCounter
NumRxMessages	%QB*	UINT	NumRxMessages
RxMsg1_CobId	%QW*	UINT	RxMsg1_CobId
RxMsg1_Byte1	%QB*	BYTE	RxMsg1_Byte1
...
RxMsg1_Byte8	%QB*	BYTE	RxMsg1_Byte8
RxMsg2_CobId	%QW*	UINT	RxMsg2_CobId
...
...
RxMsg10_CobId	%QW*	UINT	RxMsg10_CobId
RxMsg10_Byte1	%QB*	BYTE	RxMsg10_Byte1
...
RxMsg10_Byte8	%QB*	BYTE	RxMsg10_Byte8

Table 2.4: Recieve

CAN – Start-up parameters




Figure 2.31: AutoResetWhenBusOff

When `AutoResetWhenBusOff` is set as a startup parameter the value is set only once during startup. As an alternative this value can be set each execution cycle. This can be achieved by mapping `AutoResetWhenBusOff` to a global variable, assigned `TRUE`, in the EtherCAT I/O Mapping.

VAR_GLOBAL

```
CANAutoReset : BOOL := TRUE;
```

END_VAR




Figure 2.32: AutoResetWhenBusOff mapped to global variable




Figure 2.33: Baudrate




Figure 2.34: Enable/disable CAN bus

3 Communication

3.1 Creating a CANopen slave interface

If the AWC 500 is to exchange variables information with a CANopen Master e.g. on another AWC 500 system the CANopen slave interface can be used.

- Add CAN Local device to CAN channel of IFM5.1
- Specify variables for exchange
- Generate EDS file for CANopen Master
- Link I/O variables for exchange

3.1.1 Add CAN Local device to CAN channel of IFM5.1("Add→Device...")

Start by adding a device on the IFM5.1:




Figure 3.1: Add device

Change Vendor from DEIF to 3S - Smart Software solutions and select "CAN Local Device":




Figure 3.2: Select CAN Local Device

This creates a local CANopen device. This allows us to generate an EDS file for the CANopen master and specify IO variables for exchange:




Figure 3.3: CAN Local Device

3.1.2 Specify variables for exchange

Start by modifying the CAN EDS file information:




Figure 3.4: Modifying the CAN EDS file information

Then "Edit I/O area. . ." to add variables for exchange:




Figure 3.5: Edit I/O area

Here you can add variables with "Add area...":




Figure 3.6: Add area...




Figure 3.7: Add I/O range




Figure 3.8: Edit I/O area

This creates the variables for exchange:




Figure 3.9: This creates the variables for exchange

The variable `CAN_Local_Device_Digital_Inputs1_1` can be accessed from the PLC program or the mapping of the PDO can be changed to an existing variable in the PLC program.

3.1.3 Generate EDS file for CANopen Master

Finally generate an ESD file with the CANopen slave interface information using "General Information→Generate EDS-file. . ."




Figure 3.10: Generate EDS-file

3.1.4 Monitoring the state of the CANopen slave interface

The IEC Object of the CANopen slave can be accessed to monitor the state:

VAR

```
LocalState : CANOPENSTATE;
```

END_VAR

```
LocalState := CAN_Local_Device.GetState;
```

3.2 AWC 500 Inter system communication

Two AWC 500 systems can communicate together with the CANopen master/slave interface.

This same EDS file create above can be added to the CoDeSys Device repository (Tools→Device repository→Install... (EDS and DCF-files (*.eds, *.dcf))




Figure 3.11: Install Device Description

Then in the CANopen master project add the device under the master:




Figure 3.12: Adding device in CANopen master project

Locate the CANopen slave interface:




Figure 3.13: Locate the CANopen slave interface

Now the CANopen I/O variables are ready for linking:




Figure 3.14: CANopen I/O variables are ready for linking

3.3 Demo

Optionally see the demo project \CANopen Slave interface\CANopen_slave_interface.project

3.4 Setting up a CANopen master

This section describes how to set up a CAN open master on the AWC 500 .

The steps are :

- Add CANopen manager to CAN channel of IFM5.1
- Scan for devices or add the devices manually via EDS files
- Link I/O variables for exchange

3.4.1 Add CANopen manager to CAN channel of IFM5.1("Add→Device...")

The IFM5.1 has two separate CAN channels CAN 1 and CAN 2:




Figure 3.15: The two CAN channels of the IFM5.1




Figure 3.16: Add device

Change Vendor from DEIF to 3S - Smart Software solutions and select CANopen_manager




Figure 3.17: Add CANopen_manager




Figure 3.18: The Project after adding the CANopen Manager



Please note that it is important that the Bus cycle of the EtherCAT master is set to "EtherCAT master task", instead of "parent buscycle"




Figure 3.19: Setting the bus cycle

3.4.2 Scan for CANopen slaves

If online the CANopen master can now scan for devices on the network ("Scan for Devices"):




Figure 3.20: Scan for Devices

Then a dialog box with the found devices will be shown.




Figure 3.21: Devices found



It is only possible to add the device to Device tree, if it is installed in the Device repository

3.4.3 Manually added via EDS files

Alternatively CANopen slaves can be added to a configuration via EDS files.

Adding a CANopen slave EDS file.

Add a CANopen slaves EDS file via Device repository (Tools→Device repository→Install...) Change type to "EDS and DCF files (*.eds, *.dcf)", here an example on a CAN open slave:




Figure 3.22: Install Device Description

Now select "Add Device...":




Figure 3.23: Add device

Locate the device:




Figure 3.24: Locate the device

The device now shows up under the CANopen master:




Figure 3.25: The device is added under the CANopen master

The data in the PDOs are now ready to link to variables in the PLC program:




Figure 3.26: PDO data ready for linking

3.4.4 Monitoring the CANopen slave status

Each CANopen devices added can be access from PLC program via its IEC Object, here CHT4028.




Figure 3.27: Accessing CANopen device from PLC program

```

36 IF ( CHT4028.CANOpenState = CIA405.DEVICE_STATE.OPERATIONAL ) THEN
37   ;(* Operational *)
38 ELSIF( CHT4028.CANOpenState = CIA405.DEVICE_STATE. ) THEN
39   ;(* Slave missing *)
40 ELSE
41   ;(* Error*)
42 END_IF;
43
44
45
46
47
48

```

Figure 3.28: Accessing CANopen device code sample

```

IF ( CHT4028.CANOpenState = CIA405.DEVICE_STATE.OPERATIONAL ) THEN
  ;(* Operational *)
ELSIF( CHT4028.CANOpenState = CIA405.DEVICE_STATE.NOT_AVAIL ) THEN
  ;(* Slave missing *)
ELSE
  ;(* Error *)
END_IF;

```

3.4.5 Demo

Optionally see the demo project \CANopen Master\CANopen_master.project

3.5 Usage of CANopen SDOs

On the CANopen slave, select "Edit SDO Parameter area. . ."




Figure 3.29: Click "Edit SDO Parameter area"

Make the changes:




Figure 3.30: Edit Parameter area

Then "Generate EDS-File. ..."
 Import the generated EDS file.

To send SDOs to the CANopen slave at start up. Add the SDOs to Service Data Object page. Select "New. ..."




Figure 3.31: Select New

From this list the SDO can be selected:




Figure 3.32: Select SDO

Then the SDOs are sent to the CANOpen slave at start up.

For continues exchange for the SDOs to a CANOpen slave, see the CoDeSys help on topics

CIA405.SDO_READ (FB)

CIA405.SDO_WRITE (FB)

3.6 Doing CAN layer II communication

3.6.1 Demo

See the demo project \CAN layer II\testproject-can_layer2_echo.project

3.7 CAN telegrams debug logging

The AWC has built in CANopen logging feature, logging CAN telegrams to the CoDeSys log. It is enabled using the function :

```
FUNCTION IFM51_EnableDebugLog : BOOL
VAR_INPUT
usiNetID: USINT; // Which CAN line you want to filter on (Network ID)
usiSize : USINT; // How may telegrams you want to log before stopping
END_VAR
```

Example: The function must be called once, to setup and initiate the logging.

```
IFM51_EnableDebugLog(usiNetID:= 0, usiSize := 1000);
```

This logs 1000 telegrams from NetID 0, corresponding to Network ID under IFM5.1->CAN1:




Figure 3.33: CAN network id

Here after the function can be called again to perform another 1000 logs.




Figure 3.34: CAN telegrams logged to the CoDeSys log



It is only possible to log from one netID at a time.

3.8 Setting up OPC connection interface

3.8.1 Overview of concept




Figure 3.35: Concept overview

3.8.2 Example

Create a PLC project with variables to be exchanged via OPC




Figure 3.36: Project with variables for OPC exchange

Then on Application Add object→Symbol configuration




Figure 3.37: Add symbol configuration




Figure 3.38: Set symbol configuration name

Now select the Items for exchange:




Figure 3.39: Select items to exchange

Save project, Build, Download the project and run




Figure 3.40: Running project with OPC

Setting up the OPC server

Open 3S CoDeSys → CoDeSys OPC Server 3 → OPCConfiguration. Select New.




Figure 3.41: OPC configuration

Change Update Rate (ms) from 200 ms to eg. 1000 ms or 2000 ms, if many variables are to be exchanged via OPC.

Add a PLC




Figure 3.42: Append PLC

Use default settings:




Figure 3.43: Use default settings

Select Edit.




Figure 3.44: Edit settings

Use the CoDeSys PLC address from the Device Settings in CoDeSys¹

¹Please Note these settings are only valid if the AWC 500 is connected to the same subnet.




Figure 3.45: Set the PLC address




Figure 3.46: The project after configuration

IMPORTANT: Save the configuration to: C:\Program Files\3S CoDeSys\CoDeSys OPC Server 3\OPCServer.ini
 Additionally more PLCs can be added to the OPC server configuration.




Figure 3.47: More PLCs can be added to the OPC server configuration

Starting the OPC server

WinCoDeSysOPC /service




Figure 3.48: Starting the OPC server

Logs can be found in:

C:\Program Files\3S CoDeSys\CoDeSys OPC Server 3\OPCServer.txt




Figure 3.49: Log example

Testing the connection

Start the OPC test client:




Figure 3.50: TsOpc test client

Connect to CoDeSys.OPC.DA OPCServer →Connect




Figure 3.51: Connect to OPC Server

Right click Private Groups in right pane:




Figure 3.52: Right click Private Groups




Figure 3.53: Add group




Figure 3.54: Group added to Private Groups




Figure 3.55: Add all Items




Figure 3.56: Items

Right click each item to read or write E.g. rB_VAR_FROM_OPC




Figure 3.57: rB_VAR_FROM_OPC

Then the item becomes set in PLC:




Figure 3.58: The item becomes set in the PLC

Now set item bC_VAR_FROM_OPC 1




Figure 3.59: bC_VAR_FROM_OPC

and a read of rB_VAR_TO_OPC shows the value:




Figure 3.60: reading rB_VAR_TO_OPC

Stop/Uninstalling the OPC Server

With command

WinCoDeSysOPC /UnRegServer

all entries of the OPC Server will be removed from the registry.

3.9 Creating a MODBUS TCPIP slave interface

Here we show how to create a MODBUS TCP/IP Slave interface on the AWC 500 .

The steps are:

- Add the Ethernet device to the AWC 500 PCM 51 device
- Add the Modbus Slave Device
- Configure the Modbus slave variables for exchange with the Modbus master

3.9.1 Add the Ethernet device to the AWC 500 PCM 51 device ("→Add Device...")




Figure 3.61: Add device

Change vendor to 3S – Smart Software Solutions GmbH and select the Ethernet device:





Figure 3.62: Add ethernet device



Add the Modbus Slave (Add Device... → Modbus TCP Slave Device)




Figure 3.64: Add the Modbus Slave device

From the list select "MODBUS TCP Slave Device":




Figure 3.65: Select "MODBUS TCP Slave Device"

Configure the overall Response time and socket timeout (optional just leave default). The Unit Id is used to identify the AWC 500 as modbus slave, and shall be used in the configuration of the Modbus master:




Figure 3.66: Modbus TCP setup

The settings above create:

10 MODBUS Holding registers from offset 0, to be written with MODBUS Function 06 or 16. They can be read with Function 03 (4x).

10 MODBUS Input registers from offset 0. They can be read by MODBUS Function 04 (3x)

I/O Mapping:




Figure 3.67: I/O Mapping

Set "Always update variables" if the input variable is not actually used in the program. Specify Bus cycle task to control what task, should be responsible to execute the MODBUS slave.

Use a modbus master to test the interface e.g. Modbus Poll:




Figure 3.68: Modbus Poll for testing modbus interface

The used configurations in Modbus poll are shown here:




Figure 3.69: Modbus poll configuration

3.9.2 Extending the number of registers

By default the Modbus Slave is limited to max 40. To extend the registers edit the device description file:
 c:\ProgramData\CoDeSys\Devices\115\0000_0002\3.4.3.0\device.xml

Locate:

```
<RangeType basetype="std:USINT" name="AssemblySizeRangeType">
  <!-- Number IO-Parameters (WORD) -->
  <Min>2</Min>
  <Max>40</Max> Change to e.g. 500.
  <Default>10</Default>
</RangeType>
```

There is a known bug that is limiting the number of registers to 1000.

3.9.3 Diagnostics

The state of the modbus slave can be monitored by accessing the IEC Objects in the PLC program. In each cycle the server is executed once. In case of a socket error the reset flag is set, normal request processing then should continue in the next cycle:

```
m_ModbusServer(); // execute request processing
IF (m_ModbusServer.xError) THEN // any errors?
  m_ModbusServer.xReset := TRUE; // set reset flag
  IoDrvStartBusCycle := Errors.ERR SOCK_NOTCONNECTED;
ELSE
  IoDrvStartBusCycle := Errors.ERR_OK;
END_IF
```

3.9.4 Demo

See further the demo project "TCP_IP Modbus master loopback.project"

3.9.5 Troubleshooting

If you are unable to connect from the Master to the Modbus slave, try ping the AWC 500 .

3.10 Setting up a MODBUS TCP/IP master

To create a MODBUS TCP/IP master the steps are :

- Add the Ethernet device to the AWC 500 PCM 51 device
- Add the Modbus master
- Add the Modbus slave to the master
- Configure the Modbus slave variables for exchange with AWC 500

3.10.1 Add the Ethernet device to the AWC 500 PCM 51 device ("→Add Device...")




Figure 3.70: Add device

Change vendor to 3S – Smart Software Solutions GmbH and select the Ethernet device:




Figure 3.71: Add ethernet device

3.10.2 Add the Modbus master (Add Device... → Modbus TCP Master)




Figure 3.72: Add the Modbus master

From the list select "MODBUS TCP Master":




Figure 3.73: Select "MODBUS TCP Master"

Configure the overall Response time and socket timeout (optional just leave default):




Figure 3.74: Configure the overall Response time

3.10.3 Add the Modbus TCP slave(Add Device... →Modbus TCP slave)




Figure 3.75: Add the Modbus TCP slave

Select the Modbus TCP Slave from the list and "Add Device":




Figure 3.76: Select the Modbus TCP Slave

3.10.4 Configure the Modbus slave variables for exchange with AWC 500

Slave : First specify the IP address of the Modbus slave (here the local IP address is shown) and unit id:




Figure 3.77: Specify the IP address of the Modbus slave

Channel: On the Modbus Slave Channel page a list of modbus function calls (channels) are added to do the exchange of variables:




Figure 3.78: Modbus slave channels

Add a channel by selecting "Add Channel...", these settings shall match the provided modbus features of the Modbus slave eg. here are 10 variables written from the AWC 500 to 10 holding registers in the modbus slave:




Figure 3.79: Configure Modbus channels

Changing the trigger from Cyclic to RISING_EDGE, creates a boolean variable that can be toggled from the program to control exchange of variables.

Here after the channel is added to the list:




Figure 3.80: Channel added to the list

Add additional channels to eg read input registers or holding registers from the Modbus slave (eg. here are 10 (length) registers read, starting by offset 0x0000:




Figure 3.81: Configure Modbus channels

Same way the function is added to the list:




Figure 3.82: Channel added to the list

Init: Here modbus functions can be added to the list, to set registers in the Modbus slave on power up. Add them to the list using "New..." if required.




Figure 3.83: Modbus TCP Slave init tab

I/O Mapping: Here the PLC variables for exchange can be linked to the modbus function(channel):




Figure 3.84: Linking PLC Variables to the modbus function

3.10.5 Diagnostics

The state of the modbus master and each slave can be monitored by accessing the IEC Objects in the PLC program.

VAR

```
MasterError : BOOL;
MasterErrorOnSlave : BOOL;
```

END_VAR;

```
MasterError := Modbus_TCP_Master_Instance.xSlaveError; (*TRUE if error on the modbus master*)
MasterErrorOnSlave := Modbus_TCP_Slave_Instance.xError; (*TRUE if error on the particular slave*)
```

3.10.6 Demo

See further the demo project \TCPIP MODBUS Master\TCP_IP_Modbus_master_loopback.project




Figure 3.85: Modbus master demo

3.10.7 Troubleshooting

Make sure the IP address range of the Modbus slave fits the address range of the AWC 500 . To check you can use ping [slaveip] via SSH connection to test.

3.11.1 Testing the NTP Client from the command line

To update the system time from the command line type:


```
ntpd -d -n -q -p 192.168.1.122
```

(quits after first successful time update)

```
ntpd -d -n -p 192.168.1.122
```

(continues time update)

The command line options present a verbose debug output of the communication with the NTP server.



```

192.168.1.13 - PuTTY
Fri Feb 10 17:30:00 UTC 2012
~ # hwclock -w
~ # date
Fri Feb 10 17:30:29 UTC 2012
~ # ntpd -d -n -q -p 192.168.1.122
ntpd: sent query to 192.168.1.122
ntpd: reply from 192.168.1.122: reach 0x01 offset -11716.697021 delay 0.003906 s
tatus 0x24 strat 1 refid 0x4c4f4341 rootdelay 0.030411
ntpd: sent query to 192.168.1.122
ntpd: reply from 192.168.1.122: reach 0x03 offset -11716.694802 delay 0.003906 s
tatus 0x24 strat 1 refid 0x4c4f4341 rootdelay 0.030411
ntpd: sent query to 192.168.1.122
ntpd: reply from 192.168.1.122: reach 0x07 offset -11716.696452 delay 0.004931 s
tatus 0x24 strat 1 refid 0x4c4f4341 rootdelay 0.030411
ntpd: sent query to 192.168.1.122
ntpd: reply from 192.168.1.122: reach 0x0f offset -11716.691647 delay 0.013135 s
tatus 0x24 strat 1 refid 0x4c4f4341 rootdelay 0.030411
ntpd: sent query to 192.168.1.122
ntpd: reply from 192.168.1.122: reach 0x1f offset -11716.698415 delay 0.003906 s
tatus 0x24 strat 1 refid 0x4c4f4341 rootdelay 0.030411
ntpd: setting clock to Fri Feb 10 14:15:53 UTC 2012 (offset -11716.695613s)
~ # date
Fri Feb 10 14:16:00 UTC 2012
~ #

```

Figure 3.88: Output from ntpd

To verify that the system time has been updated the date command can be invoked before and after running the ntp client. The above screen shot show how the system time is changed from 17:30 to 14:16 utilising the NTP client.

A typical test could look like this:

1. Set system time(to an incorrect time) using the date command(date [yyyymmddHHMM]):

```
date 201202101730
```

2. See the current system time :

```
date
```

3. Call NTP Client:

```
ntpd -d -n -q -p 192.168.1.122
```

4. Call date to see that the system time has been reset to the correct time.

```
date
```

In case the system time has not been set correctly repeat step 3 and 4.

Another test is to change the system time on the NTP server if possible and the repeat step 2, 3, and 4 to verify that the AWC 500 system time is set accordingly to the NTP server time.

3.11.2 Test NTP server setup (NetTime)

Download the open source NTP server NetTime from Sourceforge
<http://sourceforge.net/projects/nettime/files/latest/download>

Install the NTP server using the default options in the install wizard.

The server is now running as a service.

3.11.3 Configuring NetTime

NetTime will by default run as an NTP client and synchronize the host system time with a public NTP server.

To enable the NetTime server, right-click the NetTime tray icon and select Properties.




Figure 3.89: Properties for the NetTime server

In the Network Time GUI, see Figure 3.90, click Settings. . .




Figure 3.90: Network Time GUI

By Default the checkboxes allow other computers to sync to this computer and always provide times are unchecked.




Figure 3.91: NetTime Options

Check Both Allow other computers to sync to this computer and always provide time to enable the NTP server. When checking Always provides time the following warning is presented:




Figure 3.92: Warning dialog

Click No, in the Warning dialog which means you are ignoring the risk posed by enabling this option.

Finally the NetTime Options should be as follows.




Figure 3.93: Correct set NetTime Options

Click Ok, and the NetTime server is ready to user. In case of connection problems try disabling the host machines firewall.

Then changing the PC time in Windows manually effects the time set on the AWC 500 .

The UTC time is always transferred between the NTP server and NTP client, and time is presented with the local time offsets on PC and AWC 500 .

AWC 500 (NTP Client)				Server (NTP Server)
		0) Current time Client != Server		Time Zone setting is Beijing...
03:55:21 (UTC)				12:00:00(UTC+8)
		1) Request time →		
	04:00:01(UTC)	← 2) Response	04:00:01(UTC)	12:00:01
04:00:01 (UTC) 04:00:01 (CoDeSys RTC time)	TZ=UTC	3a) New time set in AWC 500		
12:00:01(Local) 04:00:01 (CoDeSys RTC time)	TZ=Local-8	3b) New time set in AWC 500 Client == Server		

The AWC 500 only operates with UTC time. Full Linux Time zones support is not implemented. It is a design decision by the DEIF AWC 500 team, that all presentation of the time to the user should be offset from UTC to local time.

This is to avoid confusion of what time is used in logged files.

**The correct localtime when viewing with "date" can still be set up.
And localtime also needs to be handled in the PLC application.**

Correct localtime when viewing with "date" can still be set up.

In /etc/profile set the Time zone variable, by adding the lines:

```
TZ=CST-8                (CST (China Standard Time) -8 hours offset)
export TZ
```

```

/etc/profile - root@192.168.1.113
# /etc/profile: system-wide .profile file for the Bourne shell (sh(1))
# and Bourne compatible shells (bash(1), ksh(1), ash(1), ...).

PATH="/usr/local/bin:/usr/bin:/bin:/usr/local/sbin:/usr/sbin:/sbin"
EDITOR="/bin/vi"          # Needed for packages like cron
test -z "$TERM" && TERM="vt100"  # Basic terminal capab. For screen etc.

if [ ! -e /etc/localtime ]; then
    TZ="UTC"              # Time Zone. Look at http://theory.uwinnipeg.ca/gnu/glibc/libc_303.html
                        # for an explanation of how to set this to your local timezone.
    export TZ
fi

TZ=CST-8
export TZ

if [ -d /etc/profile.d ]; then
    for i in /etc/profile.d/*.sh; do
        if [ -r $i ]; then
            . $i
        fi
    done
    unset i
fi

export PATH EDITOR TERM

umask 022

Line: 15/28      Column: 19

```

Figure 3.94: Edit profile

To see the effect:

```

~ # date
Mon Feb 20 20:22:04 CST 2012    (Now the China Standard Time (CST) is used)
~ #
~ # unset TZ                    ( unsets timezone )
~ # date
Mon Feb 20 12:22:15 UTC 2012   ( now showing the UTC time again).

```

A reboot will use CST again.

Localtime handling in the PLC application

In PLC application we only want the HMI visualization time to show the local time. All logging should still use the UTC time.

A suggestion for handling is simple offset of the UTC time:

VAR

```

UTCTime_ms : SysTime;
LocalTime_ms : SysTime;
LocalTime_sys: SYSTIMEDATE;

```

END_VAR

```

(* Return the UTC time *)
SysTimeRtcHighResGet(pTimestamp := UTCTime_ms);
(* Offsets the UTC time with 8 hours *)
LocalTime_ms := UTCTime_ms + (8*60*60*1000);
SysTimeRtcConvertHighResToDate(pTimestamp := LocalTime_ms, pDate := LocalTime_sys);

```

The Time synchronization is floating and takes place up to ever 3rd hour automatically, a scheduled function can be made like a script instead.

4 Adding Multilanguage support to visualisations

Make sure to use the font Arial Unicode Ms. in Windows it needs to be enabled in the fonts configuration before it is possible to select in CoDeSys.
 Each time a text is added in CoDeSys, it is added to the GlobalTextList, together with a unique ID.




Figure 4.1: Texts are added to the GlobalTextList

In GlobalTextList additional languages can be added different from the design language (default)




Figure 4.2: Add Language




Figure 4.3: Choose Language

Unused Static texts can be removed by:




Figure 4.4: Remove Unused Text List Records

Insert boxes to change language:




Figure 4.5: Boxes to change language

Add the "Change the language":




Figure 4.6: Boxes to change language

Write "default" for designer language.




Figure 4.7: Write "default" for designer language

Or select any of the added languages:




Figure 4.8: Available languages




Figure 4.9: GlobalTextList




Figure 4.10: Chinese language example

4.1 Set Chinese as default startup language

Set up Chinese as default startup language in webvisualization(Fixed by CoDeSys 3.4.4.60)

The default startup language by the webvisualization can be changed from "default" to "Chinese" by setting `StartupLanguage = Chinese` (in `/app/service/codesys/CoDeSysControl.cfg`)




Figure 4.11: Edit CoDeSysControl.cfg

Note: In CoDeSys the default language is still used when opened. DEIF provides an dUpdate script changing this StartupLanguage.

All fonts on items has been changed to Arial Unicode MS on aSYSTEMOVERVIEW page.




Figure 4.12: Change font to Arial Unicode MS

Tip : Use the "Visualization→Visual Elements List Editor" to walkthrough all text elements.

The screenshot shows the 'Visual Elements List Editor' window with a table listing visual elements. The table has columns for Type, X, Y, Width, Height, Id, and Name.

Type	X	Y	Width	Height	Id	Name
#0 Rectangle	0	9	801	540	0	GenElemInst_0
#1 Rectangle	0	60	800	0	1	GenElemInst_1
#2 Rectangle	460	150	70	20	2	GenElemInst_2
#3 Rectangle	460	210	70	20	3	GenElemInst_3
#4 Rectangle	530	150	80	20	4	GenElemInst_4
#5 Rectangle	530	190	80	20	5	GenElemInst_5

Figure 4.13: Visual Elements List Editor

4.2 Webvisualisation or Panel PC HMI preparations

For webvisualisation or the Panel PC need to have java installed:

- Online via internet (via www.java.com/getjava)
- Or Offline installation (jre-6u26-windows-i586-s.exe) via USB stick: (<http://www.java.com/en/download/manual.jsp>)
 - Select Windows 7,XP Offline.
 - Then save the file to USB stick

One installed test the visualization with

http://[ip]:8080/webvisu.htm to view the visualisation

Make this webpage the default startup page of explorer.

4.2.1 How to remove scrollbars

As per default the Internet Explorer shows scrollbars. We propose that the generated webvisu.htm is changed manually after generating a boot project in offline mode. Then the changes below to webvisu.htm can be made. Edit /app/service/codesys/visu/webvisu.htm on the AWC 500 .

```

<HTML>
  <HEAD>
    <TITLE>CoDeSys WebVisualization</TITLE>
    <style type="text/css">
      body
      {
        margin: 0;
        padding: 0;
        overflow:hidden; <-Add this
      }
    </style>
  </HEAD>
  <BODY scroll="no" style="overflow:auto" > <-Add this
    <APPLET CODEBASE=. CODE=_3S/CoDeSys/WebVisu/WebVisu.class name="WebVisu"
      width="800" height="600" id="webvisuappletV3">
    <param name="archive" value="webvisuclient.jar , visualelements.jar">
    <param name="STARTVISU" value="aSYSTEMOVERVIEW">
    <param name="APPLICATION" value="Application">
    <param name="PLCADDRESS" value="000D">
    <param name="USELOCALHOST" value="TRUE">
    <param name="UPDATERATE" value="200">
    <param name="COMMBUFFERSIZE" value="1000000">
    <param name="BESTFIT" value="False">
    <param name="WEBVISUTYPE" value="Client">
    <param name="ANTIALIASING" value="0">

    </APPLET>
  </BODY>
</HTML>

```

5 Using boot application dUpdate builder


To make it easy to create a CoDeSys boot application package, the boot application .dUpdate builder is used. Then to do remote update of a project simply update copy the file application.dupate to /tmp/fwupdates on the AWC 500.

The steps are:


1. Delete existing CoDeSys boot application files.
2. Create new CoDeSys bootproject in offline mode.
3. Run build_dupdate.py script from CoDeSys.
4. Test the build of application.dupdate before distribution.

5.1 Step 1: Delete existing CoDeSys boot application files


1. Delete existing CoDeSys boot application files from \boot_application\application:




2. Delete existing CoDeSys boot application visu files from \boot_application\application\visu:




3. Then the folders should be empty.




5.2 Step 2: Create new boot application from CoDeSys in offline mode (Online→Create boot application)




Save the files to the location `\boot_application\application` using default names:




Then the boot application files are created:




Option: If you want make a customized version of the webvisualisation, then copy the file webvisu.htm from `\\boot_application\wwwroot` to above path `\\boot_application`.




Edit the webvisu.htm if required.




5.3 Step 3) Run build_dupdate.py script from CoDeSys (Tools→Scripting→ExecuteScript File...)




Select build_dupdate.py



The output message:




Here after the build application.dupdate file is available in \boot_application:




5.4 Step 4) Test the build of application.dupdate before distribution.

To update the application on the AWC 500 copy application.dupdate to /tmp/fwupdate




The uses the same procedure like updating firmware on the AWC 500:


After successful update the file Update_success is available:




The application.dupdate unpacks it self to /app:



and to /visu:



Details about the update can be found in /app/log/syslog:



```
/app/log/syslog - root@192.168.20.13
Dec 6 12:18:36 dupdate: Tar extracted, Running ./run_update.sh in /tmp/dupdate-uciBUX/
Dec 6 12:18:36 ./run_update.sh: Dupdate: run_update
Dec 6 12:18:36 ./run_update.sh: Check sum: on files listed in sha256sum.txt
Dec 6 12:18:37 ./run_update.sh: run_update.sh: OK
Dec 6 12:18:37 ./run_update.sh: application/Application.app: OK
Dec 6 12:18:37 ./run_update.sh: application/Application.crc: OK
Dec 6 12:18:37 ./run_update.sh: application/visu/Application.ImagePoolCollection.csv: OK
Dec 6 12:18:37 ./run_update.sh: application/visu/Application.PLC_VISU.cwv: OK
Dec 6 12:18:37 ./run_update.sh: application/visu/Application.PLC_VISU.vars.cwv: OK
Dec 6 12:18:37 ./run_update.sh: application/visu/Application.webvisu.cwv: OK
Dec 6 12:18:37 ./run_update.sh: application/visu/GlobalTextList.txt: OK
Dec 6 12:18:37 ./run_update.sh: application/visu/VisualElements.jar: OK
Dec 6 12:18:37 ./run_update.sh: application/visu/webvisu.htm: OK
Dec 6 12:18:37 ./run_update.sh: application/visu/webvisuclient.jar: OK
Dec 6 12:18:37 ./run_update.sh: Check sum: OK
Dec 6 12:18:37 ./run_update.sh: Stop already running service
Dec 6 12:18:37 root: Finish codesyscontrol
Dec 6 12:18:37 kernel: [ 1342.346269] EtherCAT: Master driver devel unknown
Dec 6 12:18:37 kernel: [ 1342.357234] EtherCAT: 1 master waiting for devices.
Dec 6 12:18:37 kernel: [ 1342.399448] ec_generic: EtherCAT master generic Ethernet device module devel u
Dec 6 12:18:37 kernel: [ 1342.399514] EtherCAT: Accepting device 02:83:13:00:0A:01 for master 0.
Dec 6 12:18:37 kernel: [ 1342.399571] ec_generic: Binding socket to interface 2 (eth0).
Dec 6 12:18:37 kernel: [ 1342.416864] EtherCAT 0: Starting EtherCAT-IDLE thread.
Dec 6 12:18:37 kernel: [ 1342.417078] EtherCAT 0: Link state changed to UP.
Dec 6 12:18:37 kernel: [ 1342.423616] EtherCAT 0: 4 slave(s) responding.
Dec 6 12:18:37 kernel: [ 1342.423642] EtherCAT 0: Slave states: INIT, PREOP.
Dec 6 12:18:37 kernel: [ 1342.424059] EtherCAT 0: Scanning bus.
Dec 6 12:18:39 kernel: [ 1344.070600] EtherCAT 0: Bus scanning completed in 1648 ms.
Dec 6 12:18:39 kernel: [ 1344.107282] EtherCAT 0: Slave states: PREOP.
Dec 6 12:18:40 ./run_update.sh: Do the update.
Dec 6 12:18:41 ./run_update.sh: Start the runtime.
Dec 6 12:18:41 ./run_update.sh: Update success
Dec 6 12:18:41 root: Run codesyscontrol
Dec 6 12:18:41 kernel: [ 1346.082314] EtherCAT 0: Master thread exited.
Line: 964/967 Column: 2347
```

6 Using DEIF VisuLoader

6.1 Purpose of the VisuLoader

The DEIF VisuLoader application is an alternative to using a web browser to display the CoDeSys Web Visualization. It has two main purposes:

1. Enabling auto-reconnecting (in many cases) to the controller in case of connection loss due to either power reset of the AWC 500 or disconnection of the Ethernet.

6.2 Installing the VisuLoader

6.2.1 Java installation

If not already installed, install Java 7+ JRE on all panel PCs

6.2.2 Copy files

- Copy VisuLoader.jar to panel PCs C:\visu\
 - Copy runVisuTower.bat to tower panel PC Windows startup folder
 - Copy runVisuNacelle.bat to nacelle panel PC desktop

6.2.3 Edit files

- Edit runVisuTower.bat and change:
 - Controller IP address: e.g. IP=192.168.20.13
 - PLC address (hex): e.g. PLCADDRESS=000D
 - Visualization start page: e.g. STARTVISU=aSYSTEMOVERVIEW
- Edit runVisuNacelle.bat and change:
 - Tower panel PC IP address: e.g. towerip=192.168.20.14
 - Controller IP address: e.g. IP=192.168.20.13
 - PLC address (hex): e.g. PLCADDRESS=000D
 - Visualization start page: e.g. STARTVISU=aSYSTEMOVERVIEW

6.2.4 Configuring

Tower panel PC or single panel setup

It is recommended that the tower panel PC will have the runVisuTower.bat file located in both the windows startup folder (for automatic startup on panel PC power on) as well as on the desktop for easy manual startup.

Nacelle panel PC

This panel PC should have the runVisuNacelle.bat located only on the desktop for manual starting, since the visualization should only be active when servicing the Nacelle and people are physically present.

6.3 VisuLoader features

6.3.1 Automatic reconnection

The VisuLoader will try to reestablish the connection to the PCM5-1 in case of connection issues. In some special cases, reestablishing the connection is not possible and the VisuLoader will need to be manually restarted. These cases include if connection is lost during the initialization phase.

6.3.2 Tower Panel Lockout

In case the VisuLoader is opened on the Nacelle panel PC (if exists), the Visualization on the Tower Panel PC will be locked from interference by any user. This situation continues until the VisuLoader is closed on the Nacelle Panel PC.

6.4 Using the VisuLoader

6.4.1 Running the VisuLoader

On the Tower Panel PC the VisuLoader will automatically open when the panel PC is turned on.

On the Nacelle Panel PC the VisuLoader should be manually started by double clicking the "runVisNacelle.bat" on the desktop.

If needed the VisuLoader can be manually restarted by closing it using the button in the upper right corner and then started again by double clicking the "runVisu. . . bat" located on the desktop or in the windows startup folder.

6.4.2 General info

Note that it is not possible to do any action on the Tower Panel PC (including exiting the VisuLoader) as long as the VisuLoader is active in the Nacelle Panel PC.

DEIF A/S reserves the right to change any of the above.

DEVELOPMENT