



-power in control



## DELOMATIC 400 GAS CHP Controller OPERATOR'S MANUAL



### Delomatic 400 Gas (DM 400 Gas) Software 436729\_008

- Functional Overview
- HMI Browser
- User Interface
- Status, Alarms and Messages



DEIF A/S · Frisenborgvej 33 · DK-7800 Skive  
Tel.: +45 9614 9614 · Fax: +45 9614 9615  
info@deif.com · www.deif.com

Document no: 4189340875B  
SW version: 436729\_008 or earlier

## Table of contents

<b>1. ABOUT THIS DOCUMENT .....</b>	<b>4</b>
GENERAL PURPOSE.....	4
INTENDED USERS .....	4
CONTENTS/OVERALL STRUCTURE .....	4
<b>2. WARNINGS AND LEGAL INFORMATION .....</b>	<b>5</b>
LEGAL INFORMATION AND RESPONSIBILITY .....	5
ELECTROSTATIC DISCHARGE AWARENESS.....	5
SAFETY ISSUES.....	5
DEFINITIONS .....	5
<b>3. GENERAL OVERVIEW .....</b>	<b>6</b>
<b>4. FUNCTIONAL OVERVIEW.....</b>	<b>7</b>
MEASUREMENTS .....	7
PROTECTION FUNCTIONS.....	8
CONTROL FUNCTIONS.....	9
<b>5. HMI BROWSER .....</b>	<b>10</b>
FIRST STEPS .....	10
SETUP .....	11
CONNECTION TO DM 400 .....	11
SET DATE AND TIME.....	12
<b>6. USER INTERFACE.....</b>	<b>13</b>
OVERVIEW PAGE.....	14
PARAMETER EDITOR.....	18
COUNTER, SERVICE PAGE.....	19
ANALYSIS COUNTER PAGE .....	20
LOG IN PAGE .....	21
NAVIGATOR PAGE.....	21
TRENDING .....	23
TRENDING – MEASURING POINTS ON THE DISPLAY .....	24
TRENDING – SAVING OF DATA .....	24
CURVE SELECTION .....	24
LOG BOOKS .....	26
SYSTEM DIAGNOSTICS PAGES.....	31
ELECTRICAL VALUES – POINTER INSTRUMENTS .....	36
ELECTRICAL VALUES – DIAGNOSTICS VALUES .....	37
ELECTRICAL VALUES – GENERATOR PROTECTION .....	38
ELECTRICAL VALUES – MAINS (GRID) PROTECTION .....	39
GENERATOR TEMPERATURES .....	40
GENERATOR TEMPERATURE PROTECTION .....	41
ACTIVE ALARMS .....	42
EMISSION CONTROL .....	43
ENGINE VALUES .....	48
IGNITION CONTROL .....	53
KNOCKING CONTROL .....	57
ROOM AIR VENTILATION .....	59
TEST OF AUXILIARIES .....	62
LUBE OIL SYSTEM.....	63
HEATING SYSTEM.....	66
GAS/EXHAUST SYSTEM.....	70
PARAMETERS.....	74

---

DEFINE PASSWORD/PARAMETERS EDITOR .....	75
PROJECT PARAMETERS .....	77
<b>7. STATUSES AND MESSAGES .....</b>	<b>78</b>
ERROR MESSAGES .....	78
PRIMARY STATUSES .....	79
SUB-CONDITIONS .....	81
OPERATING LEVELS .....	82
INPUTS AND OUTPUTS.....	83

**This document relates to Delomatic 400 software version 436729\_008 or earlier.**

## 1. About this document

---

### General purpose

This document is the operator's manual for DEIF's Delomatic 400, DM 400 Gas Combined Heat and Power (CHP) plant controller.

The general purpose is to give the user important information on how to carry out the daily operation of the unit.



**Please make sure that this document is read in full before working with the DM 400 Gas controller and the other associated system hardware. Failure to do so may result in injury or danger of death and/or damage to system hardware**

### Intended users

This operator's manual is mainly intended for the daily user. This document will provide the operator with information regarding the functions of the DM 400 that will enable the operator to control and monitor those aspects of the CHP system which the DM 400 controls and monitors.

### Contents/overall structure

The document is divided into chapters, and in order to make the structure simple and easy to use, each chapter will begin from the top of a new page.



**Note that the software pages automatically update based on the parameter options which are activated for each individual system.**

**Consequently, the diagrams shown are for illustration purposes and the actual diagram displayed may differ as they will be system specific.**

**THIS IS NOT A FAULT.**

## 2. Warnings and legal information

### Legal information and responsibility

DEIF takes no responsibility for installation or operation of the generator set or any other hardware associated with the system. If there is any doubt about how to install or operate the any hardware controlled by the DM 400, the company responsible for the installation or the operation of this equipment must be contacted.

**In order to obtain safe and trouble-free use of the DM 400 Gas, it is important that transport, storage, mounting and commissioning is done by authorised personnel and according to DEIF instructions.**  
**Failure to comply will result in a loss of warranty and possible damage to the equipment.**

### Electrostatic discharge awareness

Sufficient care must be taken to protect the terminals against static discharges during the installation. Once the unit is installed and connected correctly, these precautions are no longer necessary.

### Safety issues

Installing the unit requires work with dangerous currents and voltages. Therefore, the installation should only be carried out by authorised personnel who are appropriately qualified to do so.



**Be aware of the hazardous live currents and voltages. Do not touch any AC measurement inputs as this could lead to injury or death.**



**If the Remote Start function is activated within the DM 400 controller, then additional safety measures must be taken to prevent the remote start function from operating whilst personnel are working on the plant. Failure to do so may result in the engine starting or attempting to start without warning and may cause injury, death and/or damage to equipment as a consequence.**

### Definitions

Throughout this document, a number of notes and warnings will be presented. To ensure that these are noticed, they will be highlighted in order to separate them from the general text.

### Notes



**The notes provide general information which will be helpful for the reader to bear in mind.**

### Warnings




**The warnings indicate a potentially dangerous situation which could result in death, personal injury or damaged equipment, if certain guidelines are not followed.**

### 3. General overview

As a minimum, the DM 400 Gas system consists of a double-height (6 HE, 266 mm height) 19" rack mounted with the necessary I/O modules and a 12"-colour graphic touch screen operator interface (HMI).

The DM 400 Gas has a TCP/IP interface with a built-in webserver. This means that the graphical display screens are stored here and can be accessed from any computer via the internet, using a free of charge DEIF HMI Client software and thereby enabling remote control and monitoring from anywhere in the world.

Example of a possible system configuration:



Typically, only the HMI and DM 400 controller are within DEIF's scope of supply. The other components are shown for illustration purposes only.



The DM 400 controller is an extremely versatile unit and can be used in various system configurations. As a result of this, the terms **GRID**, **MAINS** and **BUSBAR** are used throughout this document and on the HMI and should be taken to be the primary incoming electrical supply to which the system being controlled by the DM 400 will synchronise, connect and operate in parallel.

If the system is used for an island-only application, then all references to the primary incoming electrical supply should be ignored

---

## 4. Functional overview

---

The **Delomatic DM 400 Gas control system** is designed for the control of a CHP plant driven by a gas engine.

The following functions are supported:

- Full engine control and monitoring (including associated external components for example ignition system, anti-knock system, subject to the functionality of this equipment)
- Full generator control monitoring and protections
- Synchronisation and breaker control
- Heating and cooling circuit control and monitoring
- Gas supply monitoring and adaptive control
- Overall system optimisation
- Data monitoring and recording

The integrated **visualisation software** enables simple operation of the complete system either via the HMI interface on site or via remote operation.

For remote operation purposes, a connection to the DM 400 can be established via RS-485 interface or network connection (TCP/IP).

The HMI interface provides

- Graphical representation of system values and status
- Real time trend curves of data
- Log books
- Recording of Run Hours, Power Generated (kWh), Maintenance counters plus the facility to configure additional counters

All of these functions are powerful tools available to the operator in order to

- provide a quick overview of the status of the plant
- enable adjustment of system parameters and set points
- assist in the quick identification of problems
- provide an indication of maintenance requirements
- help to identify where process or efficiency improvements can be made via system specific configurable parameters.

Access to these password-protected configurable parameters enables a simple adaptation of the controller to optimise the operation of the plant.

The DM 400 controller is a powerful and flexible device that is able to provide an extensive range of measurement, protection and control functions that include, but are not limited to:

### Measurements

#### Engine

- Temperatures
  - Cooling water
  - Cylinders
  - Exhaust
  - Intercooler
  - Receiver/Mixture
  - Oil
- Pressures
  - Receiver/Mixture

- Oil
  - Exhaust
- Lambda voltage (if lambda sensor is fitted)

**Generator**

- Generator-side voltages, 3-phase L1, L2, L3, N, measured directly up to 690 V<sub>rms</sub> rated voltage
- Grid-side voltages, 3-phase L1, L2, L3, N, measured directly up to 690 V<sub>rms</sub> rated voltage
- Currents L1, L2, L3 through current converters to 1 A or 5 A
- Active power per phase and total
- Reactive power per phase and total
- Four-quadrant counter for active power consumed/generated and reactive power consumed/generated
- Winding and bearing temperatures of the generator

**Heating and Cooling**

- Temperatures of the water circuits
- Water flow indicators

**Gas**

- Gas pressure and flow rate
- CH4 value

**Miscellaneous**

- Operating hours
- Circuit breaker switching operations
- Room temperature
- Pulse counter, configurable
- Additional plant measurements

**Protection functions****Engine**

- Over-temperature protection for all temperature inputs
- Over-/under-pressure protection for all pressure inputs
- Measurements of parameter values
- Recording and logging of measured values and conditions
- Overspeed
- Water flow
- Backfire indicator

**Generator**

- Grid protection (<U, >U, <f, >f, delayed over-voltage, under-voltage characteristic) according to BDEW/VEO guidelines
- Electrical safety functions for generator over-voltage and under-voltage, over-frequency and under-frequency, asymmetric current, overload, feedback, minimum load, over-current, thermal over-current, over-excitation, loss of excitation, vector jump, df/dt
- Grid protection/mains failure protection
- Generator protection
- Synchronisation

**Heating and cooling**

- Water level and flow rate monitor for cooling and heating circuit

**Maintenance counters**

- A number of operational and service counters are provided to assist efficient operation of the system.

**Gas**

- Integration with gas valve proving mechanism
- Integration with gas leak detection mechanism

**Miscellaneous**

- Support of a hardware safety chain with reset function according to VDE0116
- Wire break-proof monitoring of the circuit breaker position(s)
- Digital error messages from engine circuit breakers and automatic circuit breakers
- Emergency stop
- Integration with fire detection system
- Configurable inputs to enable protection of various functions with configurable message texts and fail classes
- Monitoring of external devices
- Fill level monitoring in external lubricating oil tanks (fresh oil min, used oil max.)
- Cylinder temperature monitoring

**Control functions****Engine**

- Fully automatic engine start/stop
- Regulation of the gas mixer
- Control of engine throttle for speed regulation with speed ramp on start-up
- Exhaust gas bypass control
- Optional control of (subject to capability of the external equipment)
  - Ignition system
  - Anti-knocking systems
- Engine after-run
- Power reduction function according to oil temperature, water temperature and exhaust temperatures
- Regulation of the mixture temperature through adjustment of a three-way valve and fan controller

**Generator**

- Synchronisation with voltage adaptation and time monitoring
- Power ramp function for gentle increase/decrease of power
- Power regulation
- Cos phi (Power Factor) regulation
- Automatic power reduction, based on various input conditions

**Heating and Cooling**

- Regulation of a hot water valve
- Emergency cooling circuit regulation with three-way valve and fan controller
- Heat circuit pump, engine cooling circuit pump and mixture cooling circuit pump operation
- Engine preheating

**Gas**

- Adjusting of mixer position, power adjustment as well as selection and de-selection according to CH<sub>4</sub> value, gas level, gas pressure or grid supply
- Gas compressor

**Miscellaneous**

- Auxiliary unit start-up and after-run
- Regulation of the enclosure temperature
- Interval refilling of lubricating oil, optional

## 5. HMI browser

The DM 400 system has a unique user interface which enables the use of any standard Windows PC for the operation of the plant.

The DEIF HMI browser software driver is free to download from the DEIF website on [www.deif.com](http://www.deif.com).

The installation and use of the HMI browser are described in a separate document, **Delomatic 400 Gas and Hydro application notes for the HMI Browser**, the latest version of which can be downloaded from the DEIF website on [www.deif.com](http://www.deif.com).

If multiple operators are online simultaneously, they all see the same user interface at their own computer.



If the Remote Start function is activated within the DM 400 controller then additional safety measures must be taken to prevent the remote start function from operating whilst personnel are working on the plant. Failure to do so may result in the engine starting or attempting to start without warning and may cause injury, death and/or damage to equipment as a consequence. It is recommended that a means, by which the remote start-up can be blocked, for example using a manual isolator, is implemented. This will enable remote access for diagnosis and visualisation purposes but prevents remote starting of the system when personnel are working on the equipment.

Once the HMI browser software has been loaded onto the HMI, this should be opened whilst the HMI interface has a connection to the DM 400 controller.

### First steps


The HMI browser is started up by double-clicking the desktop icon.



**HMI-Client.Ink**

Start-up window of the HMI browser will open.

Start-up window of the HMI browser:



## Setup

The start-up window appears and before proceeding, it is recommended to set up the HMI display parameters.

Using the **"File"** menu option

1

It is possible to set the desired values for the HMI screen saver action time with the following options:

- Off
- 5 min
- 15 min – Recommended selection
- 30 min

The second option from the **"File"** menu is "Update Speed". It is possible to set the desired values for the HMI update speed with the following options:

- Normal
- Fast – Recommended selection

The final option in the **"File"** menu is **"Exit"**. This terminates the connection to the DM 400 and closes the HMI browser.

## Connection to DM 400

The DM 400 can be connected using the TCP/IP option ONLY.

By pressing the corresponding "Connect to server" button, the operating window of the browser is shown. The user is then prompted to select the operating language for the system. Once this has been selected, the overview page appears as shown on the following page.

## Set date and time

The date and time of the controller are set using the corresponding button of the HMI browser (in the start-up window) and has effect as soon as a connection has been established.


The system time should not be switched for daylight saving time, because the entries in the log are recorded based on time.

The transfer of the log books is based on a time comparison which only requests entries which are newer than the already queried entries.

The mechanism has the effect of only transmitting the entries which have not been saved on the PC yet.

Caution! Resetting the time can result in the loss of entries.

## DM 400 overview page



Show or hide window frame

By clicking the bottom right corner of the operating window, the window frame is shown or hidden. When the window frame is switched off, the height of the window is adapted to the currently adjusted width so that the correct height/width ratio is provided.


## 6. User interface

---

The overview pages provide a quick glance at the current status of the plant.

Along with the function buttons, they also enable the direct selection of the most important pages and thus enable an effective operation of the plant.

The pages are grouped thematically and can be quickly and easily reached through the menu guide or through a central button.




**Please remember, that all push-button texts indicate the action that will be taken by pressing the button.**


**For example, if the button text shows “manual operation”, this indicates that the system is currently in AUTOMATIC OPERATION mode, and by pressing this button, the operator will change the operating mode to MANUAL OPERATION.**

## Overview page

From the overview page, it is possible to see the status of the overall system quickly, and this information will be described in the following pages.




1. The "Primary Status Field" is shown at all times on all pages and has the same layout on each page. It provides an overview of the status of the overall system. See section 7.0 of this document for a list of the primary status options.
2. The "Sub-Condition Field" is also repeated on each page. See section 7.0 of this document for a list of the sub-condition status options.
3. The "Access Level Field" indicates the present access level based on the password entered.
4. The "Current Operating Status Level Field" indicates the current operating condition of the system. See section 7.0 of this document for a list of the operating status options.
5. The "Reason for system stop field" indicates what has caused the system to stop under a normal stop condition. If this condition is removed, this fault will auto-acknowledge, and the system will either attempt to restart or the next condition with an auto-acknowledge designation that is preventing a start attempt will appear.




The information highlighted provides the following data:

1. Electrical power (kW) currently being generated.
2. The gas supply for the system (can be more than one possible gas supply)
3. An overview of the system connection configuration and breaker status.
4. The current operating language of the system. By clicking this button, it is possible to change the operating language to another from a list of options that will appear.
5. Power information providing values for:
  - a. Demand (kW): the power value demanded by the operator or external power control set point request for the system. Indicated by the GREEN line on the moving pointer display.
  - b. Permitted power (kW): the maximum power possible for the system to generate based on the status of the overall conditions of the system.
  - c. Active power (kW): the instantaneous power value measured by the system.
  - d. P reduced (kW): the amount by which the permitted power has been automatically reduced by the DM 400 due to the current operating conditions. The difference between the demand power and the permitted power values.
  - e. P reduced – this is a text message indicating which parameter is requesting the reduction in output power. If this condition is removed, this message will disappear and the system will attempt to return to the demand power value or the next condition with an auto-acknowledge designation that is preventing operation at the demand power value will appear in this space.




The following control functions can be selected by using the buttons on the overview page:

- Start/stop
Starts and stops the system using the normal procedures (including power down ramp and engine cool down and so on).
- Acknowledge
Acknowledgement of all pending alarms.
- Automatic/manual operation
Switch between manual and automatic operating mode. It is necessary to be in manual mode to enable the test pages.
- Quick stop
Fast shutdown on the system opens the generator circuit breaker and then stops the engine. Auxiliary systems continue to run and enter into their normal shutdown procedure. The "quick stop" button can be hidden with the selection of the appropriate parameter.
- Navigator
Go to navigator page 22
- Electrical values
Go to the electrical measurements page 36
- Engine values
Go to the engine (and ignition) pages 48
- Emission control
Go to the emission control setup pages 43



The information highlighted provides the following data:

1. The values of these buttons are fixed within the software and they increase or decrease the demand power value by the amount selected. This operation is limited to the maximum power rating of the system. The actual active power value will be limited by the permitted power value.
2. By clicking the moving pointer gauge another window opens which enables the demand power to be set at other values as shown in the typical example below (as each system is individual and so the MIN/MAX values may vary) :



The keypad which appears states the parameter name (in this case "Demanded Load") (kW)) and the parameter number, which will be set when the ENTER button is pressed.


There are three "quick keys":


- MIN: the minimum allowable value
- MAX: the maximum allowable value
- DEFAULT: the system default value.

By pressing one of these "quick keys" and selecting ENTER, the parameter is then set to this value.

Alternatively, the screen pointer can be used to enter the numerical value required and the parameter is set by pressing ENTER.

## Parameter editor



- As a basic rule, only values within the range from MIN to MAX are permitted
- The first press of a key after opening the parameters editor releases the input field
- The leading symbol is always shown (+ or -)
- The comma displayed on the keypad represents the decimal point and can only be entered once, and only if the parameter to be changed has at least one decimal position (see display of the parameter on the page)
- No more than the permissible number of decimal places may be entered
- The DEFAULT value is the value to which the parameter is set if the factory setting is activated
- If a value outside of the permissible range ( $< \text{MIN}$  or  $> \text{MAX}$ ) is entered, the MAX or MIN value is displayed when Enter is pressed. This can - if desired - be accepted with an additional press of Enter.
- To exit the parameters editor without changes, it can be closed with x.
- With the pin  it is possible to pin the parameter editor on top of the display. In other words, it is possible to enter a value without having to close the parameter editor. This function is useful in cases where a parameter must be determined through experimentation. When the editor is pinned on top, it can only be closed with x.
- All parameter changes are logged and can be viewed in the parameter changes log book (in each case with the old and new value displayed).

## Counter, service page

The counters, service page is displayed if the “counters, service” button on the overview page is selected.

<b>DEIF</b>		02-01-2014 09:45:32	
<b>READY TO START</b>		access level: 2	
operation stopped		operation level: 5	
Pel	0	kW	overview: counters, service
			gas type A

active energy, generated	0	kWh	<div>overview</div> <div>counters, service</div> <div>analysis counter</div> <div>log off</div>
reactive energy, generated	0	kvarh	
operating time	0	h	
breaker operations GCB	0		
breaker operations MCB	0		
start attempt counter	0		
service engine in	10000	h	
service lube oil in	10000	h	
service spark plug in	10000	h	

start	acknowledge	manual operation	quick stop
navigator	electrical values	engine values	emission control

This page provides an overview of the standard system counters which are:

- Total active power generated (kWh)
- Total reactive power generated (kvarh)
- Operating time (running hours)
- The total number of operations for the Generator Circuit Breaker (GCB)
- The total number of operations for the Mains Circuit Breaker (MCB)
- The total number of start attempts that the system has made
- Countdown timer indicating the number of hours before the next engine service is scheduled
- Countdown timer indicating the number of hours before the next lube oil service is scheduled
- Countdown timer indicating the number of hours before the next spark plug service is scheduled

Each of these three service countdown timers can be reset after the completion of maintenance work through maintenance counter option on the parameters page.

## Analysis counter page

The analysis counter page is displayed if the “analysis counter” button is selected either from the overview page or from the “counters, service” page.

<b>DEIF</b>		<b>DEIF</b>		02-01-2014 09:45:42	
<b>READY TO START</b>				access level: 2	
operation stopped				operation level: 5	
Pel	0	kW	overview: analysis counter		gas type A

counter name	counter value	day	month	year	unit
active energy, generated	0	0	0	0	kWh
counter 01	0.0	0	0	0	
counter 02	0.0	0	0	0	
counter 03	0.0	0	0	0	
counter 04	0.0	0	0	0	

start	acknowledge	manual operation	quick stop
navigator	electrical values	engine values	emission control

overview

counters, service

analysis counter

log off

In this page, the counters for the generated active energy and the configurable counters are displayed.

For each of these counters, in addition to the current counter status, the respective counter values

- for the current day
- for the current month and
- for the current year

are shown.

## Log in page

The log in page is displayed if the “log on” button is selected from any of the overview, counters, service or analysis counter pages. It is also possible to access the log in page by clicking the logo in the top left corner of the display.

The ability to change the system settings is depending on the current access level highlighted on the diagram by 1

If someone is already logged in, the current permission level will be higher than 0.

The higher the importance of the parameter, the higher the access level required to change it.

To log on to access level 1 (also known as operator) or access level 2 (also known as service), the corresponding button should be selected using the on-screen pointer, and the appropriate password should be entered using the keypad which appears.

Passwords can be set via the parameters page, see section on page 74, and these should be recorded and kept in a safe please.

Log on level 3 is reserved for DEIF personnel only and cannot be changed.

The operator is automatically logged off after 30 minutes of time without operation.




**Please remember, that all push-button text indicate the action that will be taken by pressing the button.**

**For example, if the button text shows log on, this indicates that the operator is currently in logged off and vice versa.**

## Navigator page

From the navigator page, it is possible to access all pages of the DM 400 software, either directly or indirectly.



Pressing the buttons on the navigator page opens the pages within the software that are connected to this theme.

Function	Page
<i>Trending</i>	23
<i>Log books</i>	26
<i>System diagnostics</i>	31
<i>Electrical values</i>	36
<i>Generator temperatures</i>	40
<i>Active alarms</i>	42
<i>Emission control</i>	43
<i>Overview</i>	14
<i>Engine values</i>	48
<i>Room air ventilation</i>	59
<i>Parameters</i>	74
<i>Test of auxiliaries</i>	62
<i>Lube oil system</i>	63
<i>Heating system</i>	66
<i>Gas/exhaust system</i>	70

## Trending


Trending information can be accessed via the “trending” button on the navigator page. The trending functionality is a very useful aid for the effective analysis of the process history. There is a choice of high-resolution, normal and long-term trending. Trending is activated through the “switch on scope” button. For each resolution, the values for 600 points in time are saved in a buffer on the DM 400.

Time interval of the trending data capture:

Trending type	Time interval of recording	Time interval of trending display (x axis)	Data automatically saved PC
High-resolution	40 msec	24 sec	No
Normal	1 sec	10 min	No
Long time	4 min	40 h	Yes


During long time trending, all data captured is written to the memory of any PC that is connected to the DM 400.

In the curve view, up to 12 curves are displayed simultaneously:




The “scale” button to the left of the vertical axis scrolls through the axis labels and units for each of the displayed curves in turn. With the “switch off scope” button, the recording of the values is stopped and the display is not updated, so that data can be analysed conveniently.

## Trending – measuring points on the display



Clicking the display pointer on the trending display brings up a measuring point, and the values for the parameters that have been selected are displayed for this measuring point.

The measuring point can be moved either by clicking at another position within the display or by

using the arrow buttons .

## Trending – saving of data

The saving of data to the PC HMI hard drive is automatic under long time trending conditions.

The saving of 600 sets of data under high resolution or normal trending conditions (every 4 ms and 1 s respectively) would cause the PC HMI memory space to become full very quickly and this is not an automatic function. This can be done manually, and it is described in the HMI browser for PC application notes which is available for download from the DEIF website on [www.deif.com](http://www.deif.com).



**It is recommended as part of the routine maintenance program, that the data saved in the PC HMI memory space is regularly copied and removed from the PC HMI memory and stored in a safe location.**

## Curve selection

With the curve selection page, it is possible for the operator to select and deselect the data points to be represented as curves on the trending display by clicking the required parameters listed on the display.

Up to a maximum of 12 trending curves can be selected for display.  
Parameters that have been selected are highlighted in yellow.

Using the “back to trending” button returns the operator to the trending display.

<b>DEIF</b>		<b>DEIF</b>			02-01-2014 09:47:30
<b>READY TO START</b>					access level: 2
operation stopped					operation level: 5
Pel	0	kW	curve selection for normal trending		gas type A

U gen L1L2	P	T exhaust after engine A	p cooling water	cooling pump
U gen L2L3	Q	T exhaust after engine B	T cold junction	heating pump
U gen L3L1	P permitted	T exhaust after KAT	T room air	knocking int. left
U gen L1N	GOV out	T exhaust after AWT	FU setpoint room vent.	phase angle
U gen L2N	AVR out	T cylinder A	knocking intensity right	throttle position
U gen L3N	T engine in	T cylinder B	T receiver	gas mixer position
U bus L1L2	T engine out	T average A	p receiver	CH4
U bus L2L3	heating water valve	T average B	p lube oil	setpoint NKK fan
U bus L3L1	emerg-cooler valve	gas flow	T lube oil	ignition retard
I gen L1	emerg-cooler stage	turbo setpoint	T intercooler water	exhaust bypass
I gen L2	T emerg-cooler	turbo position	intercooler stage	T heating water flow
I gen L3	starter	setpoint SWK	intercooler valve	T heating water return
f gen	island stage	20msTask	gas level plant	T in eng-heat-exchanger
f bus	imported power	100msTask	phase angle MCB	T after AWT
speed	generator demanded load	1000msTask	U battery	p crank case

navigator

back to  
trending

overview

Regardless of which parameters have been selected for display, all of the values listed are recorded while scope is running.

## Log books

The DM 400 log books are accessible via the navigator page.

The following events are recorded in the log books as the abbreviations shown:

- M: status change - an event where the primary status condition changes
- P: parameter change - an event where a parameter value has been changed
- S: messages/faults - an event where an error or fault message has been displayed
- C: cyclical statuses - a cyclic, scheduled log of certain data values
- W: service - log of service calls and an indication once these have been completed

Individual or multiple log books can be selected by selecting or deselecting the corresponding buttons on the logbook page. The entries are shown sorted chronologically.

In online mode, the most current data is always shown, with the latest entry at the bottom.

In offline mode ("offline ->online" button is not pressed), it is possible to trace events in the past.

When the log books are offline, it is possible to scroll the data using the buttons.



When the page up/down buttons are selected, one line of text is always retained from the previous page.

Up to 19 lines of data can be viewed on one page. If there are less than 19 lines of data, the page up/down buttons do not appear.

DEIF

**DEIF**  
**READY TO START**  
operation stopped

02-01-2014  
09:48:13  
  
access level: 2  
  
operation level: 5

Pel

0

kW

logbook

gas type A

▲

▲

▼

▼

02-01-2014	08:47:10.520	M	EMERGENCY STOP	1		
02-01-2014	08:47:28.505	P	access level 2	40030	+0	+2
02-01-2014	09:08:15.507	P	I/O assignment	44401	+0	+2
02-01-2014	09:08:44.507	P	I/O assignment	44401	+2	+0
02-01-2014	09:20:10.462	M	SYSTEM POWER UP	0		
02-01-2014	09:20:10.628	M	EMERGENCY STOP	1		
02-01-2014	09:20:19.614	P	access level 2	40030	+0	+2
02-01-2014	09:20:29.869	M	REARM SAFETY CHAIN	3		
02-01-2014	09:20:30.447	M	START BLOCKED	3		
02-01-2014	09:24:06.614	P	I/O assignment	44304	+0	+40
02-01-2014	09:29:02.614	P	I/O assignment	44304	+40	+0
02-01-2014	09:30:15.989	M	READY TO START	5		
02-01-2014	09:30:47.614	P	I/O assignment	44105	+0	+13
02-01-2014	09:31:25.327	M	START PREPARATION	5		
02-01-2014	09:31:25.614	P	I/O assignment	44106	+0	+14
02-01-2014	09:31:28.448	M	STOPPING	8		
02-01-2014	09:31:28.468	M	START BLOCKED	5		
02-01-2014	09:31:28.488	M	READY TO START	5		
02-01-2014	09:33:07.614	P	access level 2	40030	+0	+2

main state  
change (M)

parameter-  
change (P)

messages  
faults (S)

main state  
cyclic (C)

navigator

online  
-> offline

service (W)

overview

## Main State change (M)

The selection of "main state change (M)" displays an event where the primary status condition has changed.

The information is displayed in the format of: **Date, Time, Event Type (M), Status, and Stop Level**

Number of entries: 250

## Parameter change (P)

Each change of a parameter is saved, and the history of these changes can be viewed with this button.

The information is displayed in the format of: **date, time, event type (P), parameter text, parameter number, old value and new value**

The parameter number is logged, and is also shown in the parameter editor. Since the number is unique, mix-ups are avoided, even if a familiar language is not selected. Both the old and the most recently set value for this parameter are logged.

### Specifics:

The logins are also saved in this log book (operator login, service login, master login). The valid access level before and after the login is recorded here.

Number of entries: 250

DEIF

DEIF

02-01-2014  
09:48:29

**READY TO START**

Pel

0

kW

logbook

access level: 2  
operation level: 5  
gas type A

▲

▲

▼

▼

30-12-2013	11:34:44.593	P	I/O assignment	45101	+40	+0
30-12-2013	11:34:48.593	P	I/O assignment	45102	+50	+0
30-12-2013	11:34:51.593	P	I/O assignment	45105	+108	+0
30-12-2013	11:34:53.591	P	I/O assignment	45106	+109	+0
30-12-2013	11:34:57.592	P	I/O assignment	45209	+18	+0
30-12-2013	11:35:00.592	P	I/O assignment	45206	+62	+0
30-12-2013	11:35:02.592	P	I/O assignment	45207	+63	+0
30-12-2013	11:35:05.593	P	I/O assignment	45208	+17	+0
02-01-2014	08:18:27.574	P	access level 2	40030	+0	+2
02-01-2014	08:18:58.573	P	option TecJet	22500	+1	+0
02-01-2014	08:47:28.505	P	access level 2	40030	+0	+2
02-01-2014	09:08:15.507	P	I/O assignment	44401	+0	+2
02-01-2014	09:08:44.507	P	I/O assignment	44401	+2	+0
02-01-2014	09:20:19.614	P	access level 2	40030	+0	+2
02-01-2014	09:24:06.614	P	I/O assignment	44304	+0	+40
02-01-2014	09:29:02.614	P	I/O assignment	44304	+40	+0
02-01-2014	09:30:47.614	P	I/O assignment	44105	+0	+13
02-01-2014	09:31:25.614	P	I/O assignment	44106	+0	+14
02-01-2014	09:33:07.614	P	access level 2	40030	+0	+2

main state  
change (M)

parameter-  
change (P)

messages  
faults (S)

main state  
cyclic (C)

navigator

online  
-> offline

service (W)

overview

## Messages faults (S)

For messages faults (error messages), there is an entry for each when the event occurs (S) and when it is acknowledged (Q)

The information is displayed in the format of: **date, time, event type [S], message acknowledged [Q], message text, message number, stop level**

Number of entries: 250

Note: all currently pending messages can be shown through the “active alarms” page from the navigator and can be acknowledged there, if necessary.

A general acknowledge function for all active fault conditions can also be completed via the “acknowledge” button on the overview page.

The screenshot displays the DEIF control interface. At the top, the DEIF logo is on the left, and the date/time '02-01-2014 09:48:56' is on the right. Below this, a large blue banner reads 'READY TO START' with 'access level: 2' on the right. Underneath the banner, 'operation stopped' is written in red, and 'operation level: 5' is on the right. A status bar shows 'Pel 0 kW' and 'logbook' in the center, with 'gas type A' on the right. Navigation arrows are present above and below the logbook list. The logbook itself is a table with columns for date, time, event type, message text, message number, and stop level. The last entry is highlighted in red.

date	time	event type	message text	message number	stop level
02-01-2014	09:25:12.410	S	cooling water pressure too high	70248	7
02-01-2014	09:25:12.509	S	stop: cooling water pressure not in limit	50161	5
02-01-2014	09:25:14.309	S	stop: cooling water pressure too high	50163	5
02-01-2014	09:25:18.414	S Q	stop: wire break cooling water pressure	50160	5
02-01-2014	09:25:18.414	S Q	stop: cooling water pressure not in limit	50161	5
02-01-2014	09:25:18.414	S Q	stop: cooling water pressure too high	50163	5
02-01-2014	09:25:18.414	S Q	cooling water pressure too low	70247	7
02-01-2014	09:25:18.414	S Q	cooling water pressure too high	70248	7
02-01-2014	09:26:23.709	S	short circuit of sensor gen bearing A	50193	5
02-01-2014	09:30:15.980	S Q	short circuit of sensor gen bearing A	50193	5
02-01-2014	09:30:15.980	S Q	sensor defect gen bearing A	50198	5
02-01-2014	09:30:15.980	S Q	wire break PT100 mixture temperature	70226	7
02-01-2014	09:30:15.980	S Q	over temperature mixture	70229	7
02-01-2014	09:31:25.327	S Q	operation stopped	50100	5
02-01-2014	09:31:28.448	S	operation stopped	50100	5
02-01-2014	09:31:28.709	S	wirebreak throttle position	70250	5
02-01-2014	09:31:28.709	S	deviation of throttle position	70251	5
02-01-2014	09:31:33.910	S Q	deviation of throttle position	70251	5
02-01-2014	09:31:40.959	S Q	wirebreak throttle position	70250	5

At the bottom, there are eight buttons arranged in a 2x4 grid: 'main state change (M)', 'parameter-change (P)', 'messages faults (S)', 'main state cyclic (C)', 'navigator', 'online -> offline', 'service (W)', and 'overview'.




## Service (W)

In the service log book, the service due events and their acknowledgements are saved with a time stamp.

The resetting of the maintenance counter is treated as an acknowledgement. An acknowledgement entry is identified with a "Q".

The information is displayed in the format of: **date, time, event type [W] and acknowledgement [Q], maintenance event text, operating hours**

Number of entries: 200



## System diagnostics pages

The system diagnostics pages contain information relating to the system configuration, software versions and real time status of the DM 400 system.

This information is primarily for use by engineers for trouble shooting purposes and the information contained in the following pages is designed as an overview only.

The screenshot displays the DEIF system diagnostics interface. At the top, a header bar shows the DEIF logo, the text 'DEIF', and the date/time '19-11-2014 15:57:41'. Below this, a large blue box indicates an 'EMERGENCY STOP' status with the message 'DM4 IO card data exchange timeout'. To the right of this box, it shows 'access level: 0' and 'operation level: 1'. Below the emergency stop box, a row of buttons shows 'Pel', '0', 'kW', and 'system diagnostics: versions', with 'gas type A' indicated on the far right.

The main content area displays the following information:


Application software version: 436729002  
 Communication to ignition type: PHLOX

	Modul 2	Modul 3	Modul 4	Modul 5
Interface-Version	3	0	0	0
Hardware-Version	0	0	0	0
Software-Version	3002	0	0	0
Software-Revision	0	0	0	0

Task Stack Free

TASK-20MS	64000	62852	XXXXXXXXXXXXXXXXXXXXXXXXXXXX
TASK-100MS	64000	63060	XXXXXXXXXXXXXXXXXXXXXXXXXXXX
TASK-1000MS	64000	63058	XXXXXXXXXXXXXXXXXXXXXXXXXXXX

On the right side of the interface, there is a vertical stack of buttons: 'versions', 'states 1', 'states 2', 'modem/TCP', and 'I/O'. At the bottom, there is a horizontal row of buttons: 'navigator', 'electrical values', 'engine values', and 'overview'.



DEIF

19-11-2014  
15:57:58

EMERGENCY STOP

access level: 0

DM4 IO card data exchange timeout

operation level: 1

Pel0kW

system diagnostics: states 1

gas type A

MAIN.state EMERGENCY STOP

SAF.mode TRIP CHAIN

SAF.state CHAIN IS TRIPPED

MAIN.startdemand0

STOP.actualLevel1

STOP.actualBitMask64780

20msTask2

100msTask3

1000msTask1

H8 cpu load 1sec17.5%

Misfire Detected0

Misfire Counter0

Wrong Parameter0

Number Of Languages2

MIX.TempOffset0.00

HKS.TempSetp\_EngEntr890

Sync Conditions:

U/f Gen OK0

U/f Bus OK0

U Gen Reg Done0

f Gen Reg Done0

df/dt OK1

Sync Pulse0

SCM02:

ProtectionsMaske

RouteThroughMaska

TripFeedback4

BreakerFeedback8

TrippedBySCM0

TUR.TargetPhaseAngle0

TUR.Pset0

TUR.Reg.PowerSetPoint0

Reactive-Import.State0

Reactive-Import.Timer3593

Reactive-Import.Exceeded0

Qsum0

Limit-27

versions

states 1

states 2

modem/TCP

I/O

navigator

electrical values

engine values

overview

<b>DEIF</b>		<b>DEIF</b>		19-11-2014 15:58:08	
<b>EMERGENCY STOP</b>				access level: 0	
DM4 IO card data exchange timeout				operation level: 1	
<b>Pel</b>	<b>0</b>	<b>kW</b>	<b>system diagnostics: states 2</b>		gas type A

AIR.mode	0	GAS.mode	0	ISL.mode	1	WAT.mode	0	<b>versions</b>
AIR.state	1	GAS.state	1	ISL.state	6	WAT.state	1	
BY.mode	0	GEN.mode	0	MIX[1].mode	0			<b>states 1</b>
BY.state	1	GEN.state	1	MIX[1].state	1			
COM.mode	0	GEN.reg.mode	1	MIX[2].mode	0			<b>states 2</b>
COM.state	3	GEN.reg.state	0	MIX[2].state	1			
DK.mode	0	GKK.mode	0	NKK.mode	0			<b>modem/TCP</b>
DK.state	1	GKK.state	1	NKK.state	1			
DKA.mode	0	HKS.mode	0	OIL.mode	0			<b>I/O</b>
DKA.state	3	HKS.state	1	OIL.state	1			
DKB.mode	0	HVS (T1E).mode	0	PLS.mode	0			<b>navigator</b>
DKB.state	3	HVS (T1E).state	0	PLS.state	1			
ELM (MB).mode	1	HVS (L1E).mode	2	RGB.mode	0			<b>electrical values</b>
ELM (MB).state	2	HVS (L1E).state	5	RGB.state	1			
ENG.mode	0	HZM.mode	0	SAF.mode	0			<b>engine values</b>
ENG.state	1	HZM.state	0	SAF.state	1			
FAN.mode	0	IGN.mode	0	TUR.mode	0			<b>overview</b>
FAN.state	1	IGN.state	2	TUR.state	1			

DEIF

DEIF

19-11-2014  
15:58:22

EMERGENCY STOP

access level: 0

DM4 IO card data exchange timeout

operation level: 1

Pel

0

kW

system diagnostics: modem/TCP

gas type A

SEND\_SMS

SMS.wSMSstopc.:703  
SMS.bComInit: 0  
SMS.bModemInit:0  
SMS.wSMScount: 0  
  
SMS.Message:  
SMS.cBuffer:  
  
TCP address: 192.168.2 .21  
subnet mask: 255.255.255.0  
gateway address: 192.168.2 .182

SMS.wTask: 0  
SMS.wResult: 0  
SMS.wState: 0  
SMS.dwTime: 0  
  
SMS.PhoneNbr:

versions

states 1

states 2

modem/TCP

I/O

navigator


electrical values

engine values

overview

DEIF A/S

Page 34 of 83

	<h1 style="margin: 0;">DEIF</h1>	<div style="margin-bottom: 5px;">19-11-2014</div> <div>15:58:36</div>		
<h2 style="margin: 0;">EMERGENCY STOP</h2>		<div style="margin-bottom: 5px;">access level: 0</div> <div>operation level: 1</div>		
<div style="color: red; font-weight: bold; margin-bottom: 5px;">DM4 IO card data exchange timeout</div>		<div style="margin-bottom: 5px;">operation level: 1</div> <div>access level: 0</div>		
Pel	0	kW	<h3 style="margin: 0;">system diagnostics: I/O</h3>	<div style="margin-bottom: 5px;">access level: 0</div> <div>operation level: 1</div>

	3	4	5		<div style="background-color: #e0e0e0; padding: 5px; border: 1px solid #ccc;">versions</div>
Modul					
AI (PT100/NiCrNi)					
AI 1	0	0	0		<div style="background-color: #e0e0e0; padding: 5px; border: 1px solid #ccc;">states 1</div>
AI 2	0	0	0		
AI 3	0	0	0		
AI 4	0	0	0		
AI 5	0	0	0		
AI 6	0	0	0		
AI (+-20mA)					<div style="background-color: #e0e0e0; padding: 5px; border: 1px solid #ccc;">states 2</div>
AI 1	0	0	0		
AI 2	0	--	--		
AI 3	--	--	--		
AI 4	0	--	--		
AO (+-20mA)					<div style="background-color: #e0e0e0; padding: 5px; border: 1px solid #ccc;">modem/TCP</div>
AO 1	-27768	25000	0		
AO 2	0	--	--		
AO 3	0	5000	--		
AO 4	--	--	--		
BitMask 10103:	0000.0000.0000.0000.0000.0000.0000.1110 0000.0000.0000.0000.0000.0000.0000.0000				<div style="background-color: #a0a0a0; padding: 5px; border: 1px solid #ccc;">I/O</div>

navigator	electrical values	engine values	overview
-----------	-------------------	---------------	----------

## Electrical values – pointer instruments

The electrical values pages can be reached through the overview page and the navigator page. The pointer instruments page can be displayed from the electrical values pages.


Depending on the configuration of the system, the pointer instruments page will display at least two and possibly three pairs of moving pointer instruments which are:

1. Mains voltage and frequency
2. Busbar voltage and frequency (if applicable)
3. Generator voltage and frequency

If the system is operating in mains parallel mode, then data relating to

- the current
- power
- cos phi (Power Factor)

are visualised in the form of pointer instruments



## Electrical values – diagnostics values

The diagnostics value page can be displayed from the electrical values pages.

Depending on the configuration of the system, the diagnostic values page will display at least two and possibly three columns of data, which are:

1. Mains voltage (phase–phase and phase–neutral) and frequency
2. Busbar voltage (phase–phase and phase–neutral) and frequency (if applicable)
3. Generator voltage (phase–phase and phase–neutral), phase currents and frequency
4. Voltage regulator output (mA)
5. Cold junction temperature (°C)
6. Battery voltage (V)
7. Active power value (kW)
8. Cos phi (Power Factor) value

<b>DEIF</b>		<b>DEIF</b>		19-11-2014 15:39:12	
<b>EMERGENCY STOP</b>				access level: 0	
DM4 IO card data exchange timeout				operation level: 1	
Pel	0	kW	<b>electrical values</b>		gas type A

		<p>pointer instruments</p> <p>diagnostics values</p> <p>generator protection</p> <p>mains protection</p>
<p>U L1L2 <input type="text" value="0"/> V</p> <p>U L2L3 <input type="text" value="0"/> V</p> <p>U L3L1 <input type="text" value="0"/> V</p> <p>U L1-N <input type="text" value="0"/> V</p> <p>U L2-N <input type="text" value="0"/> V</p> <p>U L3-N <input type="text" value="0"/> V</p> <p>f <input type="text" value="0.00"/> Hz</p> <p>voltage reg. <input type="text" value="0.0"/> mA</p> <p>T cold j. <input type="text" value="0"/> °C</p> <p>U battery <input type="text" value="N.A."/> V</p>	<p>U L1L2 <input type="text" value="0"/> V</p> <p>U L2L3 <input type="text" value="0"/> V</p> <p>U L3L1 <input type="text" value="0"/> V</p> <p>U L1-N <input type="text" value="0"/> V</p> <p>U L2-N <input type="text" value="0"/> V</p> <p>U L3-N <input type="text" value="0"/> V</p> <p>f <input type="text" value="0.00"/> Hz</p> <p>I L1 <input type="text" value="0"/> A</p> <p>I L2 <input type="text" value="0"/> A</p> <p>I L3 <input type="text" value="0"/> A</p> <p>P <input type="text" value="0"/> kW</p> <p>CosPhi <input type="text" value="--"/></p>	


  

navigator	engine values	overview
-----------	---------------	----------

## Electrical values – generator protection

The generator protection page can be displayed from the electrical values pages.

The generator protection page displays the settings and current status of the generator protections



The generator protection data consists of:

StopC	Stop Condition alarm number
Symbol	Mnemonic symbol of the protection type
Limit	Parameter limit for the value column
Value	Actual value measured or calculated within the DM 400
Bit	Is an indication that shows which phase is causing the fault (using binary code)
State	Current parameter state COLD: not activated HOT: parameter limit has been exceeded and waiting for any associated time delay to expire REC: an auto acknowledge condition has occurred and is now in the process of recovering back to the COLD state TRIP: the parameter limit has been exceeded, any associated time delay has expired and therefore a warning or fault condition is present.
Timer	The duration for which the current state has existed, in seconds.

## Electrical values – mains (grid) protection

The mains (or grid) protection page can be displayed from the electrical values pages.

The mains (or grid) protection page displays the settings and current status of the mains protections

The screenshot shows the DEIF EMERGENCY STOP interface. At the top, it displays the DEIF logo, the date and time (19-11-2014 15:39:57), and the access level (0). Below this, it shows the operation level (1) and the gas type (A). The main section is titled 'grid protection' and displays a table of protection parameters. To the right of the table are buttons for 'pointer instruments', 'diagnostics values', 'generator protection', and 'mains protection'. At the bottom are buttons for 'navigator', 'engine values', and 'overview'.


StopC	Symbol	Limit	Value	Bit	State	Timer
30674	U>1 d	455	0 V	0	COLD	2514 s
30675	U>1 s	263	0 V	0	COLD	2514 s
30667	U>1a d	455	0 V	0	COLD	2514 s
30668	U>1a s	263	0 V	0	COLD	2514 s
30671	U<1 d	368	0 V	7	TRIP	2513 s
30665	U<1a d	384	0 V	7	TRIP	2512 s
30672	U<1 s	212	0 V	7	TRIP	2513 s
30666	U<1a s	222	0 V	7	TRIP	2512 s
30669	U<UVS	360	0 V	0	COLD	2514 s
30663	U>(avg)	440	0 V	0	COLD	2513 s
30664	U<(Q)			0	COLD	2513 s
30673	f>1	50.20	0.00 Hz	0	COLD	2514 s
30670	f<1	49.00	0.00 Hz	0	COLD	2514 s
30677	df/dt	2.4	0.0 Hz/s	0	COLD	2514 s
30657	KU	20	0	0	COLD	2514 s
30662	Sync			5	COLD	2511 s
30654	U>2 d	440	0 V	0	COLD	2513 s
30655	U>2 s	254	0 V	0	COLD	2513 s
30651	U<2 d	368	0 V	7	TRIP	2490 s
30652	U<2 s	212	0 V	7	TRIP	2490 s
30653	f>2	50.20	0.00 Hz	0	COLD	2513 s
30650	f<2	49.01	0.00 Hz	1	TRIP	2490 s

The grid protection data consists of:

StopC	Stop Condition alarm number
Symbol	Mnemonic symbol of the protection type
Limit	Parameter limit for the value column
Value	Actual value measured or calculated within the DM 400
Bit	Is an indication that shows which phase is causing the fault (using binary code)
State	Current parameter state <ul style="list-style-type: none"> <li>COLD: not activated</li> <li>HOT: parameter limit has been exceeded and waiting for any associated time delay to expire</li> <li>REC: an auto acknowledge condition has occurred and is now in the process of recovering back to the COLD state</li> <li>TRIP: the parameter limit has been exceeded, any associated time delay has expired and therefore a warning or fault condition is present.</li> </ul>
Timer	The duration for which the current state has existed, in seconds.
Grid protection indicator	Green = which circuit breaker would trip if a grid protection fault occurred.

Generator temperatures

The generator temperature values page gives a graphical indication of the status of temperature measurements and the generator winding and bearing temperatures (if assigned) of the generator.



A red indicator indicates that the parameter limit has been exceeded.

## Generator temperature protection

The generator temperature values page gives an indication of the status and temperature measurements being taken from the generator itself.

<b>DEIF</b>		<b>DEIF</b>		19-11-2014 16:00:28
<b>EMERGENCY STOP</b>				access level: 0
DM4 IO card data exchange timeout				operation level: 1
<b>Pel</b>	<b>0</b>	<b>kW</b>	<b>generator temperatures protection</b>	gas type A

StopC Symbol	Limit Value	State
50190 short circuit of sensor gen winding temp. U		COLD
50195 sensor defect gen winding temp. U		COLD
30680 winding excess temperature U	120 N.A. °C	COLD
50191 short circuit of sensor gen winding temp. V		COLD
50196 sensor defect gen winding temp. V		COLD
30681 winding excess temperature V	120 N.A. °C	COLD
50192 short circuit of sensor gen winding temp. W		COLD
50197 sensor defect gen winding temp. W		COLD
30682 winding excess temperature W	120 N.A. °C	COLD
50193 short circuit of sensor gen bearing A		COLD
50198 sensor defect gen bearing A		COLD
20050 gen bearing excess temperature A	120 N.A. °C	COLD
50194 short circuit of sensor gen bearing B		COLD
50199 sensor defect gen bearing B		COLD
20051 gen bearing excess temperature B	120 N.A. °C	COLD
20049 winding temperature limiter		COLD

<b>navigator</b>	<b>electrical values</b>	<b>engine values</b>	<b>overview</b>
------------------	--------------------------	----------------------	-----------------

The generator temperature protection data consists of:

StopC	Stop Condition alarm number
Symbol	Parameter text
Limit	Parameter limit for the value column
Value	Actual value measured or calculated within the DM 400
State	Current parameter state
	COLD: not activated
	HOT: parameter limit has been exceeded and waiting for any associated time delay to expire
	REC: an auto acknowledge condition has occurred and is now in the process of recovering back to the COLD state
	TRIP: the parameter limit has been exceeded, any associated time delay has expired and therefore a warning or fault condition is present.

## Active alarms

The active alarms page shows an overview of the current and most recent stop conditions.

DEIF		19-11-2014 16:00:48	
EMERGENCY STOP		access level: 0	
DM4 IO card data exchange timeout		operation level: 1	
Pel	0	kW	current stop conditions
			gas type A
19-11-2014	14:58:03.917	Bulk oil level low	70310 7
19-11-2014	14:58:03.917	inlet manifold pressure	60306 6
19-11-2014	14:58:03.533	operation stopped	50100 5
19-11-2014	14:58:03.533	operation blocked on switchboard panel	50002 5 R
19-11-2014	14:58:03.713	sensor defect lube oil pressure	50071 5 R
19-11-2014	14:58:03.713	room air temperature limiter	60026 6 R
19-11-2014	14:58:27.517	mains star undervoltage 2: stopping	30652 3 R
19-11-2014	14:58:27.517	mains delta undervoltage 2: stopping	30651 3 R
19-11-2014	14:58:27.517	mains underfrequency 2: stopping	30650 3 R
19-11-2014	14:58:04.532	generator breaker position failure	30610 3 R
19-11-2014	14:58:04.917	lube oil level low	20216 2
19-11-2014	14:58:03.532	low water level cooling circuit	20048 2
19-11-2014	14:58:13.712	exhaust back pressure too high	20044 2
19-11-2014	14:58:04.213	gas pressure line A	20012 2 R
19-11-2014	14:58:03.917	fire alarm	10311 1
19-11-2014	14:58:03.916	primary water pressure	10305 1
19-11-2014	14:58:03.714	gas alarm	10213 1
19-11-2014	14:58:03.532	smoke alarm	10212 1
19-11-2014	14:58:03.713	low water level heating circuit	10205 1
19-11-2014	14:58:03.370	emergency stop button	10201 1
23-06-2014	14:49:20.259	DM4 IO card data exchange timeout	10103 1

**navigator** **acknowledge** **overview**

The data is presented in the following format:

The date and time of the most recent stop condition

The parameter text for the stop condition

The stop condition code.

The stop level (1-8)

Action taken indicator, where R = a regular stop function where the generator circuit breaker is open and the engine is stopped. Auxiliary systems continue to run and enter into their normal shutdown procedure.

Note: all currently pending stop conditions can be acknowledged through the “acknowledge” button on this page, if necessary.

A general acknowledge function for all active fault conditions can also be completed via the “acknowledge” button on the overview page.

## Emission control




The emission control functionality and how to configure this is described in a separate emission control application note. The following pages provide a summary of the pages that can be viewed via the HMI only.

The “emission control” button opens up access to a number of other pages relating to set up of the system relating to emissions.

Access to change the parameters on these pages is password-protected and so the following pages provide an explanation of the data that is being displayed only.

### Emission control diagram



This page presents the following data:

Position	The relative position of the gas mixer valve (0 % [fully closed] -100 % [fully open])
Temp A	The present measured value of bank A exhaust temperature (°C)
Temp B	The present measured value of bank B exhaust temperature (°C)
U Lambda	The present measured voltage from the Lambda sensor (if fitted)
T receiver	The present measured temperature of the mixture in the receiver (°C)
P receiver	The present measured pressure of the mixture in the receiver (mbar)
P rec. setp.	The set point for the pressure of the mixture in the receiver (mbar)
Thr. Pos.	The relative position of the throttle valve (0 % [fully closed] -100 % [fully open])

## Emission control values

<b>DEIF</b>		<b>DEIF</b>		14-01-2015 17:08:02
<b>EMERGENCY STOP</b>				access level: 2
reboot necessary				operation level: 1
Pel	0	kW	<b>emission control values</b>	gas type A

mix position <input type="text" value="0.00"/> % thr. pos. <input type="text" value="-50.1"/> % p receiver <input type="text" value="v !"/> mbar p rec.setp. <input type="text" value="-1000"/> mbar T receiver <input type="text" value="^ !"/> °C p deviation <input type="text" value="v !"/> mbar T deviation <input type="text" value="^ !"/> K U lambda <input type="text" value="0.00"/> mA lean stop <input checked="" type="radio"/>	temp A <input type="text" value="0"/> °C temp B <input type="text" value="0"/> °C	emission diagram emission values emission config. emission protection emission trending
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------

navigator	electrical values	engine values	overview
-----------	-------------------	---------------	----------

This page presents the following data:

Mix Position	The relative position of the gas mixer valve (0 % [fully closed] -100 % [fully open])
Thr. Pos.	The relative position of the throttle valve (0 % [fully closed] -100 % [fully open])
P receiver	The present measured pressure of the mixture in the receiver (mbar)
P rec. setp.	The set point for the pressure of the mixture in the receiver (mbar)
T receiver	The present measured temperature of the mixture in the receiver (°C)
P deviation	The amount by which the measured pressure of the mixture in the receiver differs from the set point value (mbar)
T deviation	The amount by which the measured temperature of the mixture in the receiver differs from the set point value (K)
U Lambda	The present measured voltage from the Lambda sensor (if fitted)
Temp A	The present measured value of bank A exhaust temperature (°C)
Temp B	The present measured value of bank B exhaust temperature (°C)
Lean Stop	A red indicator indicates that the limit stop position of the gas mixer has been reached

## Emission control configuration



The emission control functionality and how to configure this is described in a separate emission control application note.

This example page taken from the HMI is for illustration purposes only as this is not a feature that an operator should need to adjust during everyday operation. Consequently, no descriptions are provided.

<b>DEIF</b>		<b>DEIF</b>		14-01-2015 17:08:16	
<b>EMERGENCY STOP</b>				access level: 2	
reboot necessary				operation level: 1	
Pel	0	kW	emission control configuration		gas type A

<div>+</div> Pel (act) <div>0</div> kW		<div>+</div> <div>+</div> mixer pos (act) <div>0.00</div> %	
<div>-</div> Pel (set) <div>500</div> kW		<div>-</div> <div>-</div> mixer pos (set) <div>0.00</div> %	

actual values:		EMIS configuration start						
el. load [kW]	<div>0</div>							
temperature [°C]	<div>^ !</div>							
pressure [mbar]	<div>v !</div>							
save	<div>1</div>	<div>2</div>	<div>3</div>	<div>4</div>	<div>5</div>	<div>6</div>	<div>7</div>	<div>8</div>
parameter values:								
el. load [kW]	<div>200</div>	<div>350</div>	<div>450</div>	<div>500</div>	<div>525</div>	<div>550</div>	<div>575</div>	<div>600</div>
temperature [°C]	<div>40</div>	<div>45</div>	<div>50</div>	<div>60</div>	<div>60</div>	<div>60</div>	<div>60</div>	<div>60</div>
pressure [mbar]	<div>0</div>	<div>600</div>	<div>800</div>	<div>1000</div>	<div>1000</div>	<div>1000</div>	<div>1000</div>	<div>1000</div>

emission diagram
emission values
emission config.
emission protection
emission trending

navigator	electrical values	engine values	overview
-----------	-------------------	---------------	----------

## Emission control protections

<b>DEIF</b>		<b>DEIF</b>		14-01-2015 17:08:35
<b>EMERGENCY STOP</b>				access level: 2
reboot necessary				operation level: 1
<b>Pel</b>	<b>0</b>	<b>KW</b>	<b>emission control protection</b>	gas type A

StopC Symbol	Limit Value	State
70220 limitstop lean does not disappear		COLD
70221 limitstop lean does not appear		COLD
70222 limitstop lean reached in control mode		COLD
70223 limitstop rich reached in control mode		COLD
70224 steps missing > 300		COLD
70237 sensor fault receiver pressure		TRIP
70225 sensor fault lambda voltage		TRIP
70226 wire break PT100 mixture temperature		TRIP
70227 short circuit PT100 mixture temperature		COLD
70229 over temperature mixture	70.0 3276.7 °C	TRIP
70230 under temperature mixture	25.0 3276.7 °C	COLD
30231 mixer control does not work	150 v !	COLD
70228 load reduction because mixture temperature		COLD
70232 timeout mixer moving to start position		COLD
70233 timeout mixer moving to idle position		COLD
70234 timeout mixer moving to parallel position		COLD
70235 timeout mixer moving to island position		COLD
70236 timeout mixer moving to rich position		COLD

<b>navigator</b>	<b>electrical values</b>	<b>engine values</b>	<b>overview</b>
------------------	--------------------------	----------------------	-----------------


  

<b>emission diagram</b>
<b>emission values</b>
<b>emission config.</b>
<b>emission protection</b>
<b>emission trending</b>

The emission control protection data consists of:

StopC	Stop Condition alarm number
Symbol	Parameter text
Limit	Parameter limit for the value column
Value	Actual value measured or calculated within the DM 400
State	Current parameter state
	COLD: not activated
	HOT: parameter limit has been exceeded and waiting for any associated time delay to expire
	REC: an auto acknowledge condition has occurred and is now in the process of recovering back to the COLD state
	TRIP: the parameter limit has been exceeded, any associated time delay has expired, and therefore a warning or fault condition is present.

## Emission trending



This page provides a graphical representation of the relationship between the emissions across full power range of the generator.


The desired values are indicated by the yellow line whilst the actual value is indicated by the green dot.

The DM 400 system will automatically and continuously adjust the appropriate system parameters in order to position the green dot on the yellow line and thus achieve the defined emission setting when the emission control function is active.

## Engine values

The “engine values” button opens up access to a number of other pages relating to present status and protection settings relating to the gas engine itself.

### Emission control diagram



This page presents the following data:

Thr. Pos.	The relative position of the throttle valve (0 % [fully closed] -100 % [fully open])
n Gen	The present measured engine speed (rpm)
Temp A	The present measured temperature of exhaust gas (°C)
pressure	The present measured engine oil pressure (bar)
temp	The present measured engine oil temperature (°C)
temp (out)	The present measured temperature of engine cooling water out to the heat exchanger (°C)
temp (in)	The present measured temperature of engine cooling water return from the heat exchanger (°C)
Starter	An indicator representing the status of the starter where WHITE = off GREEN= status OK RED = fault, alarm or warning condition
Ignition	An indicator representing the status of the ignition unit where the colour indications are as stated above
Pressure	An indicator representing the status of the exhaust gas, either green or red only, where the colour indications are as stated above
Level	An indicator representing the status of the engine cooling water level switch, either green or red only, where the colour indications are as stated above
Flow	An indicator representing the status of the engine cooling water flow switch, either green or red only, where the colour indications are as stated above
Pump	An indicator representing the status of the engine water pump, where the colour indications are as stated above for starter

<b>DEIF</b>		19-11-2014 15:40:39	
<b>EMERGENCY STOP</b>			access level: 0
DM4 IO card data exchange timeout			operation level: 1
Pel	0	kW	engine values
			gas type A

<b>lube oil:</b>  pressure <input type="text" value="v !"/> bar temp <input type="text" value="0"/> °C	<b>cooling water:</b>  level <input checked="" type="radio"/> flow <input checked="" type="radio"/>  temp (in) <input type="text" value="0"/> °C temp (out) <input type="text" value="0"/> °C pump <input type="radio"/>	<b>gas mix:</b>  throttle pos <input type="text" value="-1.0"/> % pos setpoint <input type="text" value="0.0"/> % pressure <input type="text" value="-1000"/> mbar	<input type="button" value="engine diagram"/> <input type="button" value="engine values"/> <input type="button" value="engine protection"/> <input type="button" value="diagnostics cylinders"/>
<b>exhaust:</b>  temp A <input type="text" value="0"/> °C temp exch <input type="text" value="0"/> °C pressure <input checked="" type="radio"/> cold junction <input type="text" value="0"/> °C			
starter <input type="radio"/> ignition <input type="radio"/> PKG <input type="radio"/>	n Gen <input type="text" value="0"/> rpm	reset safety chain <input type="radio"/> trip safety chain <input checked="" type="radio"/>	
<input type="button" value="navigator"/> <input type="button" value="ignition control"/> <input type="button" value="overview"/>			

This page presents the following data:

#### lube oil

pressure The present measured lube oil pressure (bar)  
 temp The present measured lube oil temperature (°C)

#### cooling water

Level An indicator representing the status of the engine cooling water level where  
           GREEN= status OK  
           RED = fault, alarm or warning condition

Flow An indicator representing the status of the engine cooling water flow where the  
       colour indications are as stated above

temp (in) The present measured temperature of engine cooling water return from the heat  
           exchanger (°C)

temp (out) The present measured temperature of engine cooling water out to the heat  
           exchanger (°C)

pump An indicator representing the status of the engine water pump where  
       WHITE = off  
       GREEN= status OK  
       RED = fault, alarm or warning condition


#### gas mix

Thr. Pos. The relative position of the throttle valve (0 % [fully closed] -100 % [fully open])  
 Pos set point The set point for the throttle valve (0 % [fully closed] -100 % [fully open])  
 pressure The present measured pressure of the mixture in the receiver (mbar)

**exhaust**

temp A	The present measured temperature of bank A exhaust temperature (°C)
temp exch	The present measured temperature of exhaust heat exchanger (°C)
cold junction	The present measured temperature of cold junction reference point (°C)
pressure	An indicator representing the status of the exhaust gas pressure where GREEN= status OK RED = fault, alarm or warning condition
starter	An indicator representing the status of the starter where WHITE = off GREEN= status OK RED = fault, alarm or warning condition
ignition	An indicator representing the status of the ignition unit where the colour indications are as stated above
PKG	(if fitted) An indicator representing the status of the amplifier driver for the throttle valve where the colour indications are as stated above
n Gen	The present measured engine speed (rpm)
reset safety chain	An indicator representing the status of the system safety chain reset output where the colour indications are as stated above, green or red only
trip safety chain	An indicator representing the status of the system safety chain trip output where the colour indications are as stated above, green or red only

## Engine protections

		<b>DEIF</b>		19-11-2014 15:40:56	
<b>EMERGENCY STOP</b>				access level: 0	
DM4 IO card data exchange timeout				operation level: 1	
Pel	0	kW	<b>engine protection</b>		gas type A

StopC	Symbol	Limit	Value	State	Timer
50071	sensor defect lube oil pressure			TRIP	
20039	low lube oil level (digital)		N.A.	COLD	
20040	low lube oil pressure	2.5	-327bar	COLD	
50072	lube oil pressure too low while GCB closed	3.0	-327bar	COLD	
20041	high lube oil pressure	9.0	-327bar	COLD	
50117	wire break T208 lube oil temp.			COLD	
20042	lube oil overheated	110	0 °C	COLD	2572 s
60120	LR because oil temperature	105	0 °C	COLD	2572 s
20036	speed input defective or engine still turning			COLD	
20033	start failure	3	0	COLD	
20034	stop failure			COLD	
20035	testmode: starter operation too long			COLD	
70050	pickup signal missing			COLD	
50121	wire break T201 engine cooling water inlet temp.			COLD	
20046	high cooling water temperature engine inlet	95	0 °C	COLD	2572 s
50122	wire break T202 engine cooling water outlet temp.			COLD	
20043	high cooling water temperature engine exit	98	0 °C	COLD	2572 s
60121	LR because water temperature engine exit	92	0 °C	COLD	2572 s
50160	stop: wire break cooling water pressure		N.A.	COLD	
50161	stop: cooling water pressure not in limit		N.A.	COLD	
50162	stop: cooling water pressure too low	0.5	N.A.bar	COLD	
50163	stop: cooling water pressure too high	3.5	N.A.bar	COLD	
70247	cooling water pressure too low	1.0	N.A.bar	COLD	
70248	cooling water pressure too high	3.0	N.A.bar	COLD	

navigator

ignition control

overview

engine diagram

engine values


engine protection

diagnostics cylinders

The engine protection data consists of:

StopC	Stop Condition alarm number
Symbol	Parameter text description
Limit	Parameter limit for the value column
Value	Actual value measured or calculated within the DM 400
State	Current parameter state COLD: not activated HOT: parameter limit has been exceeded and waiting for any associated time delay to expire REC: an auto acknowledge condition has occurred and is now in the process of recovering back to the COLD state TRIP: the parameter limit has been exceeded, any associated time delay has expired and therefore a warning or fault condition is present.
Timer	The duration for which the current state has existed in seconds

## Cylinder temperatures



A graphical representation of:

- Individual cylinder temperatures
- An average of the cylinder temperature
- An indication of the cold junction temperature

## Ignition control


The ignition control pages are accessed from the engine values page and these pages present data concerning one of the possible ignition systems for the gas engine.

The ignition control pages provide data relating to the ignition control system read from that device by the DM 400 and therefore the information shown is for illustration purposes only and may differ from the actual system being operated.



**Ignition control data can only be presented if the ignition control system used within the application permits communication with the DM 400 controller.**

### Ignition Diagram



The data displayed on this page is:

HW: , SW: , timer: This is the hardware and software version and timer reference read from the ignition controller

Then for each cylinder, the following data is displayed:

TIM timing angle (°)  
 S-DUR spark duration (ms)  
 C-DUR charge duration (ms)  
 EGY energy (mJ)

A graphical display of the energy value for each cylinder is also displayed.

## Ignition values

The ignition values page displays values relating to the ignition control system that is read by the DM 400 for the ignition control system.

If it is not possible to communicate with the ignition control system in a particular application, then this data cannot be retrieved or displayed.

<b>DEIF</b>		<b>DEIF</b>		19-11-2014 15:45:22	
<b>EMERGENCY STOP</b>				access level: 0	
DM4 IO card data exchange timeout				operation level: 1	
<b>Pel</b>	<b>0</b>	<b>kW</b>	<b>ignition values</b>		gas type A

Speed: 2000	! 0 rpm	Common Warning: 3799	! 0
Power Supply: 3600	! 0.00 V	Emergency Alarm: 3800	! 0
		Common Alarm: 3801	! 0
		Ignition Stop Request: 3802	! 0
		Engine Stopped: 3803	! 0
		Engine Starting: 3804	! 0
		Engine Running: 3805	! 0
		Ignition Released: 3806	! 0
		Ignition Active: 3807	! 0
		Phase: 3830	! 0

<b>ignition diagram</b>
<b>ignition values</b>
<b>ignition protection</b>
<b>angle adjust</b>

<b>navigator</b>	<b>knocking control</b>	<b>engine values</b>	<b>overview</b>
------------------	-------------------------	----------------------	-----------------

For each value, there is a description and a four digit number.

The four digit number relates to the ignition system parameter allocated to the particular ignition value.

The values shown are the values read back from the ignition control system.


The data which can be retrieved from the ignition control system and therefore displayed on these pages is depending on the capability of the ignition control system itself and so may differ from that shown above.

Ignition protection

The ignition protection page displays values relating to the ignition control system protections that are read by the DM 400 for the ignition control system.

If it is not possible to communicate with the ignition control system in a particular application, then this data cannot be retrieved or displayed.

The data which can be retrieved from the ignition control system and therefore displayed on these pages is depending on the capability of the ignition control system itself.



## Angle adjust

The angle adjust page displays values relating to the timing angle, set for each cylinder, that are read by the DM 400 from the ignition control system.

If it is not possible to communicate with the ignition control system in a particular application, then this data cannot be retrieved or displayed.

The data which can be retrieved from the ignition control system and therefore displayed on these pages is depending on the capability of the ignition control system itself.

DEIF		19-11-2014 15:46:05
<b>EMERGENCY STOP</b>		access level: 0
DM4 IO card data exchange timeout		operation level: 1
Pel	0 kW	gas type A
<b>angle adjust</b>		
ignition offset A1:	0.0 °	0.0 °
ignition offset A2:	0.0 °	0.0 °
ignition offset A3:	0.0 °	0.0 °
ignition offset B1:	0.0 °	0.0 °
ignition offset B2:	0.0 °	0.0 °
ignition offset B3:	0.0 °	0.0 °
reset		
1 angle adjust (AKR)		1
navigator		knocking control
engine values		overview

The data displayed on this page is:

1. Angle adjust (AKR): this parameter is used to indicate if a suitable Anti-Knocking Regulator (AKR) is fitted to the system that will enable the adjustment of ignition timing angles based on input from the AKR device  
0 = this is not permitted  
1 = this is permitted
2. Ignition offset: if the value of the angle adjust (AKR) parameter is 1, then by clicking any of the boxes opens up the keypad input window (as shown previously) through which it is possible to enter a set point for the ignition offset value.
3. The values shown in position 3 are the actual values for the ignition timing read from the ignition control system.

The reset button resets any manually entered offset values immediately to zero.

## Knocking control

The knocking control pages are accessed from the engine values page or the ignition control page, and these pages present data concerning the knocking control system for the gas engine.




**Knocking control data can only be presented if the knocking control system used within the application permits communication with the DM 400 controller.**

### Knocking values pages 1 and 2

The knocking values pages display values relating to the anti-knocking control system that are read by the DM 400.

If it is not possible to communicate with the knocking control system in a particular application, then this data cannot be retrieved or displayed.

The data which can be retrieved from the knocking control system and therefore displayed on these pages is depending on the capability of the knocking control system itself.

		<b>DEIF</b>		19-11-2014 15:46:32
<b>EMERGENCY STOP</b>				access level: 0
DM4 IO card data exchange timeout				operation level: 1
Pel	0	kW	<b>knocking values 1</b>	gas type A

RELEVANT DATA WILL APPEAR  
HERE WHEN COMMUNICATION  
IS ESTABLISHED WITH THE  
KNOCKING CONTROL SYSTEM

knocking values 1

knocking values 2

knocking protection

navigator

ignition control

engine values

overview

## Knocking protection

The knocking protection page displays DM 400 parameters relating to the anti-knocking control system.

<b>DEIF</b>		<b>DEIF</b>		19-11-2014 15:46:46
<b>EMERGENCY STOP</b>				access level: 0
DM4 IO card data exchange timeout				operation level: 1
<b>Pel</b>	<b>0</b>	<b>kW</b>	<b>knocking protection</b>	gas type A

StopC Symbol	Limit Value	State
60126 warning: AKR knock sensor error bank A		COLD
60127 warning: AKR knock sensor error bank B		COLD
60128 warning: AKR speed error		COLD
60129 load reduction due to AKR adjusting too high		COLD
60130 warning: AKR system not configured		COLD
60131 timeout: AKR not ready		COLD
20512 fault: AKR max retard exceeded		COLD
20534 timeout: AKR knock monitoring not active		COLD

knocking values 1

knocking values 2

knocking protection

navigator

ignition control

engine values


overview

The knocking protection data consists of:

StopC	Stop Condition alarm number
Symbol	Parameter text description
Limit	Parameter limit for the value column
Value	Actual value measured or calculated within the DM 400
State	Current parameter state
	COLD: not activated
	HOT: parameter limit has been exceeded and waiting for any associated time delay to expire
	REC: an auto acknowledge condition has occurred and is now in the process of recovering back to the COLD state
	TRIP: the parameter limit has been exceeded, any associated time delay has expired and therefore a warning or fault condition is present.

## Room air ventilation

### Ventilation diagram



This page presents the following data:


Fan                      The set point of the flap position or the fan speed (0 %-100 %)  
 Room temp            The present measured container/enclosure temperature (°C)

Smoke alarm          An indicator representing the status of the smoke alarm where  
                               WHITE = off  
                               GREEN= status OK  
                               RED    = fault, alarm or warning condition



Gas fault              An indicator representing the status of gas fault indicator where the colour  
                               indications are as stated above

Fan stage 1            An indicator representing the status of cooling fan(s) where the colour  
                               indications are as stated above

## Ventilation values

		<b>DEIF</b>		19-11-2014 16:01:23	
<b>EMERGENCY STOP</b>				access level: 0	
DM4 IO card data exchange timeout				operation level: 1	
Pel	0	kW	<b>ventilation values</b>		gas type A

smoke alarm  gas fault 		room temp <input type="text" value="0"/> °C  fan <input type="text" value="0.0"/> %  flap open <input type="radio"/>  fan stage 1 <input type="radio"/>		<div>ventilation diagram</div> <div>ventilation values</div> <div>ventilation protection</div>	
----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--	------------------------------------------------------------------------------------------------	--


  

navigator	electrical values	engine values	overview
-----------	-------------------	---------------	----------

This page presents the following data:

- Smoke alarm    An indicator representing the status of the smoke alarm where  
                     WHITE = off  
                     GREEN= status OK  
                     RED    = fault, alarm or warning condition
- Gas fault        An indicator representing the status of gas fault indicator where the colour  
                     indications are as stated above
- Room temp      The present measured container/enclosure temperature (°C)
- Fan                The set point of the flap position or the fan speed (0 %-100 %)
- Flap open        An indicator representing the status ventilation flap where the colour indications  
                     are as stated above
- Fan stage 1      An indicator representing the status of cooling fan(s) where the colour  
                     indications are as stated above

## Ventilation protections

		<b>DEIF</b>		19-11-2014 16:01:36	
<b>EMERGENCY STOP</b>				access level: 0	
DM4 IO card data exchange timeout				operation level: 1	
Pel	0	kW	<b>ventilation protection</b>		gas type A

StopC Symbol	Limit Value	State	Timer
20045 timeout gasalarm stage 1		COLD	
70257 gas alarm stage 1		COLD	
70245 room air too hot	55 0.0 °C	COLD	3813 s
70204 wire break room temperature sensor		COLD	
60026 room air temperature limiter		TRIP	

StopC Symbol

Limit Value

State

Timer

**ventilation diagram**

**ventilation values**

**ventilation protection**

navigator

electrical values

engine values

overview

The ventiation protection data consists of:

StopC	Stop Condition alarm number
Symbol	Parameter text description
Limit	Parameter limit for the value column
Value	Actual value measured or calculated within the DM 400
State	Current parameter state
	COLD: not activated
	HOT: parameter limit has been exceeded and waiting for any associated time delay to expire
	REC: an auto acknowledge condition has occurred and is now in the process of recovering back to the COLD state
	TRIP: the parameter limit has been exceeded, any associated time delay has expired and therefore a warning or fault condition is present.
Timer	The duration for which the current state has existed in seconds


## Test of auxiliaries



The auxiliaries test functionality is designed only for use during commissioning and for diagnostics purposes. The pages and functions within this section are not intended for use by an untrained operator and are therefore intentionally omitted from this manual. Consequently, no descriptions are provided.

## Lube oil system

### Lube oil diagram



This page presents the following data:

fresh oil tank: the value read from the fresh oil tank sender  
 oil tank pump: the status of the pump for adding fresh oil to the engine  
 waste oil tank: the value read from the waste oil tank sender

Lube oil values

DEIF

DEIF

19-11-2014  
16:03:44

EMERGENCY STOP

access level: 0

DM4 IO card data exchange timeout

operation level: 1

Pel

0

kW

lube oil values

gas type A

RELEVANT DATA WILL APPEAR  
HERE WHEN CONNECTION IS  
ESTABLISHED WITH THE LUBE  
OIL SYSTEM

lube oil  
diagram

lube oil  
values

lube oil  
protection

navigator

electrical  
values

engine  
values

overview

## Lube oil protection

<b>DEIF</b>		<b>DEIF</b>		19-11-2014 16:04:03
<b>EMERGENCY STOP</b>				access level: 0
DM4 IO card data exchange timeout				operation level: 1
<b>Pel</b>	<b>0</b>	<b>kW</b>	<b>lube oil protection</b>	gas type A

StopC Symbol	Limit Value	State
20038 low lube oil level (analog)	20 N.A. %	COLD
20039 low lube oil level (digital)	N.A.	COLD
50089 sensor defect lube oil level (analog)	N.A.	COLD
50090 lube oil level max (analog)	90 N.A. %	COLD
50091 lube oil level max (digital)	N.A.	COLD

**navigator**

**electrical values**

**engine values**

**overview**

**lube oil diagram**

**lube oil values**


**lube oil protection**

The lube oil protection data consists of:

StopC	Stop Condition alarm number
Symbol	Parameter text description
Limit	Parameter limit for the value column
Value	Actual value measured or calculated within the DM 400
State	Current parameter state
	COLD: not activated
	HOT: parameter limit has been exceeded and waiting for any associated time delay to expire
	REC: an auto acknowledge condition has occurred and is now in the process of recovering back to the COLD state
	TRIP: the parameter limit has been exceeded, any associated time delay has expired and therefore a warning or fault condition is present.

## Heating system

### Heating system diagram



The heating system shows relevant values measured at various points of the heating/cooling circuit and also shows the status of pumps and visual status indicators of temperature values where a GREEN indicator confirms that the temperature values at the specified points are acceptable and a RED indicator advises that the temperature is out of the specified limits.



**Note that the heating system diagram automatically updates, based on the parameter options selected.**

**Consequently, the diagram above is shown for illustration purposes, and the actual diagram displayed will be system-specific.**

## Heating water values

<b>DEIF</b>		<b>DEIF</b>		20-01-2015 18:33:35
<b>EMERGENCY STOP</b>				access level: 0
reboot necessary				operation level: 1
Pel	0	kW	heating water values	
				gas type A

<b>engine circuit:</b> T eng in <input type="text" value="0"/> °C T eng ex <input type="text" value="^!"/> °C  p engine <input type="checkbox"/> preheat <input type="checkbox"/>	<b>heating circuit:</b> T return <input type="text" value="0"/> °C T em.c <input type="text" value="0"/> °C T HK->MK <input type="text" value="^!"/> °C T after AWT <input type="text" value="0"/> °C T heating <input type="text" value="0"/> °C heat pos <input type="text" value="0.0"/> %  heat OK <input checked="" type="checkbox"/> pump <input type="checkbox"/>	<b>emergency cooler:</b> em.c pos <input type="text" value="0.0"/> %  em.c OK <input checked="" type="checkbox"/> em.stage1 <input type="checkbox"/> em.stage2 <input type="checkbox"/> em.stage3 <input type="checkbox"/>	<b>intercooler:</b> T ic <input type="text" value="^!"/> °C ic pos <input type="text" value="0.0"/> %  ic OK <input checked="" type="checkbox"/> ic stage1 <input type="checkbox"/> ic stage2 <input type="checkbox"/> ic stage3 <input type="checkbox"/>	<input type="button" value="heating diagram"/> <input type="button" value="heating values"/> <input type="button" value="heating protection"/> <input type="button" value="heating counters"/>
fault auxiliaries <input checked="" type="checkbox"/>				

navigator	electrical values	engine values	overview
-----------	-------------------	---------------	----------

This page presents the heating and cooling circuit data and is shown for illustration purposes. The actual data displayed is system-specific based on the parameter options selected. Consequently, the actual data shown may differ from that shown above.

All measured values are displayed with text identifier and unit of measure.

An indicator representing the status of the equipment is also displayed where

WHITE = off  
 GREEN= status OK  
 RED = fault, alarm or warning condition

## Heating water protection

<b>DEIF</b>		<b>DEIF</b>		19-11-2014 16:05:07	
<b>EMERGENCY STOP</b>				access level: 0	
DM4 IO card data exchange timeout				operation level: 1	
Pel	0	kW	heating water protection		gas type A

StopC Symbol	Limit Value	State	Timer
emergency valve stage 2	70 0.0 %	COLD	4024 s
emergency valve stage 3	85 0.0 %	COLD	4024 s
60040 fault emergency cooler (G313)	N.A.	COLD	
60041 heating water after emergency cooler too cold	2 N.A. °C	COLD	4024 s
50035 low water level intercooler	N.A.	COLD	
10205 low water level heating circuit		TRIP	
70208 heating water flow temperature too high	95 0 °C	COLD	4024 s
70211 wirebreak T302 heating water temperature flow		COLD	
70261 short circuit PT100 heating water temperature flow		COLD	
70264 wire break PT100 after AWT		COLD	
70263 short circuit PT100 after AWT		COLD	
70265 over temp. heating water after AWT	102 0.0 °C	COLD	
70210 wirebreak T300 heating water temperature return		COLD	
70260 short circuit PT100 heating water temperature return		COLD	

navigator	electrical values	engine values	overview
-----------	-------------------	---------------	----------

The heating water protection data consists of:

StopC	Stop Condition alarm number
Symbol	Parameter text description
Limit	Parameter limit for the value column
Value	Actual value measured or calculated within the DM 400
State	Current parameter state
	COLD: not activated
	HOT: parameter limit has been exceeded and waiting for any associated time delay to expire
	REC: an auto acknowledge condition has occurred and is now in the process of recovering back to the COLD state
	TRIP: the parameter limit has been exceeded, any associated time delay has expired and therefore a warning or fault condition is present.
Timer	The duration for which the current state has existed in seconds

## Heat counters

<b>DEIF</b>		<b>DEIF</b>		19-11-2014 16:05:20	
<b>EMERGENCY STOP</b>				access level: 0	
DM4 IO card data exchange timeout				operation level: 1	
Pel	0	kW	heat counters		gas type A

<b>heating circuit:</b>					
HK water temp. flow	0	°C			
HK water temp. return	0	°C			
Delta T	0	K			
	<b>counter value</b>	<b>day</b>	<b>month</b>	<b>year</b>	<b>unit</b>
heat generated	0	0	0	0	kWh
heat consumed	0	kWh			

<b>heating diagram</b>
<b>heating values</b>
<b>heating protection</b>
<b>heating counters</b>

<b>navigator</b>	<b>electrical values</b>	<b>engine values</b>	<b>overview</b>
------------------	--------------------------	----------------------	-----------------

This page displays the following data:

HK Water Temp Flow: heating circuit water temperature flow (out of CHP system) (°C)

HK Water Temp Return: heating circuit water temperature return (back to CHP system) (°C)

Also displayed on this page are the counters for the generated heat energy and a value for the heat energy consumed.

The heat-generated counter displays


- a total heat value generated by the system
- for the current day
- for the current month and
- for the current year

The heat consumed counter displays

- a total heat value consumed by the system

## Gas/exhaust system

### Gas diagram




This page presents the gas supply system data and is shown for illustration purposes. The actual data displayed is system-specific based on the parameter options selected. Consequently, the actual data shown may differ from that shown above.

All measured values are displayed with text identifier and unit of measure.

An indicator representing the status of the equipment is also displayed where

WHITE = off  
 GREEN = status OK  
 RED = fault, alarm or warning condition

## Exhaust diagram



This page presents the exhaust system data and is shown for illustration purposes. The actual data displayed is system-specific based on the parameter options selected. Consequently, the actual data shown may differ from that shown above.

All measured values are displayed with text identifier and unit of measure.

An indicator representing the status of the equipment is also displayed where

WHITE = off

GREEN = status OK

RED = fault, alarm or warning condition

## Gas and exhaust values

<b>DEIF</b>		<b>DEIF</b>		20-01-2015 18:54:33	
<b>EMERGENCY STOP</b>				access level: 0	
reboot necessary				operation level: 1	
Pel	0	kW	gas / exhaust values		gas type A

<b>gas:</b>  level A <input type="text" value="v !"/> %  CH4 value <input type="text" value="0"/> % gas type (act) <input type="text" value="A"/> gas type (sel) <input type="text" value="A"/>  p (compr) <span style="color: red;">●</span> compressor <input type="radio"/> T (compr) <span style="color: red;">●</span>  T gas A <span style="color: red;">●</span> leak ctrl A <input type="radio"/> lc A on <input type="radio"/> press. A <span style="color: red;">●</span> valve gas A <input type="radio"/>		<b>exhaust:</b>  T exh A <input type="text" value="0"/> °C T exh B <input type="text" value="0"/> °C  T exh aC <input type="text" value="0"/> °C T exh exch <input type="text" value="0"/> °C  p exh <span style="color: red;">●</span> close bypass <input type="radio"/>	<input type="button" value="gas diagram"/> <input type="button" value="exhaust diagram"/> <input type="button" value="gas/exhaust values"/> <input type="button" value="gas/exhaust protection"/>
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>navigator</b>	<b>electrical values</b>	<b>engine values</b>	<b>overview</b>
------------------	--------------------------	----------------------	-----------------

This page presents the combined data from the gas supply and exhaust systems and is shown for illustration purposes.

The actual data displayed is system-specific based on the parameter options selected. Consequently, the actual data shown may differ from that shown above.

All measured values are displayed with text identifier and unit of measure.

An indicator representing the status of the equipment is also displayed where

WHITE = off

GREEN= status OK

RED = fault, alarm or warning condition

## Gas and exhaust protections

<b>DEIF</b>		<b>DEIF</b>		20-01-2015 18:55:06	
<b>EMERGENCY STOP</b>				access level: 0	
reboot necessary				operation level: 1	
Pel	0	kW	gas / exhaust protection		gas type A

StopC Symbol	Limit Value	State	Timer
10213 gas alarm		TRIP	
10215 gas temperature line A		TRIP	
10216 gas temperature line B		TRIP	
20507 gas leakage check failed		COLD	
20508 gas pressure controller before compressor		TRIP	
20509 gas temperature controller before compressor		TRIP	
20012 gas pressure line A		COLD	
20010 gas pressure line B		TRIP	
70257 gas alarm stage 1		TRIP	
70258 gas detector device fault		TRIP	
20044 exhaust back pressure too high		TRIP	
50152 stop: exhaust temp. before catalyst too hot	700 N.A. °C	COLD	2639 s
50153 stop: exhaust temp. after catalyst too hot	700 0 °C	COLD	2639 s
50154 stop: exhaust temp. after engine A too hot	700 0 °C	COLD	2639 s
50155 stop: exhaust temp. after engine B too hot	700 0 °C	COLD	2639 s
50156 stop: exhaust temp. after heat exchanger too hot	700 0 °C	COLD	2639 s
50093 stop because of gas level too low	50 -327%	TRIP	2637 s
70152 warning: exhaust temp. before catalyst too hot	650 N.A. °C	COLD	
70153 warning: exhaust temp. after catalyst too hot	650 0	COLD	
70154 warning: exhaust temp. after engine A too hot	650 0	COLD	
70155 warning: exhaust temp. after engine B too hot	650 0	COLD	
70156 warning: exhaust temp. after heat exchanger too hot	650 0	COLD	

navigator	electrical values	engine values	overview
-----------	-------------------	---------------	----------

The gas and exhaust protection data consists of:


StopC	Stop Condition alarm number
Symbol	Parameter text description
Limit	Parameter limit for the value column
Value	Actual value measured or calculated within the DM 400
State	Current parameter state
	COLD: not activated
	HOT: parameter limit has been exceeded and waiting for any associated time delay to expire
	REC: an auto acknowledge condition has occurred and is now in the process of recovering back to the COLD state
	TRIP: the parameter limit has been exceeded, any associated time delay has expired and therefore a warning or fault condition is present.
Timer	The duration for which the current state has existed in seconds

## Parameters

Parameters are variable settings that define the limits and the functionality of the overall DM 400 system. Parameters are set relative to the specific requirements of each system and thus the values shown in the following pages are for illustration purposes only.

Access to the system parameters is made via the navigator page.

With the “parameters” button (on the navigator page), the “parameter selection” page is displayed, which makes it possible to view all variable parameters and adapt them as necessary.

		<b>DEIF</b>		02-01-2014 09:53:29
<b>READY TO START</b>				access level: 2
operation stopped				operation level: 5
Pel	0	kW	<b>parameter selection</b>	gas type A

mains protection 1	emergency cooling circuits	passwords
mains protection 2	heating circuit	system configuration
generator protection 1	intercooler circuit	standby power operation
generator protection 2	engine cooling circuit	modbus
engine configuration	power management	I/O assignments
generator configuration	exhaust bypass	I/O assignments (RED)
circuit breaker	exhaust system	turbo bypass
speed control	lube oil system	TecJet
synchronization	air ventilation system	reserve
ignition / knocking control	load reduction	reserve
volt/var control	maintenance	messages 1-12
gas mixer control	parameterizable counters and regulators	messages 13-24
gas line	CH4 control	messages 25-30
gas compressor	peak shaving / heat control	counters
gas tight control	gas level control	project parameters

<b>navigator</b>	<b>electrical values</b>	<b>engine values</b>	<b>overview</b>
------------------	--------------------------	----------------------	-----------------

### Parameter numbers

Each parameter has a unique number which is used to identify the parameter and is displayed in the parameters editor page and also entered into the parameter log book when changed.

### Permission level

Each parameter is assigned with a minimum permission level required to change that value. Only users who have logged on with the required permission level (or higher) can change that parameter.

### Parameter list

All parameters available within the standard DM 400 software can be found in the DM 400 software parameter list document. This document is adapted to the project in question and is delivered with the Delomatic 400.

This document provides information relating to each individual parameter then, after logging on, select the parameter and the parameter editor will display the parameter number and this can be located in the parameter list documentation.


## Define password/parameters editor

With a new system, it is possible to log in as an operator (access level 1) or service technician (access level 2) without a password, until the respective password has been defined.

As long as a password has not been defined and saved as a parameter, logging in is possible by simply clicking the access level 1 or access level 2 buttons; in other words, the system is not protected from unauthorised parameter changes.

It is normal that the passwords are set during the commissioning procedure to ensure that the system is properly protected.

The passwords can only be defined or redefined if the operator is logged in with at least the appropriate permission level.

		<b>DEIF</b>		02-01-2014 09:54:04
<b>READY TO START</b>				access level: 0
operation stopped				operation level: 5
Pel	0	kW	<b>passwords</b>	gas type A

password definition:

access level 1

access level 2

<b>navigator</b>	<b>previous page</b>	<b>next page</b>	<b>parameter selection</b>
------------------	----------------------	------------------	----------------------------

If, for example, the operator is logged in with access level 1, then only the access level 1 password can be changed, not the access level 2 password. Access level 3 is reserved for DEIF and cannot be reset.

By clicking the button for define password (access level 1 or access level 2), the parameters editor is activated. This enables the definition of a password in the permissible range between 1000 and 9999.

It is **very important** that the **password** entered is **recorded and kept in a secure yet retrievable location**.

### Password parameter editor

<b>DEIF</b>		<b>DEIF</b>		21-01-2015 10:59:16
<b>EMERGENCY STOP</b>				access level: 2
<b>reboot necessary</b>				operation level: 1
<b>PeI</b>	<b>0</b>	<b>kW</b>	<b>passwords</b>	gas type A

password definition:

access level 1

access level 2

access level 1

**+0**

MIN **+1000**

MAX **+9999**

DEFAULT **+0**

7	8	9	←
4	5	6	AC
1	2	3	Enter
0	+ -	,	

Factory setting for the passwords:

Level 1: 1111

Level 2: 2222

Use the parameter editor in the standard way as previously defined.

## Project parameters

The project parameters page is accessed via the parameter selection page.

<b>DEIF</b>		21-01-2015 11:46:44	
<b>EMERGENCY STOP</b>			access level: 2
reboot necessary			operation level: 1
<b>PeI</b>	<b>0</b>	<b>kW</b>	<b>project parameters</b>
			gas type A

factory setting

XXX

project name

DEIF

SMS message

SMS option

0

PIN number

phone number

auto start/stop

0

start at

0 h

0 min

stop at

0 h

0 min

navigator

previous page

parameter selection

The page displays the following data:

Factory setting	A password-protected function which will restore all PARAMETER values back to their factory default settings.
Project name	The name under which the data will be saved on the hard drive of the touchpanel PC HMI and the wording that will appear at the top of every display page
SMS option	0 = disabled; 1 = enabled
Pin number	For the SIM card used
Phone number	For the SIM card used
Auto start/stop	Option to allow the unit to auto start/stop within defined time periods. 0 = disabled; 1 = enabled
Start at	Hours value for start time setting (range 0-23 h) Minute value for start time setting (range 0-59 minutes)
Stop at	Hours value for stop time setting (range 0-23 h) Minute value for start time setting (range 0-59 minutes)

## 7. Statuses and messages

The current primary status of the plant is displayed on the user interface at all times.

The sub-condition information and error messages are also shown at all times directly below the primary status.

If the text of the sub-condition is red, this indicates either a stop condition or pending error message relating to a fault condition.

The highest priority fault condition error message is always shown here.

When this fault condition shown is cleared, the next highest priority fault condition (if there is one) is displayed.



### Error messages

Every error message defined in the system by an alarm number along with descriptive text.

“Current alarms” can be viewed at any time with the navigator button, and these alarms can also be acknowledged on this page.

The first digit of the alarm number indicates the operating level of the error message.

The highest priority fault condition is shown in the sub-condition field of the HMI display.

Higher level fault conditions must be acknowledged by the user before the system will allow the operation to commence.

It is possible to classify lower level fault conditions as “auto acknowledge”. This means that the error message will be automatically acknowledged, and the message will be cleared whenever the fault condition is no longer present.

It is not possible to acknowledge and clear an error message if the fault condition still exists.

The fault condition must be removed and then the error message acknowledged before the system operation will continue.

## Primary statuses

The following primary statuses are possible:

Primary status - text	Comments
<b>SYSTEM BOOT</b>	DM 400 main boot
<b>SYSTEM START</b>	DM 400 system start
<b>EMERGENCY STOP</b>	Emergency stop condition exists, and engine is stopped
<b>EMERGENCY BRAKING</b>	An emergency stop condition exists, and the engine is stopping
<b>REARM SAFETY CHAIN</b>	Rearm the safety chain
<b>START BLOCKED</b>	System is blocked from restarting due to a fault condition
<b>READY TO START</b>	System is ready to start
<b>STOPPING</b>	Engine is stopping under a normal stop condition
<b>START PREPARATION</b>	Starting sequence has been initiated
<b>CRANKING</b>	Engine has been given the signal to crank
<b>IGNITION</b>	Ignition system has been enabled
<b>OPEN GAS VALVES</b>	Gas valves have been given signal to open
<b>ACCELERATION</b>	Engine is running and is accelerating to nominal speed
<b>IDLE RUNNING</b>	Engine is running at nominal speed. Generator breaker is open
<b>SYNCHRONISING</b>	Voltage and frequency are being adjusted to match mains/busbar voltage. Generator breaker is open
<b>LIMITED LOAD</b>	Generator breaker is closed and the generator is operating at reduced load for warming up
<b>GRID PARALLEL OPERATION</b>	Generator breaker is closed, and generator is operating in parallel to the grid at nominal power output.
<b>OPEN BREAKER</b>	Signal sent to open breaker
<b>COOLDOWN</b>	Generator breaker is open, and the engine is in a cool down period before stopping
<b>TEST OPERATION</b>	Running in test mode
<b>CLOSE BREAKER (ISLAND)</b>	Signal sent to close generator breaker in island mode
<b>ISLAND OPERATION</b>	Generator breaker is closed, and generator is operating in island mode at nominal power output
<b>BACK SYNCHRONISING</b>	Voltage and frequency are being adjusted to match mains voltage. Mains breaker is open.
<b>OPEN MAINS BREAKER</b>	Signal sent to open mains breaker
<b>LOADSHARING RAMP UP</b>	Power output is being increased in order to join load sharing

---

Primary status - text	Comments
<b>LOADSHARING</b>	<b>Load sharing mode at nominal value</b>
<b>LOADSHARING RAMP DOWN</b>	<b>Power output is being decreased in order to leave load sharing</b>
<b>UNDEFINED BREAKER POSITION</b>	<b>Breaker feedback has been lost, and the system cannot be certain of the position of the breaker that is being operated</b>
<b>BLACK OPERATION</b>	<b>System operating under a loss of mains condition</b>
<b>MAINS OPERATION</b>	<b>System operating with mains present</b>
<b>WAIT FOR BLACKOUT CLOSING</b>	<b>System is waiting for release information from other power producing units within the island group</b>

## Sub-conditions

The following sub-conditions can arise:

Sub-condition – text	Comments
<b>Opening air flaps</b>	Ventilation flaps have been given signal to open
<b>Closing air flaps</b>	Ventilation flaps have been given signal to close
<b>Opening exhaust flap</b>	Exhaust flaps have been given signal to open
<b>Closing exhaust flaps</b>	Exhaust flaps have been given signal to close
<b>Flushing</b>	Engine is being flushed of gas remaining from previous run
<b>Stop time</b>	Waiting for the stop timers to expire
<b>Starter on</b>	Starter has been enabled
<b>Starter pause</b>	Start sequence has been temporarily paused
<b>Engine running</b>	Engine running feedback has been received
<b>Adjusting voltage</b>	Voltage output is being adjusted
<b>Adjusting frequency</b>	Frequency output is being adjusted
<b>Island operation</b>	Generator is running in island mode
<b>Adjusting real power</b>	Real power output is being adjusted
<b>Load reduction operation</b>	System is completing a load reduction instruction
<b>Deloading for cut out</b>	System is reducing power output prior to opening the generator breaker
<b>Interval prelubrication</b>	System is completing a scheduled engine lubrication process, and starting is blocked until process is completed
<b>Start prelubrication</b>	System is completing a pre-start engine lubrication process, and starting is blocked until process is completed
<b>Post lubrication</b>	System is completing a post-run engine lubrication process, and starting is blocked until process is completed
<b>Gas mixer in configuration</b>	The operator has disabled automatic regulation of the gas mixer (normally for testing purposes), and this will remain disabled until the operator exits the testing mode.

## Operating levels

There are alarms which make it necessary to stop and/or block the continued operation of the plant until the fault condition is removed or an alarm can simply show a warning message.

If the alarm type is more serious than a warning and requires the engine to be stopped, then there is an additional level of attribute which will indicate if an immediate stop or a controlled stop of the engine is required.

If the fault condition has caused the engine to stop (whether immediately or via a controlled stop), the engine will be blocked from restarting until the fault condition has been cleared and the alarm has been acknowledged.

Operating Level	Level description	Comments
<b>0</b>	System boot, system start	System tries to start. No further action is possible until this has been achieved. All outputs are 0.
<b>1</b>	Emergency stop	An emergency stop condition has occurred and has not been cleared. All outputs are 0.
<b>2</b>	Standstill	Auxiliary units can operate, engine is stopped, starter off, start sequence is possible
<b>3</b>	Idle run	Auxiliary units, generator and engine are operating. Voltage and frequency are at nominal values. Generator breaker close operation is blocked
<b>4</b>	Voltage and frequency adjustment	Auxiliary units, generator and engine are operating. Voltage and frequency are being adjusted to nominal values (island mode) or for synchronisation (grid parallel operation mode) prior to generator breaker close operation. Generator breaker is open.
<b>5</b>	Power output increase	Auxiliary units, generator and engine are operating. Voltage and frequency have been adjusted to nominal values (island mode) or are synchronised (grid parallel operation mode). Generator breaker is closed. Power output is being increased to nominal power operating conditions (power ramp up).
<b>6</b>	Power output reduction	Auxiliary units, generator and engine are operating. Parallel or island mode operation (as applicable). Generator breaker is closed. Reduced power operating conditions exist.
<b>7</b>	Normal operation	Auxiliary units, generator and engine are operating. Normal (or island – if applicable) mode operation. Generator breaker is closed. Nominal power operating conditions. Warning messages may occur without the unit stopping.
<b>8</b>	Full operation	Auxiliary units, generator and engine are operating. Normal (or island – if applicable) mode operation. Generator breaker is closed. Nominal power operating conditions. No warning messages active.

## List of error messages

A summary of the possible alarm numbers and error messages can be downloaded from the system using the DEIF DM 400 configuration software tool.

## Inputs and outputs

The inputs and outputs available from the DM 400 Gas system fall into one of three categories, which are:

- a number of permanently configured inputs and outputs
- a number of pre-programmed project-specific inputs and outputs
- a number of freely configurable inputs and outputs

Even though many units are delivered with the standard software to which this manual relates, it is still possible to have project-specific inputs and outputs assigned prior to delivery. As a consequence of this, the operator should refer to the I/O assignment created specifically for their project.