

ASC 150 Storage

Designer's handbook



Improve
Tomorrow



1. Introduction

1.1 About ASC 150 Storage	9
1.1.1 Controller types	9
1.2 Terms and abbreviations	10
1.3 About the Designer's handbook	12
1.3.1 Software version	14
1.4 Warnings and safety	14
1.5 Legal information	15

2. Utility software

2.1 Download the utility software	16
2.2 Connection	16
2.2.1 USB connection	16
2.2.2 TCP connection	17
2.3 Using NTP	18
2.4 Utility software interface	19
2.4.1 Top toolbar	19
2.4.2 Left menu	20
2.5 Set up applications	21
2.6 Emulation	21

3. Communication

3.1 Overview	25
3.2 Battery/Storage controller communication	26
3.2.1 Modbus client and Modbus server	26
3.3 Hardware settings	27
3.3.1 RS-485	27
3.3.2 CAN bus	27
3.3.3 ESS Modbus TCP/IP settings	27
3.3.4 Ethernet	28
3.4 Protocol parameters	28
3.4.1 ESS parameters	28
3.4.2 BMS parameters	29
3.4.3 PDS parameters	30
3.4.4 Power meter parameters	30
3.4.5 Configurable power meter	30
3.5 Troubleshooting	32
3.6 Remote monitoring	32
3.6.1 Monitoring solutions	32
3.6.2 Modbus server TCP connection	32
3.6.3 DEIF remote monitoring	33
3.6.4 ESS values	33

4. Single-controller applications

4.1 Single controller	34
4.2 Modes of operation	34
4.2.1 Off-grid applications	34
4.2.2 Grid-tied applications	34
4.3 Setup of a single controller application	35
4.3.1 Application setup using the display	35
4.3.2 Application setup using the utility software	36

4.4 Breaker control	37
4.5 Power measurements and connection status	38
4.5.1 Power meters and genset controllers	39
4.5.2 Genset power measurement from power meter communication	39
4.5.3 Mains power measurement from power meter communication	40
4.5.4 DEIF open communication	41
4.5.5 Measurement transducers for genset power	42
4.5.6 Measurement transducers for mains power	42
4.5.7 Power meter monitoring	43
4.6 Genset applications	45
4.6.1 Gensets and single storage controller (off-grid)	45
4.6.2 Start and stop external gensets	45
4.6.3 State of charge genset control	46
4.6.4 Split busbar	47
4.7 Mains applications	49
4.7.1 Mains and single storage controller (grid-tied)	49
4.7.2 Mains power measurement	49
4.7.3 Mains breaker handling in single controller applications	50
4.8 Combination (off-grid + grid-tied)	50
5. Energy management systems	
5.1 Overview	52
5.2 Power management applications	53
5.2.1 Power management operation	53
5.2.2 System limitations	53
5.2.3 Off-grid applications	54
5.2.3.1 Off-grid with solar and battery	54
5.2.3.2 Off-grid with genset(s) and battery	55
5.2.3.3 Off-grid with genset(s), solar and battery	56
5.2.4 Grid-tied applications	57
5.2.4.1 Grid-tied battery	57
5.2.4.2 Grid-tied genset-battery	58
5.2.4.3 Grid-tied solar-battery	59
5.2.4.4 Grid-tied solar-genset-battery	60
5.2.4.5 Multi-mains with battery	61
5.2.5 Combination (off-grid + grid-tied)	62
5.3 Configure power management	63
5.3.1 Power management communication	63
5.3.1.1 CAN connections	63
5.3.1.2 Using Ethernet for power management	63
5.3.2 Easy connect	63
5.3.3 Using utility software to create the application	67
5.3.3.1 Controller IDs	67
5.3.3.2 Application configuration	67
5.4 Power management functions	71
5.4.1 ESS power reference	71
5.4.2 Spinning reserve	72
5.4.2.1 Alarms for spinning reserve	74
5.4.3 Default load sharing in multi-battery applications	75
5.4.4 SOC balancing in multi-battery applications	75

5.4.5 ESS is the isochronous source.....	78
5.4.6 Genset management.....	78
5.4.6.1 Genset load-dependent start and stop.....	78
5.4.6.2 Genset set points (kW).....	79
5.4.7 Ground relay.....	79
5.5 More power management communication.....	81
5.5.1 CAN flags (M-Logic).....	81
5.5.2 CAN bus setup.....	82
5.5.3 CAN failure mode.....	82
5.5.4 CAN bus alarms.....	83
6. Open PMS applications	
6.1 Open PMS.....	85
6.2 Single-line application diagrams for open PMS.....	86
6.2.1 Off-grid open PMS	86
6.2.2 Grid-tied open PMS	87
6.3 Setup of an open PMS application.....	89
6.3.1 Open PMS parameters in battery/storage and solar controllers.....	92
6.3.2 Using external gensets.....	93
6.3.3 Start and stop external gensets.....	94
6.3.4 Starting external gensets connected to other controllers.....	95
6.3.5 Using an external mains.....	96
6.3.6 Using a mains controller.....	98
6.4 Open PMS in operation.....	99
7. Battery functions	
7.1 Managing charging and discharging.....	101
7.1.1 State of charge.....	101
7.1.2 Charging the ESS.....	102
7.1.3 Discharging from the ESS.....	103
7.1.4 Force charging/discharging.....	104
7.1.5 Freeze charging/discharging.....	104
7.1.6 Maintenance charge.....	104
7.1.7 System power genset control.....	105
7.2 Battery leading or assisting operation.....	106
7.2.1 Battery leading operation.....	106
7.2.2 Battery assisting operation.....	106
7.2.3 Battery leading or assisting parameter.....	107
7.2.4 ESS black busbar start.....	107
7.2.5 ESS as the only energy source.....	107
7.3 ESS charging source.....	107
7.3.1 Charging from PV.....	107
7.3.2 Charging from gensets.....	108
7.3.3 Genset minimum load.....	108
7.3.4 Genset optimum load.....	109
7.3.5 Charging from mains.....	110
7.4 Grid-forming or grid-following.....	111
7.4.1 Battery droop (VSG).....	111
7.4.2 Setting the mode.....	112
7.5 AC- or DC-coupled.....	112
7.5.1 AC-coupled connections.....	112

7.5.2 DC-coupled connections.....	113
7.5.3 AC- or DC-coupled parameter.....	113
7.5.4 PDS spinning reserve.....	113
7.6 Using nominal settings.....	114
7.6.1 Setting the nominal apparent power (S).....	114
7.6.2 Setting the nominal reactive power (Q).....	114
7.6.3 Setting the nominal power (P).....	114
7.7 Flowcharts.....	114
7.7.1 Functions.....	114
7.7.2 Start sequence.....	115
7.7.3 Stop sequence.....	116
7.8 Modes of operation.....	116
7.8.1 ESS operation.....	116
7.8.2 Island operation.....	117
7.8.3 Peak shaving.....	119
7.8.4 Mains power export.....	121
7.8.5 Automatic mains failure.....	122
7.9 Regulation.....	124
7.9.1 ESS power reference.....	124
7.9.2 Voltage reference.....	125
7.9.3 Frequency reference.....	126
7.9.4 Reactive power (kvar).....	126
7.9.5 Peak shaving charging limit.....	127
7.9.6 External set point control.....	128
7.9.7 Hotel load.....	128
7.9.8 Load ramps.....	129
7.9.9 Heartbeat.....	130
7.9.10 Droop deadband for the ESS.....	131
7.10 Fail class.....	131
7.10.1 Energy storage system running.....	131
7.10.2 Energy storage system stopped.....	132
7.11 Alarm inhibit.....	132
7.12 Mode overview.....	132
7.12.1 MANUAL mode.....	132
7.12.2 Not in AUTO mode.....	133
7.13 ESS power measurements.....	133
7.13.1 ESS meter.....	134
7.14 Breaker control.....	135
7.14.1 Energy storage breaker control.....	135
7.14.2 No ESS breaker control.....	135
7.14.3 No mains breaker control.....	135
7.15 Monitoring the ESS.....	136
7.15.1 ESS data.....	136
7.15.2 ESS labels.....	136
7.15.3 State of health.....	137
7.15.4 Run status alarm.....	137
7.15.5 Running output.....	138
7.16 Command schedulers.....	138
7.17 M-Logic.....	140
7.18 Additional functions.....	140

7.18.1 Electrical data monitoring.....	140
7.18.2 Allow PCS to inhibit MB, TB, or ESB opening.....	140
7.18.3 Unsupported application alarm.....	141
8. General functions	
8.1 Introduction.....	142
8.2 Password.....	142
8.3 AC measurement systems.....	143
8.3.1 Three-phase system.....	143
8.3.2 Split-phase system.....	144
8.3.3 Single-phase system.....	144
8.3.4 AC measurement averaging.....	145
8.4 Nominal settings.....	146
8.4.1 Default nominal settings.....	147
8.4.2 Scaling.....	148
8.5 Step-up and step-down transformers.....	148
8.5.1 Step-up transformer.....	148
8.5.2 Vector group for step-up transformer.....	149
8.5.3 Setup of step-up and measurement transformers.....	152
8.5.4 Vector group for step-down transformer.....	153
8.5.5 Setup of step-down and measurement transformers.....	153
8.6 Breakers.....	155
8.6.1 Breaker types.....	155
8.6.2 Breaker spring load time.....	155
8.6.3 Breaker position failure.....	156
8.6.4 Breaker sync function.....	156
8.7 M-Logic.....	156
8.7.1 General shortcuts.....	157
8.7.2 Oneshots.....	157
8.7.3 M-Logic.....	158
8.8 Timers and counters.....	158
8.8.1 Command timers.....	158
8.8.2 USW counters.....	158
8.9 Interfaces.....	159
8.9.1 Additional operator panel, AOP-2.....	159
8.9.2 Access lock.....	160
8.9.3 Language selection.....	161
8.10 RRCR external set point control.....	161
9. AC protections	
9.1 About protections.....	162
9.1.1 Protections in general.....	162
9.1.2 Phase-neutral voltage trip.....	162
9.1.3 Phase sequence error and phase rotation.....	163
9.1.4 4th current transformer input.....	163
9.2 ESS protections.....	164
9.2.1 Over-voltage (ANSI 59).....	165
9.2.2 Under-voltage (ANSI 27P).....	165
9.2.3 Unbalanced voltage (ANSI 47).....	166
9.2.4 Negative sequence voltage high (ANSI 47).....	166
9.2.5 Zero sequence voltage high (ANSI 59U ₀).....	167

9.2.6 Over-current (ANSI 50TD).....	168
9.2.7 Fast over-current (ANSI 50P).....	168
9.2.8 Unbalanced current (ANSI 46).....	169
9.2.9 Voltage-dependent over-current (ANSI 51V).....	170
9.2.10 Directional over-current (ANSI 67).....	171
9.2.11 Neutral over-current (4th CT).....	171
9.2.12 Earth fault over-current (4th CT).....	172
9.2.13 Inverse time over-current (ANSI 51).....	172
9.2.14 Inverse time neutral over-current (ANSI 51N).....	175
9.2.15 Earth fault inverse time over-current (ANSI 51G).....	176
9.2.16 Negative sequence current high (ANSI 46I ₂).....	176
9.2.17 Zero sequence current high (ANSI 50I ₀).....	177
9.2.18 Over-frequency (ANSI 81O).....	178
9.2.19 Under-frequency (ANSI 81U).....	178
9.2.20 Overload (ANSI 32F).....	179
9.2.21 Reverse power (ANSI 32R).....	179
9.2.22 Over-excitation or reactive power export (ANSI 40O).....	180
9.2.23 Under-excitation or reactive power import (ANSI 40U).....	180
9.3 Busbar standard protections.....	181
9.3.1 Busbar over-voltage (ANSI 59).....	181
9.3.2 Busbar under-voltage (ANSI 27).....	182
9.3.3 Busbar voltage unbalance (ANSI 47).....	182
9.3.4 Positive sequence under-voltage (ANSI 27d).....	183
9.3.5 Busbar over-frequency (ANSI 81O).....	183
9.3.6 Busbar under-frequency (ANSI 81U).....	184
9.3.7 Vector shift (ANSI 78).....	184
9.3.8 Rate of change of frequency (ANSI 81R).....	185
10. General purpose PID.....	187
10.1 Introduction.....	187
10.1.1 General purpose PID controllers in the battery/storage controller.....	187
10.1.2 General purpose PID analogue loop.....	187
10.1.3 General purpose PID interface in the utility software.....	188
10.2 Inputs.....	188
10.2.1 Dynamic input selection.....	189
10.3 Outputs.....	191
10.3.1 Explanation of output settings.....	191
10.3.2 Additional analogue outputs with IOM 230.....	193
10.4 M-Logic.....	195
10.5 Using general purpose PIDs for ESS regulation.....	195
10.5.1 Voltage regulation.....	196
10.5.2 Frequency regulation.....	197
10.5.3 Reactive power regulation.....	199
10.5.4 Power regulation.....	200
11. Inputs and outputs.....	203
11.1 Digital inputs.....	203
11.1.1 Standard digital inputs.....	203
11.1.2 Configuring digital inputs.....	203
11.2 DC relay outputs.....	204
11.2.1 Configure a relay output.....	205

11.3 Analogue inputs	205
11.3.1 Introduction	205
11.3.2 Application description	205
11.3.3 Configuring multi-inputs	206
11.3.4 Alarms	207
11.3.5 DC measurement averaging	208
11.3.6 Wire break	209
11.3.7 Differential measurement	210
11.4 Analogue outputs	211
11.4.1 Using an analogue output as a transducer	211
11.5 Additional inputs and outputs	212
12. Small rental application (ESS-Genset) example	
12.1 Introduction	213
12.2 Application setup	213
12.3 Inputs/Outputs	215
12.4 Wiring	216
12.5 Parameters	217
12.6 Timer logic	218
12.7 Commissioning	219
12.8 Operation	219

1. Introduction

1.1 About ASC 150 Storage

Use the **ASC 150 Storage** as a **single** controller to add a storage system to an existing site, or with other DEIF controllers in a **power/energy management system**. The controller optimises the battery power, to **save fuel** and maximise green penetration.

Each controller controls and protects an energy storage system (ESS) with communication to a BMS, BCU, and/or a PCS. The controller is **plug-and-play**, and **easy to customise** (with the user-friendly M-Logic tool). You can **easily scale up** from a single controller, to a PMS with a variety of controllers and up to 16 storage controllers.

1.1.1 Controller types

Parameter	Setting	Controller type	Minimum software
9101	Genset unit	Generator controller	Core
	Genset unit	Generator Stand-alone controller	Stand-alone
	Mains unit	Mains controller	Core
	BTB unit	BTB controller	Core
	Genset HYBRID unit	Genset-Solar hybrid controller	Core
	ENGINE DRIVE unit	Engine drive controller	Stand-alone
	Remote unit	Remote display	None
	ENGINE DRIVE MARINE unit	Engine drive controller for marine use	Stand-alone
	Genset MARINE unit	Stand-alone genset controller for marine use	Stand-alone
	ASC 150 Storage*	Battery storage controller	Extended + Sustainability
	ASC 150 Solar*	Solar controller	Extended + Sustainability
	ATS unit	Automatic transfer switch (open transition)	Stand-alone
	ATS unit	Automatic transfer switch (closed transition)	Core
	Genset PMS LITE	PMS lite controller	Core

Software packages and controller types

The controller software package determines which functions the controller can use.

- **Stand-alone**
 - You can change the controller type to any other controller that uses Stand-alone software.
- **Core**
- **Extended**
 - You can change the controller type to any other controller type*.
 - * To change to a storage or solar controller, the controller must also have the sustainability option (S10).
- **Premium**
 - You can change the controller type to any other controller type*.
 - * To change to a storage or solar controller, the controller must also have the sustainability option (S10).
 - All functions are supported.

You can select the controller type under `Basic settings > Controller settings > Type`.

1.2 Terms and abbreviations

Term	Abbreviation	Explanation
	iE 150 Battery iE 150 Marine Battery ASC 150 Storage ASC-4 Battery	DEIF's controller to integrate an energy storage system in an application with other power sources.
	iE 150 Solar iE 150 Marine Solar ASC 150 Solar ASC-4 Solar	DEIF's controller to integrate photovoltaic power in an application with other power sources.
	iE 150 iE 150 Marine AGC 150 AGC-4 Mk II AGC-4	DEIF controllers to control a genset (GEN (previously called "DG")), a bus tie breaker (BTB), or a mains (grid) connection/marine shore connection.
Alternating current	AC	An electric current which periodically reverses direction. A power converter is used to convert alternating current to direct current to charge the batteries. The power converter also converts direct current from the batteries to alternating current.
Apparent power	S	The vector sum of active power (P) and reactive power (Q).
Automatic mains failure	AMF	The ESS automatically supplies power if there is a mains failure. See Automatic mains failure .
Battery assisting		The battery runs parallel to other energy sources. Genset power is prioritised over battery power. Previously called "power source".
Battery Control Unit	BCU	The control unit for the ESS. The BCU handles all the internal ESS controls. The BCU is the interface between the ESS and the energy management system.
Battery leading		Battery power is prioritised over genset power. The ESS must be able to do grid-forming. Previously called "energy source".
Battery Management System	BMS	The monitoring system of the battery/energy clusters. The BMS monitors the SOC, and the maximum charge and discharge values. The BMS can also be the control unit for DC breakers and cluster breakers. The controller can write commands to the BMS.
Brownfield		An installation that already has power generating equipment and controllers. The controllers may be from other suppliers. Therefore the brownfield system cannot be fully controlled by DEIF. For ASC Storage, you can add single controllers or open PMS controllers to a brownfield site. These added controllers can be fully controlled by DEIF.
Busbar	BB	The equipment for the electrical connection of all the sources and the loads. The busbar can also be connected to the mains (grid).
Charge		Power flows to the ESS.
Direct current	DC	A flow of electric charge in one direction. Batteries provide direct current, and are charged using direct current. The power converter converts direct current to alternating current. The power converter also converts alternating current to direct current.
Discharge		Power flows from the ESS.

Term	Abbreviation	Explanation
Droop		For some energy storage systems, you can add droop to the battery regulation, to increase the system stability. See Battery droop .
Energy management	EM	The controllers work together to follow the energy management rules. They work together to run at the configured set point. In this way, the PV, ESS, mains connection(s), and/or genset(s) run optimally.
Energy management system	EMS	Genset, BTB, Mains/Shore connection, Battery/Storage and Solar controllers work with each other. The battery/storage controllers charge and discharge according to the energy management rules. The genset controllers start, stop and run at the load required by energy management. The mains controllers connect and disconnect the mains as required. Bus tie breaker controllers and ALC automatic load controllers can also be used. Together, the controllers form an energy management system. This can also be called an integrated system.
Energy storage breaker	ESB	The breaker between the ESS and the rest of the system. The battery/storage controller can control this breaker.
Energy storage system	ESS	A container-sized assembly that acts as a battery.
Fixed power		The ESS has a fixed power set point.
Greenfield		A new installation. Since there are no pre-existing controllers, the owner can choose to only use DEIF controllers. The new control system can then consist of DEIF controllers working together for power/energy management.
Grid		National or local electricity grid. Also known as mains.
Grid-tied		The energy storage system is connected to grid/mains power.
iE 150		A DEIF controller series that includes iE 150 Genset, iE 150 Battery, and iE 150 Solar. The controllers work together to provide energy management. ML 150 and ML-2 controllers can also be used with these controllers.
iE 150 Marine		A DEIF controller series that includes iE 150 Marine Genset, iE 150 Marine Battery, and iE 150 Marine Solar. The controllers work together to provide energy management.
Island operation		For island operation, the application is not connected to mains. See Island operation .
Load-dependent start or stop	LDSS	Controller settings that use the system load to determine when to start and stop gensets.
Mains breaker	MB	The breaker between the energy storage system and the grid/mains power.
Mains power export	MPE	This maintains a constant level of exported or imported power through the mains breaker. See Mains power export .
M-Logic		DEIF's PLC-like configurable logic tool.
Multi-line 150	ML 150	A DEIF controller series that includes AGC 150, ASC 150 Storage, and ASC 150 Solar. The controllers work together to provide energy management. iE 150 and ML-2 controllers can also be used with these controllers.
Multi-line 2	ML-2	A DEIF controller series that includes AGC-4, ASC-4 Battery, and ASC-4 Solar. The controllers work together to provide energy management. iE 150 and ML 150 controllers can also be used with these controllers.
Off-grid		The energy storage system is not connected to grid/mains power.
Open PMS		For brownfield energy management applications. Open PMS has Solar and/or Battery/Storage controllers along with other controllers from other vendors. The controllers get power measurements (required for energy management) from the other controllers and/or power meters.

Term	Abbreviation	Explanation
Peak shaving	PS	The maximum mains import set point is not exceeded. See Peak shaving .
Photovoltaic	PV	A system that converts sunlight to electrical power. The system may consist of several solar panels and an inverter.
Power conversion system	PCS	The PCS controls the AC/DC power. During discharging, the power converter converts the direct current from the ESS to alternating current to supply the busbar. During charging, the power converter converts the alternating current from the busbar to direct current to charge the ESS. The PCS also ensures that the ESS is grid forming (island), grid following (grid tie), or has droop control (grid tie-grid V/f support).
Power DC-DC system	PDS	In a DC-coupled application, the PDS is between the PV and ESS.
Power management	PM	DEIF's name for energy management.
Radio Ripple Control Receiver	RRCR	Binary inputs are used for external set point control.
Single controller		The single controller operates based on its own measurements and inputs. The single controller can also use power measurements from other power sources. However, single controllers are used in applications without power management.
Source	BA	A power source. This can be a PV system, an ESS, a mains connection, another busbar section, or a genset.
Spinning reserve		Partially loaded and synchronised power sources that can quickly respond to load changes.
State of charge	SOC	The charge in the ESS [%].
State of energy	SOE	The energy in the ESS [kWh].
State of health	SOH	The degree of degradation in the ESS. This could, for example, be based on the charge and discharge of the ESS.
Time of use	TOU	The amount charged for electricity changes according to the time of day.
Utility software	USW	DEIF's software to configure the application and controllers. The USW can also be used to monitor the application, as well as to configure M-Logic.
Virtual synchronous generator	VSG	A power source that follows a droop curve by using the system measurements to adjust its V/f or P/Q set points.

1.3 About the Designer's handbook

General purpose

This document gives information about the controller's functionality and its applications, and for configuring the controller.



CAUTION



Installation errors

Read this document before working with the controller. Failure to do this may result in human injury or damage to the equipment.

Intended users of the Designer's handbook

This Designer's handbook is primarily intended for the panel designer in charge. Based on this document, the panel designer can give the electrician the necessary information to install the controller, for example detailed electrical drawings.

The Designer's handbook can also be used during commissioning to check the parameters, and operators may find it useful for understanding the system and for troubleshooting.

List of technical documentation

Document	Contents
Product sheet	• Short description • Controller applications • Main features and functions • Technical data • Protections • Dimensions
Data sheet	• General description • Functions and features • Controller applications • Software variants • Protections • Inputs and outputs • Technical specifications
Designer's handbook	• Principles • Communication • Applications • Controller sequences and functions • Protections and alarms • Regulation • Examples
Installation instructions	• Tools and materials • Mounting • Minimum wiring for the controller • Wiring information and examples
Operator's manual	• Controller equipment (buttons and LEDs) • Operating the system • Alarms and log
Communication	ASC 150 Modbus server tables • Modbus address list ◦ PLC addresses ◦ Corresponding controller functions • Descriptions for function codes, function groups ASC 150 Modbus server User manual • Communication and connections • Data tables, including Modbus configurator • Parameter setting • DEIF Open protocol IE 150 Battery ASC 150 Storage ASC-4 Battery Modbus client tables

Document	Contents
	• Modbus address list for the <i>DEIF Generic</i> protocol (connection to energy storage system) • Descriptions for function codes, function groups iE 150 ASC 150 Modbus client User manual • Communication and connections • Modbus client monitoring • DEIF Generic protocols
Application notes	DEIF Hybrid controller compatibility • Energy storage systems ◦ BCU control ◦ BCU and PCS control ◦ BMS control ◦ PDS control • Power measurements ◦ Power meters ◦ Genset controllers • PV systems • Weather stations and forecast systems ASC 150 Storage M-Logic • M-Logic events, and when each events is activated • M-Logic outputs, and the effect of each output
Drawings	• 2D CAD drawing • 2D PDF • 3D STEP-file • 3D PDF • EPLAN

1.3.1 Software version

This document is based on the AGC 150 software version 1.35.

1.4 Warnings and safety

Safety during installation and operation

When you install and operate the equipment, you may have to work with dangerous currents and voltages. The installation must only be carried out by authorised personnel who understand the risks involved in working with electrical equipment.



DANGER!



Hazardous live currents and voltages

Do not touch any terminals, especially the AC measurement inputs or any relay terminals, as this could lead to injury or death.

Current transformer danger



DANGER!



Electrical shock and arc flash

Risk of burns and electrical shock from high voltage.

Short all current transformer secondaries before breaking any current transformer connections to the controller.

Factory settings

The controller is delivered pre-programmed from the factory with a set of default settings. These settings are based on typical values and may not be correct for your system. You must therefore check all parameters and settings before using the controller.

Electrostatic discharge

Electrostatic discharge can damage the controller terminals. You must protect the terminals from electrostatic discharge during the installation. When the controller is installed and connected, these precautions are no longer necessary.

Data security

To minimise the risk of data security breaches:

- As far as possible, avoid exposing controllers and controller networks to public networks and the Internet.
- Use additional security layers like a VPN for remote access, and install firewall mechanisms.
- Restrict access to authorised persons.

1.5 Legal information

Third party equipment

DEIF takes no responsibility for installation or operation of any third party equipment. In no event shall DEIF be liable for any loss of profits, revenues, indirect, special, incidental, consequential, or other similar damages arising out of or in connection with any incorrect installation or operation of any third party equipment.

Warranty

NOTICE



Warranty

The controller is not to be opened by unauthorised personnel. If opened anyway, the warranty will be lost.

Disclaimer

DEIF A/S reserves the right to change any of the contents of this document without prior notice.

The English version of this document always contains the most recent and up-to-date information about the product. DEIF does not take responsibility for the accuracy of translations, and translations might not be updated at the same time as the English document. If there is a discrepancy, the English version prevails.

Copyright

© Copyright DEIF A/S. All rights reserved.

2. Utility software

2.1 Download the utility software

The **Multi-line 2 Utility Software v.3.x** is the software interface between a PC and the controller. The software is free of charge. Download it from www.deif.com


2.2 Connection

You can use a USB connection or TCP/IP to connect to the controller.


2.2.1 USB connection

You need a USB cable (USB A to B) to connect the controller to a PC.

1. Install the utility software on a PC.
2. Use the USB cable to connect the controller service port to the PC.
3. Start the utility software.



4. If needed, *Scan ports*, then select a service port option.
5. When prompted, select the access level, enter the password, and select OK.



More information

See **General functions**, **Password** for the default passwords.

2.2.2 TCP connection

You can use TCP/IP communication to connect to the controller. This requires an Ethernet cable, or a connection to the network that includes the controller.

Default controller network address

- IP: 192.168.2.2
- Gateway: 192.168.2.1
- Subnet mask: 255.255.255.0

Configuring the controller IP address using the display unit or a USB connection

When connecting to a controller using TCP/IP, you must know the controller's IP address. Find the IP address on the display under: `Communication > Ethernet setup`.

You can use the display to change the controller's IP address.

Alternatively, you can use a USB connection or an Ethernet connection and the utility software to change the controller IP address.


Point-to-point Ethernet connection to the controller

If you do not want to use the display unit or a USB connection to change the IP address, you can use a point-to-point Ethernet connection. The PC must have a static IP address. For the default controller network address, the PC static IP address must be 192.168.2.xxx, where xxx is a free IP-address in the network (note: xxx cannot be 2 (the controller IP address) or 1 (the gateway)).

If you change the controller address (for example, from 192.168.2.yyy to 192.168.47.yyy) the connection is lost. A new static IP for the PC is needed. In this case, 192.168.47.zzz, where zzz is a free IP-address in the network. The PC address, IP address, and gateway must be in the same subnet.

When the PC has the correct static IP address:

1. Use an Ethernet cable to connect the PC to the controller.
2. Start the utility software.
3. Select *TCP-IP*, and enter the controller IP address.




4. You can use the *Test* button to check if the connection is successful.
5. Select *Connect* to connect to the controller using TCP-IP.

Configuring the controller IP address using the utility software

1. Select *Connect* to connect to the controller using TCP-IP.
2. Select *Ethernet setting (TCP/IP)*.

The *Network Parameters* window opens:



When the controller network parameters have been changed, press the *Write to device*  button.

The controller receives the new network parameters and reboots the network hardware.

To connect to the controller again, use the new controller IP address (and a correct PC static IP address).

NOTE Please note that not all controllers support DNS and NTP settings. Features described in this document apply only if they are available on the controller.

Using a switch

For a system with multiple controllers, all controllers can be connected to a switch. Create a unique IP address for each controller in the network before connecting the controllers to a switch.


The PC can then be connected to the switch, and the Ethernet cable can be in the same port of the switch at all times. You can enter the controller IP address in the utility software.

The TCP-IP connection is faster than other connections. It also allows the user to shift between controllers in the application supervision window in the utility software.

2.3 Using NTP

To ensure that the controller always has the right time, you can use the network time protocol (NTP) function.

Select *Ethernet setting (TCP/IP)* in the Utility software, then select the *NTP parameters* tab in the *Network Parameters* window:



You can select an NTP server, a time zone and an update interval. Write the changes to the controller to activate the NTP function.

NOTE The selected NTP server must be available in the network.


2.4 Utility software interface

2.4.1 Top toolbar




1. Start communication with the device.
2. Disconnect from a controller.
3. Change your user level.
4. Application settings.
5. Upgrade options (create an option code and send it to support@deif.com).
6. Write new options (received from DEIF support).
7. Write a firmware to the device.
8. AOP 1: Not used for this controller.
9. AOP 2: Configure the AOP-2 buttons and LEDs (Additional Operator Panel).
10. RRCR: Radio ripple control receiver.
11. Counters: Read the controller counters.
12. Identifiers: Information on the controller and the software.
13. Batch read and write: Read, write, backup, and restore the device.
14. Show/Hide the real-time readings window.
15. Send a command to the controller.
16. Synchronise the clock of the device with the connected PC.

2.4.2 Left menu



- **DEIF**
 - Link to www.deif.com
- **Monitoring**
 - Application supervision
 - See the plant operation, including how much power each genset produces.
 - Alarms
 - An overview of the active alarms.
 - See the history for the alarms that are activated while the PC is connected.
 - Logs
 - See the alarms and events logs from the controller.
 - Inputs/outputs
 - The controller input and output status.
 - Trending
 - See real-time operation.
 - Trending is possible when a PC is connected and the trending window is open. The controller cannot save the data.
- **Configuration**
 - Application configuration
 - Create the application single-line drawing(s).
 - Parameters
 - Configure and view parameters.
 - I/O & Hardware setup
 - Configure the inputs and outputs.
 - External I/O (CIO)
 - Detect and configure the external inputs and outputs.
- **Scheduler**
 - Configure schedules for the controller modes and set points.
- **Tools**
 - Ethernet setting (TCP/IP)
 - Configure Ethernet settings and communication.
 - M-Logic & AOP
 - Configure M-Logic and additional operator panels.
 - Modbus Configurator
 - Configure the configurable Modbus addresses.
 - Options & Firmware
 - See the available options.
 - Translations
 - Customise or translate (almost all of) the text in the controller.
 - General Purpose PID
 - Configure the general purpose PID settings.
 - Display views
 - Configure the display views.
 - Permissions
 - See and change the user permissions.
- **Compare offline files**
 - Compare utility software project files.

2.5 Set up applications



Select *Application configuration* in the left menu. The controller comes with four pre-configured standard applications. Standard applications 1, 3 and 4 are identical.

The applications can be changed with the utility software.

2.6 Emulation

You can use the utility software to emulate the application.

Requirements:

- One or more controllers, each with its own power supply.
- For multiple controllers, set up a network for PMS over Ethernet, or connect their power management CAN bus terminals.
- A USB or TCP/IP connection from one of the controllers to your PC.
- For each controller, disable the *Emergency STOP* alarm (menu 3490). Alternatively, activate digital input 4 (the emergency stop).

The operation and other inputs can be emulated.

NOTE During emulation, if the controller detects AC voltage, it activates the *Live voltage detected* alarm.



CAUTION



Emulation can start the ESS

During emulation, the controller uses the communication connection to the ESS. If communication is not disabled, the controller can send commands to the ESS. Be very careful about using emulation if the controller is mounted in a real installation.



CAUTION



Emulation can activate relays

If you select *Breaker and engine cmd. active*, the controller activates its relays (for example, the relay to close a breaker). Be very careful about selecting this if the controllers are mounted in a real installation.

1. Under *Application configuration*, in *Plant options*, select *Breaker and engine cmd. active* or *Breaker and engine cmd. inactive*.

- For *Breaker and engine cmd. active*, the controllers activate the relays and try to communicate with the ESS. If the controllers are mounted in a real installation, the breakers will open/close and the ESS start/stop.
- The real installation is not affected if *Breaker and engine cmd. inactive* is selected.

In real installations, emulation can be used during the commissioning. When the commissioning is done, select *Off* for *Application emulation*.

Plant options [X]

Product type
ASC 150 Storage

Plant type
Single controller

Application properties
☒ Active (applies only when performing a batchwrite)
 Name: Single control. app.

Bus Tie options
☐ Wrap bus bar

Power management CAN
☒ Primary CAN
☐ Secondary CAN
☐ Primary and Secondary CAN
☐ CAN bus off (stand-alone application)

Application emulation
☐ Off
☒ Breaker and engine cmd. active
☐ Breaker and engine cmd. inactive

OK Cancel

- Under *Application supervision*, select *Emulation stimuli*  to open the *Plant emulation* box. You can adjust a wide range of plant and input settings.


 **Plant emulation: Breaker and engine cmd. active** [Min] [Max] [X]

Battery

Set emulation settings for Battery (ASC 150 Storage)

	Load	Mains	Battery	ESB	MB	Dig	Ain
Active Load	<input type="range" value="450"/>						kW
Reactive load	<input type="range" value="0"/>						kvar

Write to Battery Close



3. You can see the emulated effect on the plant diagram on the *Application supervision* page.


3. Communication

3.1 Overview

The controller is the link between the ESS and other power sources.


Communication with the battery management system and power conversion system

If the ESS does not have a BCU, the controller communicates with the battery management system (BMS) over Modbus. The controller also communicates with the power conversion system (PCS) over Modbus.




Communication with the battery control unit

If the ESS has a battery control unit (BCU), the controller communicates with the BCU over Modbus.




Communication with the BMS, PCS, and Power DC-DC system

If the ESS has a power DC-DC system (PDS), the controller also communicates with the PDS over Modbus. The PDS can be a separate charger or DC from PV (solar).



3.2 Battery/Storage controller communication

Example of communication for a single controller application



The controller can communicate over Modbus as the client and/or server device. The controller can communicate with the ESS using Modbus TCP and/or Modbus RTU. * The controller reads from power meters or genset controllers using Modbus RTU.

3.2.1 Modbus client and Modbus server

The controller as Modbus client

The controller can communicate with the energy storage system directly, or through a gateway device.

The controller uses Modbus for its communication with the BCU, PCS, PDS, or BMS. The controller is the client and the energy storage system is the server. The controller transmits the references to the energy storage system using Ethernet (Modbus TCP/IP) or RS-485 (Modbus RTU).

The controller as Modbus server

The DEIF Open protocol uses Ethernet (Modbus TCP/IP) or RS-485 (Modbus RTU). The ESS controller is the client device. Using this protocol, the energy storage system can read the references from the controller, which is the server device.

Other equipment, for example, a SCADA system or a PLC, can also be the client and use the controller Modbus server to read operating data and adjust set points.



More information

See **ASC 150 Modbus server tables**, **iE 150 Battery** **ASC 150 Storage** **ASC-4 Battery Modbus client tables**, and **DEIF hybrid controller compatibility**.

3.3 Hardware settings

3.3.1 RS-485

Communication > RS485 > RS485 [1 or 2] > Settings

Parameter	Name	Range	Default	Details
7511 or 7521	Ext. comm. ID [1 or 2]	1 to 247	3	Modbus communication ID for the controller Modbus server. The external Modbus client uses this ID to communicate with the controller.
7512 or 7522	Ext. comm.speed[1 or 2]	9600 Baud 19200 Baud 38400 Baud 115200 Baud	9600 Baud	Communication speed for RS-485 [1 or 2]

Communication > RS485 > RS485 [1 or 2] > Communication error

Parameter	Name	Range	Default	Details
7513 or 7523	Timer	1 to 100 s	10 s	Communication error for RS-485 [1 or 2]
7516 or 7526	Enable	OFF ON	OFF	
7517 or 7527	Fail class	Fail classes	Warning	

3.3.2 CAN bus

Communication > CAN protocols

Parameter	Name	Range	Default	Details
7841	CAN A protocol	OFF AOP2 Ext. Modules DEIF	OFF	AOP2: CAN [A or B] is connected to an AOP. Ext. Module DEIF: CAN [A or B] is connected to a CIO.
7842	CAN B protocol	OFF PMS Primary AOP2 PMS Secondary Ext. Modules DEIF	PMS Primary	
7843	VCAN C protocol	OFF PMS Primary PMS Secondary	OFF	See Using Ethernet for power management .

3.3.3 ESS Modbus TCP/IP settings

You can use Ethernet connections for Modbus communication to the ESS, BMS and/or PDS.

Display

Configure the ESS, BMS and PDS Modbus TCP/IP settings under Settings > Modbus TCP/IP setup

Utility software

On the *Ethernet setting (TCP/IP)* page in the utility software, select *Modbus TCP/IP*, then configure the settings.

DEIF

Monitoring ⌵

Configuration ⌵

Tools ⌴

Ethernet setting (TCP/IP)

M-Logic & AOP

Modbus Configurator

Option & Firmware

Translations

General Purpose PID

Permissions

Compare offline files

Network parameters | Remote Display | Power Management | NTP parameters | Modbus TCP/IP

ESS IP address: 192.168.2.5

ESS TCP/UDP: TCP

ESS port number: 502

ESS modbus ID: 3

BMS IP address: 192.168.2.31

BMS TCP/UDP: TCP

BMS port number: 502

PDS IP address: 192.168.2.32

PDS TCP/UDP: TCP

PDS port number: 502

Use Tx min. interval: False

Configure the IP addresses, communication type (TCP or UDP), and port numbers for the ESS, BMS and/or PDS.

3.3.4 Ethernet

Communication > Ethernet comm. error

Parameter	Name	Range	Default	Details
7901	Timer	1 to 100 s	10 s	Communication error for the Ethernet port.
7904	Enable	OFF ON	OFF	
7905	Fail class	Fail classes	Warning	

3.4 Protocol parameters

3.4.1 ESS parameters

Communication > ESS

Parameter	Name	Range	Default	Details
7541	ESS comm. intf.	Modbus RTU client 1 Modbus RTU client 2 Modbus TCP/IP client	Modbus RTU client 1	Select the ESS communication interface.
7545	ESS comm. ID	0 to 247	3	The ID given to the ESS to receive and transmit data.
7561	ESS protocol	See DEIF Hybrid controller compatibility	Off	Select the protocol that matches your ESS. If the ESS is not in the list, select Off. Additional protocols may be available. Contact DEIF for details.

Parameter	Name	Range	Default	Details
7562	Tx write type	Unicast Broadcast*	Unicast	Only affects protocols where the controller is the client. * Broadcast is not available yet.
7563	Tx min. interval	0.1 to 10 s	0.5 s	The time that the controller waits (after receiving a telegram) before it sends the next telegram. This only affects protocols where the controller is the client. For TCP/IP this parameter is only active if <i>Ethernet setting (TCP/IP)</i> , <i>Modbus TCP/IP</i> , <i>Use Tx min. interval</i> is True . If False , the communication is as fast as possible.
7564	Tx write fnc.	Single register 0x06 Multiple register 0x10	Multiple register 0x10	Select whether the controller sends Modbus telegrams with only a single register, or multiple registers. Only affects protocols where the controller is the client.
7570	ESS comm. error	0 to 100 s	3 s, Warning	This alarm activates when there is no communication from the ESS.
7580	ESS warning	0 to 100 s	0 s, Warning	This alarm activates when a warning alarm is present on the ESS.
7590	ESS shutdown	0 to 100 s	0 s, Shutdown	This alarm activates when there is a shutdown alarm present on the ESS.

NOTE The controller detects communication failure if the ESS does not respond to telegrams.

You can also configure these settings from the display, under *Settings > Communication > ESS*

3.4.2 BMS parameters

Communication > BMS

Parameter	Name	Range	Default	Details
7542	BMS comm. intf.	Modbus RTU client 1 Modbus RTU client 2 Modbus TCP/IP client	Modbus RTU client 1	Select the BMS communication interface.
7681	BMS comm. ID	1 to 247	5	The ID given to the PDS to receive and transmit data.
7682	BMS protocol	See DEIF Hybrid controller compatibility	OFF	Select the battery management protocol that matches your BMS. If no BMS is available, or the BMS is not in the list, select OFF.
7690	BMS comm. error	0 to 100 s	3 s, Warning	This alarm activates when there is no communication from the battery management system.
7610	BMS warning	0 to 100 s	0 s, Warning	This alarm activates when a warning alarm is present on the BMS.
7620	BMS shutdown	0 to 100 s	0 s, Shutdown	This alarm activates when a shutdown alarm is present on the BMS.

You can also configure these settings from the display, under *Settings > Communication > BMS*

3.4.3 PDS parameters

Communication > PDS

Parameter	Name	Range	Default	Details
7543	PDS comm. intf.	Modbus RTU client 1 Modbus RTU client 2 Modbus TCP/IP client	Modbus RTU client 1	Select the PDS communication interface.
7901	PDS comm. ID	1 to 247	5	The ID given to the PDS to receive and transmit data.
7912	PDS protocol	See DEIF Hybrid controller compatibility	OFF	Select the Power DC-DC system protocol that matches your PDS. If no PDS is available, or the PDS is not in the list, select OFF.
7910	PDS comm. error	0 to 100 s	3 s, Warning	
7920	PDS warning	0 to 100 s	0 s, Warning	
7930	PDS shutdown	0 to 100 s	0 s, Shutdown	

You can also configure these settings from the display, under `Settings > Communication > PDS`

3.4.4 Power meter parameters

Communication > Power meter

Parameter	Name	Range	Default	Details
7544	Meter comm. intf.	Modbus RTU client 1 Modbus RTU client 2	Modbus RTU client 1	Select the power meter communication interface.
7761	Pow. met. Tx min int	0.1 to 10 s	0.5 s	Minimum time between the controller telegrams to the power meters.
7721	GEN meter prot.	See DEIF Hybrid controller compatibility	OFF	Select the power meter protocol that matches the power meter. Note that all genset power meters must use the same protocol.
7723	ESS meter prot.	See DEIF Hybrid controller compatibility	OFF	Select the power meter protocol that matches the power meter.
7725	Mains meter prot.	See DEIF Hybrid controller compatibility	OFF	Select the power meter protocol that matches the power meter.

These parameters are used for all the power meters connected to the controller.



More information

See **Power measurements and connection status** for the genset meter and mains meter parameters.



More information

See **Storage controller functions** for the ESS meter parameters.

3.4.5 Configurable power meter

You can use the *Configurable power meter* function to configure the Modbus communication to power meters. This function is useful for a power meter that is not included in the **DEIF Hybrid controller compatibility** list.


Parameters

For *GEN meter prot.* (parameter 7721), *ESS meter prot.* (parameter 7723), and/or *Mains met. prot* (parameter 7725), select *Configurable power meter*.

NOTE You can only have one type of configurable power meter in a controller.

Configurable power meter setup

In the utility software, under *I/O & Hardware setup*, select the *Configurable power meter* tab.



	Enable	Modbus address	Function code	Data type *	Scaling	Unit	Invert	Offset
Active power	☐	0	Read holding registers	U16	1/1	kW	☐	0
Reactive power	☐	0	Read holding registers	U16	1/1	kVar	☐	0

	Enable	Modbus address	Function code	Data type *	Bit selection
Digital input 1	☐	0	Read discrete Inputs	U16	Bit 0
Digital input 2	☐	0	Read discrete Inputs	U16	Bit 1
Digital input 3	☐	0	Read discrete Inputs	U16	Bit 2
Digital input 4	☐	0	Read discrete Inputs	U16	Bit 3

About Function code for code Digital input 1:
 If holding or input register is chosen only 1 modbus address will be visible.
 Then choose bit value in data types to chose which bit that fits the correct digital input for the specific modbus address

Configure the power measurements

1. Select **Enable** for the power measurements that the power meter supports.
2. For each power measurement, configure the Modbus address, function code, data type, scaling, and power unit. If the sign (positive or negative) of the value must be reversed, select *Invert*. If the measurement value is offset, configure the offset.



Example of power measurement configuration

The controller has the following power measurement configuration:

	Enable	Modbus address	Function code	Data type *	Scaling	Unit	Invert	Offset
Active power	Enable	1	Read holding registers	U16	1/100	kW	☒	2000
Reactive power	Enable	2	Read holding registers	U16	1/100	kVar	☒	1000

If the value that the controller reads from the power meter for active power is 19876, and the reactive power value is 12345:

Active power = - (19876 + 2000)/100 kW = -218.76 kW

Reactive power = - (12345 + 1000)/100 kvar = -133.45 kvar

Configure the digital inputs

1. Select **Enable** for the digital inputs that the power meter supports.
2. For each digital input, configure the Modbus address, function code, and data type.
 - a. If you select *Read holding registers* or *Read input registers* for the function code, you can only use the first Modbus address for the digital inputs.
 - b. When the data type is *Bit value*, select the bit under *Bit selection*.

Connect the digital inputs to breaker feedback

If the breaker status is included in the power meter protocol, configure M-Logic to connect the output from the power meter to enable the corresponding equipment.

For example, in an Open PMS application, external source 1 is a genset. Digital input 1 from the power meter is activated when the generator breaker is closed:

Logic 1 Power meter 1 input 1 enables GB 1 closed feedback

	NOT	Operator		Delay (sec.)	
Event A	☐		DG Power meter 1 input1: DG power meter ir		0
Event B	☐	OR	Not used		
Event C	☐	OR	Not used		

Output: GB1 closed feedback: External GB feedbacks

Enable this rule ☒

Check the configuration

In the utility software, under *Application supervision*, select the *Power meter data* icon to open the *Power meter data* window. Here you can see the power measurement values, as well as the bit values for the digital inputs.

3.5 Troubleshooting

You can use the display to check whether the communication is connected for each external device. You can also see communication details from the display.

Under *Service view > Communication analysis*, you can see:

- Modbus client RTU port 1
- Modbus client RTU port 2
- Modbus client TCP/IP
- TCP/UDP multi node status

For each selection, you can see configuration and operating details. For example, for *Modbus client TCP/IP*, you can see:

- Details for each connected device (use <Prev. and Next> to navigate)
 - IDs, Rx and Tx info, IP address, connected (true or false), and so on.



More information

See **Modbus Troubleshooting** in the **iE 150 ASC 150 Modbus client User manual** for a list of Rx status texts and their reasons.

3.6 Remote monitoring

3.6.1 Monitoring solutions

A range of remote monitoring solutions is possible.

For an existing system, you can use the Ethernet TCP/IP connection or one of the RS-485 ports of the controller. All data in the Modbus protocol can then be polled from the device. The controller acts as a server device in the system. For example, this solution can be used in HMI or SCADA systems.

Another solution is to install a gateway, giving access to a cloud-based database. This gives an accessible front portal. Live data and log data are sent to a server (depending on the solution). **Insight** is DEIF's ready-made solution for remote monitoring.

Alternatively, the gateway can work as an actual remote gateway. In this solution, the DEIF PC utility software can be accessed with all the control and monitoring functions needed (control can be switched off, or made user level-dependent).

3.6.2 Modbus server TCP connection

The controller's Ethernet connection is used for remote or local monitoring.

You can use the utility software to see (or set up) the controller. On the *Ethernet setting (TCP/IP)* page, open *Network parameters*.

Network parameters	Remote Display	Power Management	NTP parameters
IP address	192.168.18.12		
Net mask	255.255.255.0		
Gateway	192.168.12.1		
DNS Primary IP	8.8.8.8		
DNS Secondary IP	8.8.4.4		

Alternatively, use the display: Settings > Communication > Ethernet setup

3.6.3 DEIF remote monitoring

The DEIF remote monitoring system is a hybrid monitoring system that provides ESS values and other relevant plant values. Values, alarms and logs can be seen from both the controller and the BCU, PCS, PDS, and BMS. Alternatively, all the values, alarms and logs can be seen from the controller.

3.6.4 ESS values

The controller includes a generic Modbus client that can access various values from the supported BCU, PCS, PDS, and BMS. The available values depend on the BCU, PCS, PDS, and BMS. For compatible systems, see **DEIF hybrid controller compatibility**.

The **iE 150 Battery ASC 150 Storage ASC-4 Battery Modbus client tables** show which values are supported. Available ESS data can be read from the controller Modbus server using the TCP/IP port.

4. Single-controller applications

4.1 Single controller

The controller can operate as a single controller, that is, without power management communication to other DEIF controllers. Single controllers are particularly useful for brownfield applications (the controller is installed in an existing plant). Single controllers can also be used in greenfield applications.

In a single-controller application, the controller operates as the only DEIF controller in the system. The controller is the link to the ESS.

To control the ESS power set point, the single controller must get the power measurements and breaker positions for the power sources in the rest of the application. You can use transducers, or the controller can read Modbus values from power meters, external genset controllers, or a PLC.

The controller can be used in single controller applications that are off-grid, grid-tied, or a combination. There is a maximum of 16 grid connections, and there can be up to 16 gensets. If there is more than 1 grid connection, the controller interacts with the grid connections as if there was only 1 grid connection.

The controller calculates the charging and discharging set points. The set points are determined by:


- The operating mode
- The system load and configuration
- The state of charge in the storage
- The maximum charge and discharge capacity for the storage
- The power readings from the other power source(s)
- The breaker position(s) of the other power source(s)

4.2 Modes of operation

4.2.1 Off-grid applications

In a single controller off-grid application, the controller can only use island operation.

Single controller off-grid ESS application




4.2.2 Grid-tied applications

In a single controller combination application, the controller can have the following modes of operation:

- Mains breaker open (that is, off-grid):
 - Island mode
 - AMF (Automatic Mains Failure)
- Mains breaker closed (that is, grid-tied):

- MPE (Mains Power Export)
- Peak shaving
- Fixed power
- AMF (Automatic Mains Failure)

Single controller grid-tied ESS application



NOTE Gensets are not required in a grid-tied application.

4.3 Setup of a single controller application

In a single controller application, the controller can control one ESS, one ESS breaker (ESB), and one mains breaker (MB). The controller can also send start and stop signals to gensets.

You can use the display or the utility software to set up a single controller application.

4.3.1 Application setup using the display

Parameters > Functions > Quick setup


Name	Range	Default	Details
Mode	Off Setup stand alone Setup plant Adapt plant	Off	Select Setup stand alone .
CAN line	Off CAN PM Primary CAN PM Secondary	Off	Select Off .
MB	Pulse No breaker EXT/ATS Continuous ND Continuous NE	Pulse	Select the mains breaker type.

Name	Range	Default	Details
	Compact		
ESB	Pulse No breaker External Continuous NE	Pulse	Select the ESS breaker type.
Mains	Mains present No mains present	Mains present	Select whether there is a mains connection.
ESS	Single controller Standard	Standard	Select Single controller .

4.3.2 Application setup using the utility software

When connected to the controller with the utility software:

1. Select *Application configuration*
2. Select *New plant configuration* 
3. The *Plant options* window opens.



Select the plant options:

1. Select the *Product (controller) type*
 - Greyed out when already connected to a controller.
2. Select the *Plant type: Single controller*
3. Select to activate the application when it is written to the controller.
4. Write a name for the application.
5. Select OK to save the application.

Example

Area control Plant totals

< Area 1 of 1 >

Area configuration - Top

Source Mains 1

ID 0

MB Pulse 2

Bottom

Source Battery 3

ID 0

ESB Pulse 4

< Add Delete Add >

1. Select one of these types of power source to show in the top area:
 - None
 - Mains
 - Battery
2. Select the breaker type for the mains breaker:
 - Pulse
 - Continuous NE
 - Compact
 - Ext
 - None
 - Continuous ND
3. Select the power source to show in the bottom area:
 - None
 - Mains
 - Battery
4. Select the breaker type for the ESS breaker:
 - Pulse
 - Ext/ATS no control
 - Continuous NE
 - None

After the application drawing is created, press *Write plant configuration to device*  to send the configuration to the connected controller.

4.4 Breaker control

Single controller application without a breaker

If you created a single controller application without an ESS breaker, reset any ESS breaker feedback in the I/O setup list:

1. In the utility software, select *I/O & Hardware setup*
2. Change the function to *Not used* for the relevant I/Os, for example:

Digital Input 49


Function Not used

Single controller applications with breakers

In a single controller application, the controller can control up to two breakers. This can be the ESB (energy storage breaker) and/or a mains breaker. If genset breakers are present, the controller cannot control all three breakers. The controller only receives the breaker feedback (open/closed).

Use the *Application configuration* page in the USW to add/remove the ESB and/or mains breaker to match the application. The controller automatically assigns digital inputs* for the breaker feedbacks and relays for the breaker control.

NOTE * To use breaker feedbacks from a mains power meter, configure these in M-Logic. Note that digital inputs are required if the controller controls the breaker. See [Mains power measurement from power meter communication](#).



4.5 Power measurements and connection status

For a single controller application, the controller needs the active power from all the other power sources in the system. The controller also needs the connection status of the other power sources.

The reactive power is optional, but is required if the controller must control the reactive power. To control reactive power, the controller must also have the premium software version.

There is a range of ways to get this information, using Modbus or analogue transducer signals.

	Active power (P)	Reactive power (Q)	Connection status
Power meter*	●	●	●
External genset controller*	●	●	●
DEIF open communication	●	●	●
Transducer (Modbus or analogue)*	●	●	-
Controller 4th current transformer**	●	●	-
Digital input	-	-	●

NOTE * Check the compatibility list to make sure that the power meter, external genset controller, or transducer supports all these measurements.

NOTE ** Only for a mains connection. The controller uses the single-phase current measurement to calculate the mains power.

4.5.1 Power meters and genset controllers

The controller supports a wide range of power meters, as well as communication with genset controllers from other manufacturers.



More information

See the **DEIF hybrid controller compatibility** documents for a list of compatible power meters and genset controllers.

Connection status

If the power meter/genset controller does not include the connection status, you must configure a digital input.

4.5.2 Genset power measurement from power meter communication

For a single controller application, the genset active power and breaker positions must be monitored. Genset reactive power is optional, and is only required if the controller must control reactive power. The application can include up to 16 gensets. There are a number of ways for the controller to get the genset power measurements.

Genset power measurement from power meter communication is described here. Power meter communication includes power measurements and breaker feedback from power meters, or from genset controllers.

Communication > Power meter > GEN meter

Parameter	Name	Range	Default	Details
7701	GEN meter ID	1 to 247	3	Select the genset power meter ID.
7721	GEN meter protocol	See DEIF Hybrid controller compatibility	Off	Select the protocol that matches your power meter. Additional protocols may be available. Contact DEIF for details.
7722	GEN nbr. nodes	1 to 16	1	Number of nodes.
7730	GEN meter err.	0 to 60 s Fail classes	0 s Warning	If enabled, this alarm activates when there is no communication from the genset power meter.

You can also configure these settings from the display, under Settings > Communication > Power meter > GEN meter settings

Power measurement

In the utility software, on the *I/O & Hardware* page, select *Ext. P/Q sources*. For up to 16 sources, select the type and nominal power. For each *P source* and *Q source*, select *GEN power meter comm. xx*.

DI 39 - 50	MI 20	MI 21	MI 22	MI 23	DO 5 - 18	DC meas AVG	AC meas AVG	Ext. P/Q sources	Configurable power meter	ESS custom inputs
	Type	Nominal P (kW)	P source	Q source						
Ext. source 1	GEN	1500	GEN power meter comm. 01	GEN power meter comm. 01						
Ext. source 2	GEN	1500	GEN power meter comm. 02	GEN power meter comm. 02						
Ext. source 3	GEN	1500	GEN power meter comm. 03	GEN power meter comm. 03						
Ext. source 4	GEN	1500	GEN power meter comm. 04	GEN power meter comm. 04						

Gensets connected

The controller also needs to know which gensets are connected. For some power meter protocols, this is included. See the **DEIF hybrid controller compatibility** document.

Genset breaker status from the power meter protocol

Event A: GEN power meter inputs > GEN Power meter 1 input 1

Output: External GB feedbacks > GB1 closed feedback

If the genset breaker status is included in the power meter protocol, configure M-Logic to connect the output from the power meter to enable the corresponding genset.

For DEIF genset controllers, Input 1 is always for GB closed. Input 3 is always for GB open.

Genset breaker status from digital inputs

If the genset breaker status is not included in the power meter protocol, configure a digital input for each breaker.

4.5.3 Mains power measurement from power meter communication

For a single controller application, the mains active power is needed. Mains reactive power is optional. There are a number of ways for the controller to get the mains power measurements. Mains power measurement from power meter communication is described here.

If a mains breaker is included in the application drawing, the mains breaker position must be monitored. A single controller can control the breaker for one mains connection. Alternatively, the single controller can be used with up to 16 mains connections (no breaker control).

Operating modes and power measurement

For mains power export (MPE) and peak shaving operation, the mains power must be measured.

For fixed power operation, you must configure the mains power measurement, even though the mains power measurement is not used. If the mains power measurement is not connected, the controller shows 0 kW for the mains power.

Parameter	Name	Range	Default	Details
7703	Mains meter ID	1 to 247	3	Select the mains power meter ID.
7725	Mains meter protocol	See DEIF Hybrid controller compatibility	Off	Select the protocol that matches your power meter. Additional protocols may be available. Contact DEIF for details.
7726	Mains nbr. nodes	1 to 16*	1	Number of nodes.
7750	Mains meter err.	0 to 60 s Fail classes	0 s Warning	If enabled, this alarm activates when there is no communication from the mains power meter.

NOTE * If there are any mains nodes, you must have *Premium* software.

You can also configure these settings from the display, under *Settings > Communication > Power meter > Mains meter settings*

NOTE To use a mains meter for active power, select *Power meter comm.* in parameter 7005. For reactive power, select *Power meter comm.* in parameter 7009.

Mains connection

If a mains breaker is included in the application drawing, the mains breaker position must be monitored. For some power meter protocols, this is included. See the **DEIF hybrid controller compatibility** document.

Mains breaker status from the power meter protocol

The screenshot displays the M-Logic configuration interface with two logic rules, Logic 3 and Logic 4, configured for mains breaker status feedback.

Logic 3: Power meter 1 input 2 is MB closed feedback

- Event A:** NOT ☐ Mains Power meter 1 input2: Mains powe [X]
- Event B:** ☐ Not used [X]
- Event C:** ☐ Not used [X]
- Operator:** OR (dropdown)
- Delay (sec.):** 0
- Output:** MB closed feedback: External MB feedback [X]
- Enable this rule:** ☒

Logic 4: Power meter 1 input 4 is MB open feedback

- Event A:** NOT ☐ Mains Power meter 1 input4: Mains powe [X]
- Event B:** ☐ Not used [X]
- Event C:** ☐ Not used [X]
- Operator:** OR (dropdown)
- Delay (sec.):** 0
- Output:** MB open feedback: External MB feedbacks [X]
- Enable this rule:** ☒

If the mains breaker status is included in the power meter protocol, configure M-Logic to connect the output from the power meter to mains breaker feedbacks.

For DEIF mains controllers, Power meter input 2 is always used for MB closed. Power meter input 4 is always used for MB open.

Mains breaker status from digital inputs

If the mains breaker status is not included in the power meter protocol, you can configure a digital input for each breaker feedback. Digital inputs are also required if the controller controls the mains breaker. Configure the inputs in the utility software, under *I/O & Hardware setup*.

You must use digital input 47 for *MB position on* and digital input 48 for *MB position off*.

4.5.4 DEIF open communication

An external system (for example, a PLC) can use the controller Modbus server to send the controller the power measurements and connection status.



Example for two gensets

The application consists of two gensets (controlled by a PLC) and an ESS (controlled by a single controller).

1. In the utility software, on the *I/O & Hardware setup* page, under *Ext. P&Q sources*, configure two external sources. For *P source* and *Q source*, select *DEIF open communication*.

	Type	Nominal P (kW)	P source	Q source
Ext. source 1	DG	1500	DEIF open communication	DEIF open communication
Ext. source 2	DG	1500	DEIF open communication	DEIF open communication

2. Configure the PLC to connect to the controller Modbus server.
3. Configure the PLC to use the following:
 - *Genset 1 Active power*: PLC address 446151 (Modbus address 46150, function code 03)
 - *Genset 2 Active power*: PLC address 446152 (Modbus address 46151, function code 03)
 - *Genset 1 Reactive power*: PLC address 446167 (Modbus address 46166, function code 03)
 - *Genset 2 Reactive power*: PLC address 44618 (Modbus address 46167, function code 03)
 - *Genset breaker 1 Closed*: PLC address 446185, bit 0 (Modbus address 46184, bit 0, function code 03)
 - *Genset breaker 2 Closed*: PLC address 446185, bit 1 (Modbus address 46184, bit 1, function code 03)

4.5.5 Measurement transducers for genset power

The genset power (active and reactive) can be measured with transducers, and received by the controller analogue inputs, multi inputs, or a CIO 308.

Selecting the measurement transducers

In the utility software, under *I/O & Hardware setup*, *Ext. P/Q sources*, select the inputs that the transducers are connected to.

In the following example, the *Ext. source 1* power transducer is connected to Multi input 20. The reactive power transducer is connected to Multi input 21.

	Type	Nominal P (kW)	P source	Q source
Ext. source 1	GEN	0	Multi input 20	Multi input 21

Configuring the multi-input

For a multi-input, under *I/O & Hardware setup*, select the multi-input. Select the input type and scaling (for example, for active power, this can be kW 1/1 or kW 1/10). Configure the curve.

Connection status

Transducers always also need a digital input for connection status. If the power meter/genset controller does not include the connection status, you must configure a digital input.

4.5.6 Measurement transducers for mains power

The mains power (active and reactive) can be measured with transducers, and received by the controller analogue inputs, multi inputs, or a CIO 308.

Parameter	Name	Range	Default	Details
7003	Transducer range max	0 to 20000 kW	0 kW	If used, configure the mains power transducer range.
7004	Transducer range min	-20000 to 0 kW	0 kW	If used, configure the mains power transducer range.
7005	Mains power measure	Multi input 20 (transducer) 4th CT power meas (internal) DEIF open communication Power meter comm.	4th CT power meas (internal)	Select the mains power measurement.
7007	Transd. range max Q	-20000 to 20000 kvar	0 kvar	If used, configure the mains reactive power transducer range.
7008	Transd. range min Q	-20000 to 20000 kvar	0 kvar	If used, configure the mains reactive power transducer range.
7009	Mains Q measure	Multi input 22 (transducer) 4th CT power meas (internal) DEIF open communication Power meter comm.	4th CT power meas (internal)	Select the mains reactive power measurement.

Configuring the multi-input

For a multi-input, under *I/O & Hardware setup*, select the multi-input. Select the input type and scaling (for example, for active power, this can be *kW 1/1* or *kW 1/10*). Configure the curve.

Connection status

When using transducers, you always also need a digital input for the connection status.

4.5.7 Power meter monitoring

In the utility software, under *Application supervision*, select *Power meter data*  to open the *Power meter data* window.

Powermeter Data

Battery25

Powermeter data for Battery25 (ASC 150 Storage)

Meter monitoring | Genset meter | ESS meter | Mains meter

Meter number	Active power	Reactive power	Digital inputs
1	30 kW	15 kvar	0000000000000001
2	25 kW	12 kvar	0000000000000001
3	18 kW	14 kvar	0000000000000001
4	28 kW	11 kvar	0000000000000001
5	30 kW	15 kvar	0000000000000001
6	30 kW	15 kvar	0000000000000001
7	30 kW	15 kvar	0000000000000001
8	30 kW	15 kvar	0000000000000001

Total Active power DG: Total Reactive power DG:

Close

Digital inputs shows the breaker status.

For the *DEIF Genset Control* protocol, for genset breakers:

- ...**0001**: The breaker is closed.
- ...**0100**: The breaker is open.

For mains breakers (*AGC Genset single controller*, or *AGC Mains*):

- ...**0010**: The breaker is closed.
- ...**1000**: The breaker is open.

Power meter error

You can enable the power meter error alarms (menus 7730, 7740, 7750). If there is a power meter error, after the alarm timer runs out, the alarm is activated. When the alarm is activated:

- The controller clears the data for the power meter(s) that have lost communication.
 - The battery regulates as if there is no power from the corresponding external genset(s).
 - The values in the *Power meter data* window are cleared.
- You can see the communication status for all the power meters from the controller display: *Service view > Power meter view > GEN power meter*.


When power meter communication is restored (and the alarm is deactivated), the power from the external gensets is used for the battery regulation, and the power meter values are shown again.

4.6 Genset applications

4.6.1 Gensets and single storage controller (off-grid)

A single controller application is used if the gensets already have a control system (shown by *Other controller(s)* in the example).

The controller requires the GB breaker feedbacks (open or closed), and the active power from the gensets. The reactive power is optional. See **Power measurements and connection status** for the range of ways to get this information.



Setting in the controller

Parameter	Name	Setting
6071	Operating mode	Island operation

4.6.2 Start and stop external gensets

You can configure the battery/storage controller to activate an output to start and run external gensets based on the load and/or the ESS SOC. You can deactivate the output based on the load to ensure that the genset minimum load requirement is met. You can use start based on the load and/or the SOC to ensure that the load is supplied and the ESS gets enough power to charge.

When the controller activates the output to start and run one or more external gensets (*Start/Stop Ext. GEN*), the external generator controller must start the genset(s) (including synchronisation and generator breaker closing).

When the controller needs to stop the external genset(s), the controller regulates the ESS to take over the genset load. When the breaker open point is reached, the controller deactivates the output to stop the last external genset. The external generator controller should bring the genset to a controlled stop. If required, this should include a load ramp down to unload the genset. After opening the generator breaker, the generator controller should ensure that there is a cooldown sequence before stopping the genset.

Start-stop output

On the *Inputs/Outputs* page in the USW, choose a digital output to use as the output. Select the *Start/Stop Ext. GEN* function.

Alternative setup using M-Logic

You can also control the *Start/Stop Ext. GEN* output by using M-Logic, for more flexibility. For example, the request to start the genset can be used in combination with the command timers. This enables scheduling of the genset start and stop. The request to stop the gensets from M-Logic overrules any start request from the SOC, system load, and M-Logic.

You can find the M-Logic functions under *Output, Command GEN*:

- Request ext. Gen to start
- Request ext. Gen to stop

External genset breaker open

External control > External GEN start/stop

Parameter	Name	Range	Default	Description
15180	Ext. GEN breaker open	0 to 100 % of total external genset nominal power	5 %	When the total external genset power reaches this point, the controller deactivates the <i>Start/Stop Ext. GEN</i> output.

External genset start/stop alarm

External control > External GEN start/stop


Parameter	Name	Range	Default	Description
15170	Ext. GEN start error	1 to 1000 s	30 s	The alarm is activated if a genset start request is active, but the controller has not received feedback from a genset. The alarm timer also starts running if the only genset connected to the busbar is disconnected.*

NOTE * If the ESS supports it, the system can run on battery power (grid-forming) either alone, or together with solar power.

4.6.3 State of charge genset control


The controller can start and stop the genset based on the ESS state of charge (SOC).

Low state of charge genset start



When the charge is low, start the generator to avoid depleting the battery, and make sure that there is enough power for the load and charging.

High state of charge genset stop



When the charge is high and the battery can supply the load without the generator, stop the generator.


SOC start-stop parameters (for a single controller or a power management system)

External control > External GEN start/stop

Parameter	Name	Range	Default	Description
15151	SOC GEN start limit	0 to 100 % 0 to 3200 s	30 % 10 s	When the SOC goes below the start limit (and the timer has run out), the controller activates the output.
15153	SOC GEN stop limit	0 to 100 % 5 to 3200 s	50 % 15 s	When the SOC goes above the stop limit (and the timer has run out), the controller deactivates the output. If the SOC GEN stop limit is higher than SOC threshold 2, the controller shows the warning <i>SOC STOP LIM > THR 2</i> . The battery stops charging from the genset at SOC threshold 2. As a result, the battery charge never reaches the SOC GEN stop limit, and the genset is never stopped.
15155	SOC GEN control	Enabled Not enabled	Not enabled	Select <i>Enable</i> to activate the SOC GEN start function.

4.6.4 Split busbar

In a single controller application, the generators can be enabled and disabled. This is useful if the generators can connect to two busbars.



In the battery/storage controller in M-Logic, you can program whether the genset is connected to the ESS side (enabled) or connected to the side without the ESS (disabled):

Logic 1 Enable GEN 1 when input 39 is activated

Event	NOT	Operator	Delay (sec.)	Output	Enable this rule
Event A	☐	OR	0	Enable ext. GEN 1: Exter	☒
Event B	☐				
Event C	☐				


Logic 2 Disable GEN 1 when input 39 is not activated

Event	NOT	Operator	Delay (sec.)	Output	Enable this rule
Event A	☒	OR	0	Disable ext. GEN 1: Exter	☒
Event B	☐				
Event C	☐				

4.7 Mains applications

4.7.1 Mains and single storage controller (grid-tied)

This application is used to operate parallel to mains when no mains controller is installed. The battery/storage controller needs inputs from the MB feedback (open/closed) and the active and reactive power from the mains (export or import). See **Power measurements and connection status** for the range of ways to get this information.



Setting in the battery/storage controller

Basic settings > Application type > Plant type > Plant mode

Parameter	Name	Range
6071	Operating mode	Island operation Fixed power Peak shaving Main power export Automatic mains failure

4.7.2 Mains power measurement

For a single controller application, the mains active power (imported or exported) and breaker position must be measured. The reactive power is optional.

Basic settings > Measurement setup > Wiring connection > Mains power measure

Parameter	Name	Range	Default	Details
7005	Mains power measure	Multi input 20 (transducer) 4th CT power meas (internal) DEIF open communication Power meter communication	4th CT power meas (internal)	Select the measurement for the mains active power.
7009	Mains Q measure	Multi input 22 (transducer) 4th CT power meas (internal) DEIF open communication	4th CT power meas (internal)	Select the measurement for the mains reactive power.

Parameter	Name	Range	Default	Details
		Power meter communication		



More information

See **Power measurements and connection status** for the range of ways to get this information.

4.7.3 Mains breaker handling in single controller applications

The controller can control one mains breaker in a single controller application. However, if there is more than one mains connection, the controller cannot control a mains breaker.

Synchronising the mains breaker

To synchronise the mains breaker without a blackout:

- The battery must be grid-forming.
- Externally controlled gensets must be disconnected.
- Back synchronisation (parameter 7083) and sync. to mains (parameter 7084) must be enabled.

Busbar blackout rules

To close the mains breaker when there is no voltage or frequency on the busbar:

- For safety, the controller checks that there is no voltage or frequency on the busbar. For example, voltage could come from externally controlled gensets.
- If there is an ESB, to confirm that there is no voltage, the controller closes the ESB. The controller can then use its AC measurements to check the busbar voltage and frequency.
- Once the controller has confirmed that there is no voltage or frequency on the busbar, it can close the mains breaker.

Mains failure

You can configure the mains failure detection voltages (parameter 7063, 7064), frequencies (parameter 7073, 7074) and hysteresis (parameters 7091, 7092, 7093, 7094).


There are mains failure voltage (parameter 7061) and frequency (parameter 7071) alarms.

If the storage controller must automatically open the mains breaker during a mains failure, you must enable mode shift (parameter 7081).

4.8 Combination (off-grid + grid-tied)

This application is used when a single controller application is used in both grid-tied and off-grid (islanded) modes. In this example, third party controllers are installed (shown by *Controller* in the diagram).

The controller needs the mains power and reactive power, and the gensets power and reactive power. The controller also needs feedback from the breakers (GBs and MB). See **Power measurements and connection status** for the range of ways to get this information.



Setting in the storage controller

Basic settings > Application type > Plant type > Plant mode

Parameter	Name	Range
6071	Operating mode	Island operation Fixed power Peak shaving Mains power export Automatic mains failure

From grid-tied to off-grid

If *Mode shift on* is selected (*Modeshift*, parameter 7081), then the controller automatically changes the operating mode. When the mains breaker is opened, the mode changes to *Island operation*. Note that you can use M-Logic to set parameter 7081.

NOTE If the battery is the only power source on the busbar, and if the PCS does not support seamless transfer between modes, there will be a short blackout during the mode transfer.

5. Energy management systems

5.1 Overview

Controllers from iE 150, ASC and AGC 150, AGC-4 Mk II and AGC-4, and ASC-4 (that is, battery/storage, solar, genset, mains, BTB, and ALC-4 controllers) can work together as an energy management system. The application configuration and controller parameters allow a wide range of applications.


The controllers use CAN bus to share the information needed for energy management. In AGC-4 Mk II and AGC-4, option G5 is required for energy management.



Quick overview

See [DEIF - Hybrid Solutions](#) for a quick introduction to energy management systems.

Example of energy management system



Controller functions

Controller	Controls	Functions
Solar	PV	• P and Q control • Control photovoltaic (PV) breaker* • Inverter communication
Battery/Storage	ESS	• P-Q control, V-f control, and droop (VSG) • Energy storage system charging and discharging • Control energy storage system (ESS) breaker* • Energy storage system communication
Genset	Genset	• Governor control

Controller	Controls	Functions
		• AVR control • Control genset breaker • ECU communication
Mains	Mains connection	• Power import or export • Control mains breaker*, tie breaker* • Synchronise the plant to the mains
ALC	Load groups	• Connect and disconnect load groups • Manage heavy consumer requests

NOTE * Optional.

5.2 Power management applications

The battery/storage controller can be included in power management (also known as energy management). This allows mains, gensets, PV and/or ESS to work together in an integrated system. Power management can include:

1. Automatic rotation of genset priority.
2. Fuel-optimised genset priority.
3. Control of plant spinning reserve.
4. Flexible application support with common grid-tied, combination, and off-grid applications.

Battery/storage controller and ESS on the utility software application drawing

The battery/storage controller controls and monitors the ESS. In the application single line drawing, each battery/storage controller is shown as a battery.

Breaker control

The battery/storage controller can control an ESS breaker like a genset controller controls a generator breaker. One battery/storage controller can control one ESS breaker.

If the ESS is grid-following, the ESS breaker can close when the busbar is live and Hz/voltage is normal. If the busbar is outside its limits, the controller can open the ESS breaker but not close it. If the controller is in AUTO mode, the controller closes the breaker when the busbar is live. The ESS then starts. The controller does not require a manual start signal if AUTO is selected.

In MANUAL mode, an operator must press the breaker close and start buttons on the display unit. Alternatively, this signal can be sent by Modbus, digital input, and so on.

5.2.1 Power management operation

The battery/storage controller follows the operation of the mains controller: Island, fixed power, mains power export, peak shaving, or load take-over (grid-tied or off-grid). If there is no mains controller in the application, the plant uses island operation (off-grid).

5.2.2 System limitations

For power management, the number of controllers in an application is limited.

Controller	Maximum number
Genset	32
Mains	32
Solar	16

Controller	Maximum number
Battery/storage	16
ALC-4	8
BTB/Externally-controlled BTB	8

Controller ID allocation and sharing

ID 1 to 24	ID 25 to 32	ID 33 to 40
Genset (1 to 32)		
Mains (1 to 32)		
		Solar (25 to 40)
		Battery/Storage (25 to 40)
		ALC-4 (25 to 40)
		BTB (33-40)
		External BTB (33-40)




Example

If you have a system with one mains feeder, then you have $(32 - 1) = 31$ IDs left for the gensets. If you have two mains feeders, you have $(32 - 2) = 30$ IDs left for the gensets.

If you have a system with 14 battery, storage and/or solar controllers, you can have $(16 - 14) = 2$ bus tie breakers.

5.2.3 Off-grid applications

5.2.3.1 Off-grid with solar and battery




Battery/storage and solar controller configuration

Basic settings > Application type > Plant type > Plant mode

Parameter	Name	Setting
6071	Operating mode	Power management

5.2.3.2 Off-grid with genset(s) and battery



To improve power quality, the ESS can supply peak loads while gensets start. The battery/storage controller can support the load, so that the genset can run at its optimal load point. If the ESS is designed to supply the busbar load, the ESS can be the only source connected to the busbar.

Battery/storage controller configuration

Basic settings > Application type > Plant type > Plant mode


Parameter	Name	Setting
6071	Operating mode	Power management

Genset controller configuration

Basic settings > Application type > Genset type > Genset/plant mode

Parameter	Name	Setting
6071	Operating mode	Power management

5.2.3.3 Off-grid with genset(s), solar and battery



Battery/storage and solar controller configuration

Basic settings > Application type > Plant type > Plant mode

Parameter	Name	Setting
6071	Operating mode	Power management


Genset controller configuration

Basic settings > Application type > Genset type > Genset/plant mode

Parameter	Name	Setting
6071	Operating mode	Power management

5.2.4 Grid-tied applications

5.2.4.1 Grid-tied battery



Battery/storage controller configuration

Basic settings > Application type > Plant type > Plant mode


Parameter	Name	Setting
6071	Operating mode	Power management

Mains controller configuration

Basic settings > Application type > Plant type > Plant mode

Parameter	Name	Setting
6070	Plant mode	Select a plant mode (in the mains controller). For example, Mains Power Export.

5.2.4.2 Grid-tied genset-battery



Battery/storage controller configuration

Basic settings > Application type > Plant type > Plant mode

Parameter	Name	Setting
6071	Operating mode	Power management

Genset controller configuration

Basic settings > Application type > Genset type > Genset/plant mode


Parameter	Name	Setting
6071	Operating mode	Power management

Mains controller configuration

Basic settings > Application type > Plant type > Plant mode

Parameter	Name	Setting
6070	Plant mode	Select a plant mode (in the mains controller). For example, Mains Power Export.

5.2.4.3 Grid-tied solar-battery



Battery/storage and solar controller configuration

Basic settings > Application type > Plant type > Plant mode


Parameter	Name	Setting
6071	Operating mode	Power management

Mains controller configuration

Basic settings > Application type > Plant type > Plant mode

Parameter	Name	Setting
6070	Plant mode	Select a plant mode (in the mains controller). For example, Mains Power Export.

5.2.4.4 Grid-tied solar-genset-battery



Battery/storage, solar, and genset controller configuration

Basic settings > Application type > Plant type > Plant mode


Parameter	Name	Setting
6071	Operating mode	Power management

Mains controller configuration

Basic settings > Application type > Plant type > Plant mode

Parameter	Name	Setting
6070	Plant mode	Select a plant mode (in the mains controller). For example, Mains Power Export.

5.2.4.5 Multi-mains with battery



Battery/storage controller configuration

Basic settings > Application type > Plant type > Plant mode

Parameter	Name	Setting
6071	Operating mode	Power management


Mains controller configuration

Basic settings > Application type > Plant type > Plant mode

Parameter	Name	Setting
6070	Plant mode	Select a plant mode (in the mains controller). For example, Mains Power Export.

5.2.5 Combination (off-grid + grid-tied)

This application is used for grid-tied and off-grid (islanded) modes.



In a power management combination application, the battery/storage controller can have the following modes of operation:

- Mains breaker open (that is, off-grid):
 - Island operation
 - AMF (Automatic Mains Failure)
- Mains breaker closed (that is, grid-tied):
 - MPE (Mains Power Export)
 - Peak shaving
 - Fixed power

Battery/storage and genset controller configuration

Basic settings > Application type > Plant type > Plant mode

Parameter	Name	Setting
6071	Operating mode	Power management

Mains controller configuration

Basic settings > Application type > Plant type > Plant mode

Parameter	Name	Setting
6071	Plant mode	Select a plant mode (in the mains controller). For example, Mains Power Export.

5.3 Configure power management

5.3.1 Power management communication

5.3.1.1 CAN connections

The CAN line wiring between controllers must be a daisy chain connection. The line must be a continuous communication bus, and it cannot be mixed with the other communication.



More information

See **CAN bus power management system** in the **Installation instructions** for wiring recommendations.

5.3.1.2 Using Ethernet for power management

You can use Ethernet connections for power management communication redundancy.

In the utility software, on the *Ethernet setting (TCP/IP)* page, select *Power management*.

The screenshot shows the DEIF utility software interface. On the left is a sidebar with the DEIF logo and a menu containing 'Monitoring', 'Configuration', and 'Tools'. Below the menu is a button labeled 'Ethernet setting (TCP/IP)'. The main window has a toolbar with icons for file operations and a tabbed interface with 'Network parameters', 'Remote Display', 'Power Management', and 'NTP parameters'. The 'Power Management' tab is active, displaying two input fields: 'IP address' with the value '239.255.2.252' and 'Port' with the value '22001'.

For each controller in the power management system:

1. Select the same IP address for the controllers to broadcast to, and the port.
 - The IP address must be in the range 239.255.xxx.xxx.
2. In parameter 7843 (*VCAN C Protocol*), select *PMS Primary* or *PMS Secondary*.

5.3.2 Easy connect

If the application consists of only genset, battery/storage, and/or solar controllers, Easy connect is a fast and easy way to add more controllers to a new or existing application. Easy connect commands normally come from the display, but they can also be sent from M-Logic and Modbus. You can also use Easy connect to remove genset, battery/storage, and/or solar controllers.

Preconditions

- All controllers in the application have the same software version.
 - You can use Easy connect for an application with a mix of iE 150, AGC 150, ASC 150, AGC-4 Mk II, and AGC-4. All the controllers must support the same Easy connect functions.

- Easy connect is enabled in all controllers in parameter 8023, or *M-Logic Output, Easy connect, Enable Easy connect*.
- For genset controllers, in *Quick setup mode* (parameter 9186), select *Setup plant*.
- For battery/storage and solar controllers, in *Quick setup mode* (parameter 9181), select *Setup plant*.
- The genset, ESS or PV to be added or removed is not running.

Activate Easy connect

If the preconditions are met, the Easy connect sequence is activated whenever:

- Easy connect is enabled in parameter 8023.
- A controller powers up.
- The CAN conditions change (that is, if a controller is added or removed).

Power management > Easy connect

Parameter	Text	Range	Default
8023	Easy connect	OFF ON	OFF

Using Easy connect

Once the Easy connect sequence starts, the operator cannot use the display unit to change parameters. Configure the parameters as required before the sequence starts, or use the utility software.

If a controller must be removed and another controller must be added to the plant, always first remove the controller then add the new controller.


NOTICE



Give the controllers enough time to make changes

When a controller is added or removed, the controllers use approx. one minute time to apply the change. When *Receiving application* is shown, do not add or remove more controllers. Making multiple simultaneous changes can reset the application.


Configuring a new application or adding new genset controllers



1. The preconditions are met, and the Easy connect sequence is activated.
2. **Go to the first controller:** The first controller keeps its CAN ID and is *GEN1*.
3. **Start new plant:** The display unit for the first controller prompts *START NEW PLANT?*:
 - Select *Yes*: The first controller starts a new application configuration.
 - Select *No*: The first controller goes into stand-alone mode with *GEN blocked for start*.
4. **Go to next controller:** The operator can connect the CAN line and power up the next controller.
5. **Add to CAN PMS:** The new controller checks the PMS CAN line for another controller. The new controller gets the lowest available CAN ID. The new controller prompts *ADD GEN TO CAN PMS?*.
 - Select *Yes*: The controller is added to the application.
 - Select *No*: The controller goes into stand-alone mode with *GEN blocked for start*.
6. If additional controllers are detected, steps 4 and 5 repeat. Otherwise, the sequence ends.

NOTE If you need to add another controller later, that controller must not be powered before the CAN line is connected. When the controller power is connected, Easy connect is activated, and the controller can be added to the application.

Removing genset controllers



1. **Disconnect controller from CAN line:** The controller to be removed from the plant is disconnected from the CAN bus, or the controller is powered down.
2. **Setup stand-alone:** If still powered, the disconnected controller prompts *SETUP STAND-ALONE?*:
 - Select *Yes*: The controller is disconnected from the plant.
 - Select *No*: The controller waits to be reconnected to the CAN line. When this happens, the controller automatically reestablishes the CAN PMS connection.
3. **Go to another controller in the plant:** The displays of all the remaining controllers in the plant prompt *REM. GEN ## CAN PMS?*.
4. **Remove GEN ##:** From the display of any remaining controller:
 - Select *Yes*: The disconnected controller is removed from the plant. The related alarms are cleared from all the remaining controllers.
 - Select *No*: The other controllers wait for the disconnected controller to be reconnected to the CAN line. When this happens, the controllers automatically reestablish the CAN PMS connection.

M-Logic commands and events

As an alternative to using the display for Easy connect, the following commands are available under *M-Logic, Output, Easy connect*:

Controller	Command	Description
Genset only	Add GEN	The user can connect multiple genset controllers to the CAN bus, then use this command to add each genset controller to the application.
Genset only	Remove GEN	The user can use this command to remove a genset controller from the application, without the need to disconnect the CAN bus.
Storage only	Add ESS	The user can connect multiple storage controllers to the CAN bus, then use this command to add each battery/storage controller to the application.
Storage only	Remove ESS	The user can use this command to remove a battery/storage controller from the application, without the need to disconnect the CAN bus.
Solar only	Add PV	The user can connect multiple solar controllers to the CAN bus, then use this command to add each solar controller to the application.
Solar only	Remove PV	The user can use this command to remove a solar controller from the application, without the need to disconnect the CAN bus.
All	Select yes on display	This command selects YES if there is a "YES/NO" prompt on the display.
All	Select no on display	This command selects NO if there is a "YES/NO" prompt on the display.
All	Enable Easy connect	The user can activate the Easy connect function with this command.
All	Disable Easy connect	The user can deactivate the Easy connect function with this command.

The following events are available under *M-Logic, Events, Easy connect*:

Event	Description
Plant active	Activated for an Easy connect plant.
Stand alone	Activated for a stand-alone (single controller) application.

Setting up the controller for a single controller application

You can also use Easy Connect to set up the controller for a single controller application.

- For genset controllers, in *Quick setup mode* (parameter 9186), select *Setup stand alone*.
- For battery/storage and solar controllers, in *Quick setup mode* (parameter 9181), select *Setup stand alone*.

5.3.3 Using utility software to create the application

5.3.3.1 Controller IDs

After connecting the CAN bus communication, each controller must have a unique internal communication ID. With Easy Connect, the controllers set the IDs automatically.

For manual setup, you must set the controller ID in each controller.

Communication > Power management ID

Parameter	Text	Range	Default
7531	PM CAN ID	25 to 40	25

5.3.3.2 Application configuration

When the IDs are configured, you can configure the application with the utility software.

Connect to a controller with the PC utility software, then select *Application configuration*. In the top taskbar, select *New plant configuration* . The *Plant options* window opens.

Plant options

Product type

ASC 150 Storage

Plant type

Standard

Application properties

☒ Active (applies only when performing a batchwrite)

Name:

New plant

Bus Tie options

☐ Wrap bus bar

Power management CAN

☒ Primary CAN

☐ Secondary CAN

☐ Primary and Secondary CAN

☐ CAN bus off (stand-alone application)

Application emulation

☒ Off


☐ Breaker and engine cmd. active

☐ Breaker and engine cmd. inactive

OK

Cancel

Plant options

	Description	Comments
Product type	The controller type is selected here.	This function is greyed out if a controller is already connected.
Plant type	- Single controller - Standard	Select <i>Standard</i> for power management systems. If <i>Single controller</i> is selected, the CAN ports for power management communication are turned off.
Application properties	The application is activated when it is written to the controller. Name the application.	Naming the application can be helpful, if the controller is in a plant where the controller will switch between applications. The controllers can switch between four different applications. Controllers connected to each other by CAN bus communication cannot have different applications or numbers.
Bus tie options	Select the <i>Wrap bus bar</i> option.	Activate this option if the busbar is connected as a ring connection in the application. When the wrap busbar is selected, it is shown like this: 
Power management CAN	Primary CAN Secondary CAN Primary and secondary CAN CAN bus off	<i>Primary CAN</i> must be used, if the Power Management CAN bus is wired to CAN port B on each controller. <i>Primary and secondary CAN</i> is only used for redundant CAN bus communication lines for power management. If this setting is selected and only one line is present, an alarm is activated. This alarm cannot be cleared. Note: Select <i>Primary and secondary CAN</i> if you are using Ethernet for power management communication redundancy.

	Description	Comments
		<i>CAN bus off</i> should only be used if the controller is in a single controller application.
Application emulation	Off Breaker and engine cmd. active Breaker and engine cmd. inactive	Turn on emulation here.

You can now create the application drawing in the controllers. From the left side of the page, you can add controllers to the configuration. You can also select the type of breakers in the application.

Area control

Plant totals

<

Area 1 of 1

>

Area configuration - Top

Source

Mains

2

▼

ID

32

3

▲

▼

MB

Pulse

4

▼

TB

Pulse

5

▼

Normally open

6

▼

Middle

☒ BTB

Pulse

8

▼

7

ID

33

9

▲

▼

Normally open

10

▼

Vdc breaker

11

▼

☐ Under voltage coil

12

Bottom

Source

Diesel gen

13

▼

ID

1

14

▲

▼

GB

Pulse

15

▼

< Add 1

Delete


Add > 1

Plant configuration options

No.	Name	Description
1	Add/Delete	Add and delete areas. Adding areas makes the application configuration/plant bigger.
2	Source	Select the type of power source for the top area (None, Mains, Diesel gen, Photovoltaic, LG or Battery).
3	ID	Set the ID. This ID should correspond to the internal communication ID (parameter 7531) in the controller.

No.	Name	Description
4	MB	Mains is selected as the source (no. 2), so it is possible to select the type of breaker for the mains breaker (Pulse, Ext/ATS no control, Continuous NE, Compact, None, Continuous ND).
5	TB	Mains is selected as the source (no. 2), so it is possible to select the type of breaker for the tie breaker (Pulse, Continuous NE, Compact, None).
6	-	Select whether the tie breaker is <i>Normally open</i> or <i>Normally closed</i> .
7	BTB	Select to add a BTB controller.
8	-	The type of bus tie breaker (Pulse, Ext, Continuous NE, Compact). Select <i>Ext</i> for an externally controlled BTB, that is, there is no AGC BTB controller. The bus tie breaker position feedbacks must be connected to any controller in the power management system.
9	ID	Set the ID. This ID should correspond to the internal communication ID (parameter 7531) in the controller.
10	-	Select whether the BTB is <i>Normally open</i> or <i>Normally closed</i> .
11	-	If <i>Vdc breaker</i> is selected, the breaker can open and close when there is no voltage on the busbar. If <i>Vac breaker</i> is selected, voltage must be present on the busbar before the breaker can be handled.
12	Under voltage coil	Select this if the BTB has an under-voltage coil.
13	Source	Select the type of power source for the bottom area (None, Mains, Diesel gen, Photovoltaic, LG or Battery).
14	ID	Set the ID. This ID should correspond to the internal communication ID (parameter 7531) in the controller.
15	GB	In this example, diesel genset is selected as the source (no. 13), so it is possible to select the type of breaker for the genset breaker (Pulse, Continuous NE, Compact).

Application configuration example



After you have created the application, send it to the controllers. Select *Write plant configuration to the device* . After this, only the controller connected to the PC utility software has the application configuration.

The application configuration can then be sent from this controller to all the other controllers. Select *Broadcast plant application* .

5.4 Power management functions

5.4.1 ESS power reference

The energy storage system (ESS) gets a power reference from the battery/storage controller. The controller can transmit the power reference to the ESS. Alternatively, the ESS can read the power reference from the controller (DEIF Open).

Calculating the ESS power reference

The ESS power reference is based on the ESS state of charge, the ESS operation, the controller parameters, and the operation of the energy management.



More information

See **Storage controller functions** for information on the ESS state of charge, ESS operation, and controller parameters.



More information

See **Storage controller functions, Regulation, Power reference** for information on the ESS power reference.

Stop all gensets

In grid-tied modes (for example, peak shaving or fixed power), the plant can be set up to stop all engines. For the genset controllers, configure the minimum number of gensets to run (multi-start) as **0**.



More information

See the **AGC Parameter list** for the genset multi-start parameters.

5.4.2 Spinning reserve

Spinning reserve ensures that the power management system is always able to supply the required power. Spinning reserve is the power that is immediately available.

You can configure spinning reserve in a battery/storage controller. This is a global parameter. That is, the power management system shares this value to the genset controllers and battery/storage controllers to ensure that the spinning reserve is available.

NOTE The battery/storage controller spinning reserve is not related to the solar controller spinning reserve.

Available power

The power management system uses **available power** in its genset start and stop calculations.

Available power = Genset nominal power - Load. Available power is thus power from gensets.

To be included in the available power, a genset must be:

- Controlled by a genset controller in AUTO mode
- Running and connected to the busbar

Spinning reserve

The *Total available power* in the system, including the generating capacity of batteries, is useful to the plant. This is the **spinning reserve**.

Spinning reserve = (Genset) Available power + Battery generating capacity

To be included in the spinning reserve:

- The battery must be controlled by a battery/storage controller in AUTO mode.
- The ESS must be ready.
- Discharging the battery must be allowed.

Parameters

Power management > Spinning reserve

Parameter	Name	Range	Default	Details
8930	Spinning Res.	0 to 30000 kW	100 kW	This is a global power management system parameter, shared with all the other controllers. This ensures that if the battery/storage controller breaks down, the rest of the system compensates for the lack of energy from the battery.

External control > GEN reverse power alarms

Parameter	Name	Range	Default	Details
15070	GEN P<1	-200 to 100 % 0.1 to 3200 s	-5 % 10 s	This alarm is activated if the genset power falls below the set point.
15080	GEN P<2	-200 to 100 % 0.1 to 3200 s	-5 % 10 s	This alarm is activated if the genset power falls below the set point.

External control > GEN spinning reserve alarms

Parameter	Name	Range	Default	Details
15090	Spinning res. 1	0 to 100 % 0.1 to 3200 s	30 % 10 s	Activate the alarm if the spinning reserve falls below this percentage of the value set in parameter 8931.
15100	Spinning res. 2	0 to 100 % 0.1 to 3200 s	10 % 10 s	Activate the alarm if the spinning reserve falls below this percentage of the value set in parameter 8931.

Example: Off-grid genset and battery application

One battery and five gensets

Battery generating capacity = 0.4 MW

Nominal power for each genset = 1.5 MW

Spinning reserve required = 1.0 MW

Genset load-dependent start set point = 90 %

Genset load-dependent stop set point = 85 %

1. Site load = 3.5 MW, three gensets running.
 - Available power = $3 \times 1.5 \text{ MW} - 3.5 \text{ MW} = 4.5 \text{ MW} - 3.5 \text{ MW} = 1 \text{ MW}$.
 - Available spinning reserve = $1 \text{ MW} + 0.4 \text{ MW} = 1.4 \text{ MW}$.
 - The spinning reserve requirement is met.
2. A load of 0.5 MW is suddenly added.
 - Site load = 4.0 MW.
 - Genset load = $4.0 \text{ MW} / 4.5 \text{ MW} = 89 \%$. The genset load-dependent start requirement is not met.
 - Available spinning reserve = $4.5 \text{ MW} - 4.0 \text{ MW} + 0.4 \text{ MW} = 0.9 \text{ MW}$. The spinning reserve requirement is not met. The power management system therefore starts another genset.
 - Available spinning reserve = $4 \times 1.5 \text{ MW} - 4.0 \text{ MW} + 0.4 \text{ MW} = 2.4 \text{ MW}$. The spinning reserve requirement is met. No more gensets start.
3. The total site load falls to 3.6 MW.
 - Can a genset stop?
 - If one genset stopped, the load on the remaining three gensets would be $3.6 \text{ MW} / 4.5 \text{ MW}$, or 80 %. A load-dependent stop is therefore possible, subject to the spinning reserve requirement.
 - If one genset stopped, the available spinning reserve would be $4.5 \text{ MW} - 3.6 \text{ MW} + 0.4 \text{ MW} = 1.3 \text{ MW}$.
 - The spinning reserve requirement would therefore also be met if the genset stopped.
 - The genset can therefore stop.

Example: Off-grid genset and energy storage system; half of storage capacity trips

Two 1 MW batteries, and ten gensets

Total battery generating capacity = 2 MW

Nominal power for each genset = 1.5 MW

Spinning reserve required = 3.5 MW

Genset load-dependent start set point = 90 %

Genset load-dependent stop set point = 70 %

1. Site load = 10 MW, eight gensets running.
 - Site load = 10 MW

- Available spinning reserve = $8 \times 1.5 \text{ MW} - 10 \text{ MW} + 2 \text{ MW} = 4 \text{ MW}$.
 - The spinning reserve requirement is met.
2. One of the batteries trips, and can therefore no longer be included in the spinning reserve. The total battery generating capacity is now 1 MW.
- Available spinning reserve = $12 \text{ MW} - 10 \text{ MW} + 1 \text{ MW} = 3 \text{ MW}$
 - The spinning reserve requirement is not met, and so the power management system must start another genset.


5.4.2.1 Alarms for spinning reserve

Two alarms are available for the spinning reserve function (menus 15090 and 15100). These alarms can be used in power management applications or single controller applications.

The alarms can be configured to activate above or below the set point, along with a set point, timer, and fail class.

Using the spinning reserve alarm to start the next genset

If there is no power management system, you can configure one of the spinning reserve alarm's outputs to send a start command to the next genset. This is shown in the diagram and screenshot below. The digital output on terminal 5 of the battery/storage controller is configured to activate if the spinning reserve is too low. The battery/storage controller terminal 5 is wired as a start input to the genset controller.



NOTE Select *Auto acknowledge* to automatically deactivate the output when the spinning reserve required is available again. Select *Enable* to enable the alarm.

Using the spinning reserve alarm for load management

You can configure the spinning reserve alarm to send a signal to disconnect load groups.

5.4.3 Default load sharing in multi-battery applications

By default, if more than one ESS is present, the energy management balances the production between the energy storage systems that are running or ready to start. The load sharing is firstly based on the ESS state of charge (SOC). That is, the ESS that needs to charge/discharge more to reach the required SOC is given priority. If both ESS have the same SOC stage, the load sharing is based on nominal apparent power.



Example of ESS load sharing

The system consists of two ESS and three gensets. The ESSs are used to ensure that the gensets run at the minimum load (40 % of nominal power). The nominal apparent power for ESS A is 500 kVA, and for ESS B it is 200 kVA. The nominal power for each genset is 500 kW.

The plant load is 300 kW, and two gensets are running. The battery state of charge conditions allow charging, and the SOC is the same in both systems. ESS A has a charging capacity of 150 kW, while ESS B has a charging capacity of 50 kW.

For the gensets run at the minimum load, each genset must run at 40 % x 500 kW = 200 kW. In total, the gensets must run at 2 x 200 kW = 400 kW. The batteries therefore need to use 400 kW - 300 kW = 100 kW for charging.

ESS A therefore uses $100 \text{ kW} \times 150 \text{ kW} / (150 \text{ kW} + 50 \text{ kW}) = 75 \text{ kW}$ to charge, while ESS B uses 25 kW to charge.

5.4.4 SOC balancing in multi-battery applications

State-of-charge (SOC) balancing is for applications where multiple ESS are running in parallel. Each ESS gets a weighted share of the load, depending on its distance from the plant SOC. The user can select the SOC balancing function most suited to their application. Parameters are also available to adjust the weighting in each controller for charging and discharging.

Restrictions

For SOC balancing to work:

- SOC balancing (parameter 8201) must be enabled in all battery/storage controllers.
- The mains charging (parameters 17022 to 17025), PV charging (parameter 17041), and genset charging (parameters 17031 to 17033) parameters must be the same in all controllers.
- The ESS operation mode (parameter 17081) (Battery leading, or Battery assisting) must be the same in all controllers.
- Maintenance charge (parameter 17400) must not be enabled in any controller.
- You must not use these M-Logic outputs in any controller: Force discharge, Force charge, Freeze discharge, or Freeze charge.
 - You can however use these M-Logic outputs: Plant Force Discharging, Plant Force Charging, Plant Freeze Discharging, and Plant Freeze Charging.

Parameters

Power management > SOC balancing

Parameter	Name	Range	Default	Details
8201	SOC balancing	Not enabled, Enabled	Not enabled	Enabled: All ESS charge/discharge as a single ESS.
8201	SOC balancing	Proportional Exponential Nominal Nominal exponential	Proportional	The function to balance the SOC in the plant, by calculating the weight for each ESS. These parameters must be the same in all controllers. See the sections below for descriptions and examples of each function.
8202	Plant SOC max *	0 to 100 %	90 %	The plant must not charge when this maximum is reached.

Parameter	Name	Range	Default	Details
				Parameter 8202 (SOC balancing) corresponds to parameters 17052/17062/17072 (without SOC balancing).
8203	Plant SOC thr. high *	0 to 100 %	80 %	Below the high threshold, the plant can discharge as battery assisting until the SOC reaches the minimum. The plant must then recharge to the low threshold before the ESS can discharge again. Below the high threshold, the plant can discharge as battery leading until the SOC reaches the low threshold. The plant must recharge to the high threshold before it can be battery leading again. Parameter 8203 (SOC balancing) corresponds to parameters 17054/17064/17074 (without SOC balancing).
8204	Plant SOC thr. low *	0 to 100 %	40 %	Below the low threshold, the plant can discharge as battery assisting until the SOC reaches the minimum. The plant must then recharge to the low threshold before the ESS can discharge again. Below the low threshold, the plant cannot discharge as battery leading. The plant must recharge to threshold high before the ESS can be battery leading again. Parameter 8204 (SOC balancing) corresponds to parameters 17053/17063/17073 (without SOC balancing).
8205	Plant SOC min *	0 to 100 %	20 %	The plant must not discharge when this minimum is reached. The ESS are not allowed to provide any power until the SOC reaches threshold low. Parameter 8205 (SOC balancing) corresponds to parameters 17051/17061/17071 (without SOC balancing).

NOTE * These parameters are used as the SOC thresholds for each controller, and also as the SOC threshold for the whole plant. These parameters must be the same in all controllers.

Power management > SOC balancing > SOC balancing tuning

If needed, use these parameters to tune the load sharing for each controller and its ESS.

Parameter	Name	Range	Default	Details
8211	Discharge tuner	0.1 to 2.0	1.0	For discharging: For values above 1.0, the ESS of this controller discharges more than other ESS. For values below 1.0, the ESS discharges less.
8212	Charge tuner	0.1 to 2.0	1.0	For charging: For values above 1.0, the ESS of this controller charges more than other ESS. For values below 1.0, the ESS charges less.

Proportional

When **Proportional** is selected in parameter 8201, the weight for each ESS is proportional to the distance between its own SOC and the targeted SOC. This function is more passive, and ideal for ESS that have the same capacities and/or discharge/charge rates.



Proportional SOC balancing example

The plant has four ESS and needs 1000 kW from them. The SOC of Battery 25 is 100 %. The SOC of Battery 26 is 90 %. The SOC of Battery 27 is 80 %. The SOC of Battery 28 is 70 %.

The plant SOC is $(100 + 90 + 80 + 70) \% / 4 = 85 \%$.

The load on Battery 25 is 333 kW, Battery 26 is 278 kW, Battery 27 is 222 kW, and Battery 28 is 167 kW.

Exponential

When **Exponential** is selected in parameter 8201, the weight for each ESS is exponentially proportional to the distance between its own SOC and the targeted SOC. This function is more aggressive, and ideal for ESS that have different capacities and/or discharge/charge rates.



Exponential SOC balancing example

The plant has four ESS and needs 1000 kW from them. The SOC of Battery 25 is 100 %. The SOC of Battery 26 is 90 %. The SOC of Battery 27 is 80 %. The SOC of Battery 28 is 70 %.

The plant SOC is $(100 + 90 + 80 + 70) \% / 4 = 85 \%$.

The load on Battery 25 is 500 kW, Battery 26 is 433 kW, Battery 27 is 59 kW, and Battery 28 is 8 kW.

Nominal

When **Nominal** is selected in parameter 8201, the weight for each ESS is proportional to the distance between its own SOC and the targeted SOC, and also proportional to its nominal capacity. This function is more passive, and ideal for ESS that where there is a correlation between their capacities and their discharge/charge rates.



Nominal SOC balancing example

The plant has four ESS and needs 1000 kW from them. The SOC of Battery 25 is 100 %, and its capacity is 600 kVAh. The SOC of Battery 26 is 90 %, and its capacity is 480 kVAh. The SOC of Battery 27 is 80 %, and its capacity is 360 kVAh. The SOC of Battery 28 is 70 %, and its capacity is 240 kVAh.

The plant SOC is $(100 + 90 + 80 + 70) \% / 4 = 85 \%$.

The load on Battery 25 is 441 kW, Battery 26 is 294 kW, Battery 27 is 176 kW, and Battery 28 is 88 kW.

Nominal exponential

When **Nominal exponential** is selected in parameter 8201, the weight for each ESS is exponentially proportional to the distance between its own SOC and the targeted SOC, and also proportional to its nominal capacity. This function is more aggressive, and ideal for ESS that have different capacities and different discharge/charge rates.



Nominal exponential SOC balancing example

The plant has four ESS and needs 1000 kW from them. The SOC of Battery 25 is 100 %, and its capacity is 600 kVAh. The SOC of Battery 26 is 90 %, and its capacity is 480 kVAh. The SOC of Battery 27 is 80 %, and its capacity is 360 kVAh. The SOC of Battery 28 is 70 %, and its capacity is 240 kVAh.

The plant SOC is $(100 + 90 + 80 + 70) \% / 4 = 85 \%$.

The load on Battery 25 is 500 kW, Battery 26 is 400 kW, Battery 27 is 92 kW, and Battery 28 is 8 kW.

5.4.5 ESS is the isochronous source

The ESS can act as the isochronous source in grid-forming mode in an application with gensets. This function is used in PMS applications that are off-grid (mains breaker open).

This function can be activated using parameter 8041 (see below) or M-Logic Output > Command Battery > Enable ESS isochronous mode (and deactivated by Disable ESS isochronous mode).

Parameters

Power management > PMS isochronous master

Parameter	Name	Range	Default	Details
8041	PMS Isochr. master	Not enabled, Enabled	Not enabled	Enabled: The battery/storage controller regulates the ESS to be the controlling isochronous master in an off-grid application with gensets. This means that the system voltage and frequency are set by the ESS, and the genset controllers use fixed power regulation. If this parameter is enabled in more than one battery/storage controller in the application, then the battery/storage controller with the lowest PMS ID is the isochronous master. Not enabled: For the off-grid application, the genset controllers use island regulation.
8042	PMS Isochr. mode req	V/f mode only V/f or droop mode	V/f mode only	V/f mode only (recommended): The ESS must be in voltage-frequency mode before starting to run as the isochronous source. V/f or droop mode*: The ESS can run in voltage-frequency mode or droop mode before starting to run as the isochronous source.
8043	PMS Isochr. Q ctrl	OFF, GEN cosphi lim	OFF	For off-grid: Select the mode for reactive power regulation between the ESS isochronous master and the gensets. Use the same value in all controllers that have PMS isochronous master enabled. GEN cosphi lim: The controller uses the GEN cosphi lim parameters (7031 and 7032) to control the reactive power from the ESS. Use the same values in all controllers that have PMS isochronous master enabled.
8044	PMS Iso. loadshare	Not enabled, Enabled	Not enabled	If enabled, and there is another battery ready for load sharing, then the PMS isochronous master follows ramps. This ensures that the ESS does not take the whole load instantly.

NOTE * This is only recommended for advanced customers. To avoid producing power at the wrong voltage and/or frequency, extra regulation and tuning may be required in the PCS.

5.4.6 Genset management

5.4.6.1 Genset load-dependent start and stop

The genset load-dependent start and stop (LDSS) parameters are configured in the AGC Genset controller. You can configure two sets of LDSS parameters in each AGC Genset controller.

If the ESS is available, the energy management system can be configured to tell the AGC Genset to use the first set of LDSS parameters. These parameters can therefore be set higher, since the ESS contributes to the spinning reserve. For example, the load-dependent start point can be 95 %, while the load-dependent stop is 75 %.

If the ESS is not available, the energy management system can be configured to tell the AGC Genset to use the second set of LDSS parameters. The ESS is not available if the state of charge is below the minimum, or if it is out of service. The LDSS

must be set lower, so that there is enough spinning reserve. For example, the load-dependent start point can be 85 %, while the load-dependent stop is 65 %.



More information

See **Genset functions, Load-dependent start and stop** in the **Option G5 Power management AGC-4 Mk II** for more information and examples.

NOTE If the ESS supports it, the system can run on battery power (grid-forming) without gensets or a mains connection. The battery can run alone, or together with solar power.

5.4.6.2 Genset set points (kW)

In power management mode, the controllers force the gensets that are connected to the busbar to operate at or above a minimum load. This is to reduce the risk of engine problems, for example wet-stacking, fouling, or other issues caused by idling at low loads.

Island operation

During island operation the connected genset load can be between -50 and 100 % of engine nominal power. The *Min GEN load 1/2* parameters (15011 to 15013) on the battery/storage controller are shared parameters that ensure that all engines connected to the busbar do not go below the minimum load.

If the gensets are in frequency control mode, the energy storage system regulates the power. If the gensets are loaded more than the parameter set point, then the energy storage system is regulated up to take over load from the gensets and vice versa.

Parallel to grid operation

Gensets that operate in parallel to the ESS are always loaded to at least their *Minimum Load*, to protect them.

The power management system uses the ESS according to the charge scheme, and starts and stops gensets as required while taking the minimum genset load into account.

5.4.7 Ground relay

The ground relay function ensures that the star point of only one connected power source is connected to ground during island operation. This prevents circulating currents between the power sources.

NOTE The relay for this function must be selected in each controller (that is, in all the genset controllers and storage controllers).

How it works

The ground relay function follows the following principles:

- If the ESS is not connected to the busbar, the ground relay does not consider the rest of the system.
 - If the close condition is met, the ground relay is closed.
 - If the open condition is met, the ground relay is open.
- If more than one power source is connected to the busbar, then power management ensures that only the ground relay of the biggest power source stays closed. The ground relays of all other power sources are opened.
 - If the power sources are the same size, then the ground relay of the connected power source with the highest priority is closed.
- A new power source can connect to the busbar. If it is bigger (or the same size and a higher priority) than the power source with the closed ground relay, the new power source keeps its ground relay closed. The other power source opens its ground relay.
- The close condition, open condition and ground relay type are configurable.

Safety

The ground relay function is NOT supported in a **Single controller** application, even if the controller has power management.

Power management > Ground relay > Ground relay

Parameter	Text	Range	Default	Description
8121	Output A	Not used Relay 5, 6 and 9 to 18 Limits	Not used	If a pulse breaker is chosen (see 8126), use this for ground relay open.
8122	Output B		Not used	If a pulse breaker is chosen (see 8126), use this for ground relay close.
8123	Enable	OFF ON	OFF	Enable the ground relay function.
8124	Timer	1.0 to 30.0 s	1.0 s	An alarm for the unusual situation where power management expects a power source's ground relay to close, but it does not. This may be due to a physical fault with the ground relay.
8125	Fail class	Fail classes	Trip ESB	
8126	Ground relay type	Continuous Pulse	Continuous	

Continuous: When the ground relay must be closed, the *Output A* relay selected in 8121 is activated continuously.
Pulse: Configure *Output A* to open and *Output B* to close the ground relay. Ground relay breaker feedback is required.

Power management > Ground relay > Gnd breaker setting

Parameter	Text	Range	Default	Description
8151	Gnd close conf	Hz/V OK Start active	Hz/V OK	Ground relay close condition. Hv/V OK: The ground relay closes if the ESS voltage and frequency (parameters 2111 to 2114) are okay. Start active: The ground relay closes when the ESS start is active.
8152	Gnd priority	GEN priority ESS priority	GEN priority	GEN priority: For the same nominal power, gensets have first priority for the ground relay function. ESS priority: For the same nominal power, energy storage systems have first priority for the ground relay function.

Ground relay with breaker position

Position feedbacks from the ground relay are required for a pulse relay.

- In the utility software, select *I/O & Hardware setup*.
- In the *Preconfigured function* list, select the required feedback:
 - *Ground breaker on*
 - *Ground breaker off*

Power management > Ground relay > Gnd Break fail

Parameter	Text	Range	Default	Description
8131	Gnd Open fail, Timer	1.0 to 30.0 s	1.0 s	Ground relay open failure. The controller deactivated its output, but the ground relay did not open before the timer ran out.
8132	Gnd open fail, Fail class	Fail classes	Trip ESB	
8133	Gnd Close fail, Timer	1.0 to 30.0 s	1.0 s	Ground relay close failure. The controller activated its output, but the ground relay did not close before the timer ran out.
8134	Gnd Close fail, fail class	Fail classes	Shutdown	

Parameter	Text	Range	Default	Description
8135	Gnd Pos fail, Timer	1.0 to 30.0 s	1.0 s	Ground relay position failure. The breaker feedbacks are inconsistent for the specified time.
8136	Gnd Pos fail, Fail class	Fail classes	Trip ESB	

NOTE There is always an overlap where both ground relays are connected when transferring the ground relay from one power source to another.

5.5 More power management communication

5.5.1 CAN flags (M-Logic)

M-Logic has 16 CAN flags for CAN commands. They are like digital inputs. When a CAN command is sent from one controller, the corresponding CAN flag is activated in all the controllers. No wire is needed, as the CAN flags are communicated over the power management CAN bus.

NOTE Only use continuous signals from digital inputs or AOP buttons to activate the CAN inputs. AOP buttons are pulse inputs, so a latch function must be used to create a continuous signal.

M-Logic CAN flag outputs and events

Events	Output	Events	Output
▼ CAN Cmd CAN Cmd 01 active CAN Cmd 02 active CAN Cmd 03 active CAN Cmd 04 active CAN Cmd 05 active CAN Cmd 06 active CAN Cmd 07 active CAN Cmd 08 active CAN Cmd 09 active CAN Cmd 10 active CAN Cmd 11 active CAN Cmd 12 active CAN Cmd 13 active CAN Cmd 14 active CAN Cmd 15 active CAN Cmd 16 active		▼ CAN Input CAN Inp 01 active CAN Inp 02 active CAN Inp 03 active CAN Inp 04 active CAN Inp 05 active CAN Inp 06 active CAN Inp 07 active CAN Inp 08 active CAN Inp 09 active CAN Inp 10 active CAN Inp 11 active CAN Inp 12 active CAN Inp 13 active CAN Inp 14 active CAN Inp 15 active CAN Inp 16 active	

M-Logic CAN command example

Logic 1

Item description (optional and saved in project file only)

NOT

Operator

Event A

☐ GEN 2 running: Power

☐ Not used

☐ Not used

OR

OR

Delay (sec.)

0

Output

CAN Cmd 01 active: CAN

Enable this rule

☒

CAN Cmd 01 is activated when GEN 2 is running. CAN Inp 01 active is then activated in all controllers in the power management system.

5.5.2 CAN bus setup

If it is critical for the application to have the fastest possible inter-controller communication, configure parameters 9171 and 9172 from the controller display.

Press *Shortcut menu* , select *Jump* and enter the parameter number:

Parameter	Text	Range	Default
9171	Int CAN units *	≤ 15 units ≤ 20 units ≤ 25 units ≤ 30 units ≤ 35 units ≤ 40 units	≤ 40 units
9172	Int CAN baud **	125k 250k	125k


NOTE * The lower the number of units, the faster the power management.

** 125 kbit baud allows cable length up to 300 m, 250 kbit baud allows cable length up to 150 m.

All controllers in the system must have the same settings in parameters 9171 and 9172, otherwise an *Appl. hazard* alarm is displayed. A *Unit number Error* entry is created in the event log, and the controller with the different baud rate is tagged with the alarm value 100 in the alarm log.

The parameters can also be configured with the utility software:

1. In the task bar, select *Identifiers* 
2. In the pop-up window, change *Int. Power Management number of units* and *Int. Power Management CAN BAUD rate*.



5.5.3 CAN failure mode

If there is a failure on the CAN controlling the power management, the system can be set up to respond in a variety of ways.

Power management > Communication failures

Parameter	Text	Range	Default	Details
7532	CAN fail mode	No reg MANUAL	No reg	The controller mode if there is a CAN failure. See below.

Parameter	Text	Range	Default	Details
		No mode change		
7533	Miss. all units	Fail classes	Warning	The controller cannot detect any other controllers.
7534	Fatal CAN error	Fail classes	Warning	More controllers are missing than configured in parameter 8800.
7535	Any GEN missing	Fail classes	Warning	The controller cannot detect at least one genset controller.
7536	Any mains missing	Fail classes	Warning	The controller cannot detect at least one mains controller.
7871	Any BTB miss.	Fail classes	Warning	The controller cannot detect at least one BTB controller.
7874	Any LG miss.	Fail classes	Warning	The controller cannot detect at least one load group controller.
7875	Any PV miss.	Fail classes	Warning	The controller cannot detect at least one solar controller.
7876	Any Bat miss.	Fail classes	Warning	The controller cannot detect at least one storage/battery controller.
8800	CAN miss amount	2 to 32	2	The setting for the fatal CAN error.

No reg mode

If *No reg* mode is selected, the controllers change to no regulation mode when a fatal CAN error occurs. There is a risk of blackout, since there is no load sharing in no regulation mode.

MANUAL mode

If *MANUAL* mode is selected, the controllers change to MANUAL mode when a fatal CAN error occurs. The regulators in the controllers are still active. This means that power sources (for example, gensets) that are visible to each other are able to share load.



CAUTION



Unsynchronised gensets or energy storage systems can be connected

If a fatal CAN error is present, it is possible to start two gensets or energy storage systems and close the breakers onto the busbar at the same time (even though they are not synchronised).

No mode change

If *No mode change* is selected, the controllers are kept in the mode they were in before the fatal CAN error occurred. In an application with several controller types, if one power source controller is not visible anymore, the rest of the system can still behave almost like normal and continue in AUTO mode.

5.5.4 CAN bus alarms

Alarm	Description
Any GEN missing	Activated when one or more genset controllers are missing. Activates the fail class in parameter 7535.
Any mains missing	Activated when one or more mains controllers are missing. Activates the fail class in parameter 7536 (also used when a BTB controller is missing).
Appl. Hazard	The application configuration is not the same in all the controllers in the system. The power management system cannot operate correctly. If enabled, this alarm activates the fail class in parameter 7872.
Duplicate CAN ID	Activated when two or more controllers have the same internal communication ID. The power management system cannot operate.
Missing all units	Activated only when a controller cannot "see" any other controllers on the CAN bus line. Activates the fail class in parameter 7533.

Alarm	Description
CAN bus communication failures	The <i>XXX missing</i> alarms, the alarm is activated on all other controllers in the application.
CAN ID X P missing	The controller has lost CAN bus communication to CAN ID on <i>PM Primary</i> .
CAN MAINS X P missing	The controller has lost CAN bus communication to a mains controller with ID X on <i>PM Primary</i> .
CAN BTB X P missing	The controller has lost CAN bus communication to a BTB controller with ID X on <i>PM Primary</i> .
CAN ID X S missing	The controller has lost CAN bus communication to CAN ID on <i>PM Secondary</i> .
CAN MAINS X S missing	The controller has lost CAN bus communication to a mains controller with ID X on <i>PM Secondary</i> .
CAN BTB X S missing	The controller has lost CAN bus communication to a BTB controller with ID X on <i>PM Secondary</i> .
CAN setup CH: 784x	The controller can detect power management communication on a CAN port, but the correct protocol is not set. For a genset controller, this alarm also monitors the CAN setup between the engine communication protocol and CAN port.

6. Open PMS applications

6.1 Open PMS

Open PMS is a power management system that consists of battery/storage and/or solar controllers. Open PMS can also include a mains controller. The battery/storage and/or solar controller(s) get power measurements from the externally controlled power source(s). You can therefore use open PMS to add power management to a brownfield application with third party gensets.

Open PMS automatically supplies the power that is necessary for the load efficiently, safely and reliably:

- Automatically maximises PV power
- Automatically optimises ESS power
- Automatically closes and opens breakers
- Balances the loads in the system
- Deploys logic

The open PMS operating data can be shown graphically on the controller display. You can also monitor open PMS from a graphical supervision page in the utility software.

Open PMS features

Open PMS features	Extended	Premium
Power management operation limits:		
• External generator controllers per battery/storage/solar controller	4	16
• Mains controllers*	32	32
• External mains connections	1	1
• Battery/storage (BESS) controllers*	16	16
• Solar controllers*	16	16
EasyConnect	●	●
External sources included in the available power:		
• Supply the busbar load	●	●
• Charge batteries	●	●
• Minimum and optimal genset load	●	●
Global or local start of external genset(s)	●	●

*Restrictions on controllers

ID 1 to 24	ID 25 to 32	ID 33 to 40
Mains (1 to 32)		
	Solar (25 to 40)	
	Battery/Storage (25 to 40)	

Plant modes with a mains controller

With a mains controller, open PMS supports:

- Configurable mains power set point
- Configurable mains operating mode
- Auto-start signal for the application to the mains controller
- Standard mains controller PMS features, including cos phi set points, and mains breaker control

Standard plant modes	Applications
Island mode	Power plant with synchronising generators.
Automatic Mains Failure	Critical power/emergency standby plants, black start generator.
Fixed power	Power plant with fixed kW set point (including building load).
Peak shaving	Power plant where generator supplies peak load demand paralleled to the mains.
Load take-over	Plant mode where the load is moved from mains to generator. For example, peak demand periods, or periods with a risk of power outages.
Mains power export	Power plant with fixed kW set point (excluding building load).

Plant modes with an external mains

The battery/storage or solar controller that is connected to the external mains operates as a *Mains lite* controller and controls the mains mode.


Standard plant modes	Applications
Fixed power	Power plant with fixed kW set point (including building load).
Peak shaving	Power plant where generator supplies peak load demand paralleled to the mains.
Mains power export	Power plant with fixed kW set point (excluding building load).

NOTE For an open external mains breaker, open PMS cannot synchronise so that the mains breaker can close. That is, open PMS runs in island mode and cannot back sync.


6.2 Single-line application diagrams for open PMS

6.2.1 Off-grid open PMS

Off-grid solar, battery and external genset(s)




Off-grid battery(s) and external genset(s)




NOTE * You can use multiple controllers in the application. Power measurements can be connected to the closest battery/storage or solar controller.

6.2.2 Grid-tied open PMS


Grid-tied solar, battery and external mains




Grid-tied solar, battery, external genset(s) and external mains



Grid-tied solar, battery, mains and external genset(s)



Grid-tied battery(s), mains and external genset(s)



NOTE * You can use multiple controllers in the application. Power measurements can be connected to the closest battery/ storage or solar controller.

6.3 Setup of an open PMS application

You must set the controller ID in each open PMS controller.

Communication > Power management ID

Parameter	Text	Range	Default
7531	PM CAN ID	25 to 40	25

When the IDs are configured, you can configure the application with the utility software.

Connect to a controller with the PC utility software, then select *Application configuration*. In the top taskbar, select *New plant configuration* . The *Plant options* window opens.

Plant options

Product type

ASC 150 Solar

Plant type

Standard

Application properties

☒ Active (applies only when performing a batchwrite)

Name:

Standard plant

Bus Tie options

☐ Wrap bus bar

Power management CAN

☒ Primary CAN

☐ Secondary CAN

☐ Primary and Secondary CAN

☐ CAN bus off (stand-alone application)

Application emulation

☒ Off

☐ Breaker and engine cmd. active

☐ Breaker and engine cmd. inactive

OK


Cancel

Plant options

	Description	Comments
Product type	The controller type is selected here.	This function is greyed out when a controller is connected.
Plant type	- Single controller - Standard	Select <i>Standard</i> for open PMS.
Application properties	The application is activated when it is written to the controller. Name the application.	Naming the application can be helpful, if the controller is in a plant where the controller will switch between applications. The controllers can switch between four different applications. Controllers that are connected to each other cannot have different applications or numbers.
Bus tie options	Not relevant.	You cannot use this for open PMS.
Power management CAN	Primary CAN Secondary CAN Primary and secondary CAN CAN bus off	Use <i>Primary CAN</i> if the Power Management CAN bus is wired to CAN port B on each controller. Only use <i>Primary and secondary CAN</i> if there is redundant CAN bus communication for power management. If this setting is selected and only one communication line is present, an alarm is activated. This alarm cannot be cleared.
Application emulation	Off Breaker and engine cmd. active Breaker and engine cmd. inactive	You can turn on emulation here, for testing the system or training operators. NOTE Do not use emulation when the controller is connected to power generating equipment.

You can now create the application drawing in the controllers. From the left side of the page, you can add the battery/storage/solar controllers and/or the mains controller to the configuration. You can also select the type of breakers in the application.

Plant configuration options

No.		Name	Description
			
1	Source		Select the type of power source for the top area (None, Mains, Photovoltaic, or Battery).
2	ID		Set the ID. This ID should correspond to the internal communication ID (parameter 7531) in the controller.
3	MB		Mains is selected as the source (no. 2), so it is possible to select the type of breaker for the mains breaker (Pulse, Ext/ATS no control, Continuous NE, Compact, None, Continuous ND).
4	TB		Open PMS does not support TB. You must therefore select <i>None</i> .
5	-		Select whether the tie breaker is <i>Normally open</i> or <i>Normally closed</i> .
6	BTB		You cannot select a BTB in open PMS.
7	Source		Select the type of power source for the bottom area (None, Mains, Photovoltaic, or Battery).
8	ID		Set the ID. This ID should correspond to the internal communication ID (parameter 7531) in the controller.
9	ESB		In this example, battery is selected as the source (no. 13), so it is possible to select the type of breaker (Pulse, Ext/ATS no control, Continuous NE, None).
10	Add/Delete		Add and delete areas. Adding areas makes the application configuration/plant bigger.

Restrictions

Do not include the external genset(s) or an external mains in the open PMS application. These are configured separately as external P/Q sources.

Do not include genset controllers (s) in the open PMS application. If present, these are also configured separately as external P/Q sources.


Mains controller(s) cannot have tie breakers in an open PMS application.

- As a result, there is no mains load point on an open PMS application diagram. For open PMS, the **solar controller** is therefore shown as connected to the busbar.

Do not include bus tie breakers (BTB) or load groups (LG) in the open PMS application. These are not supported by open PMS.

NOTE Use a DEIF **Energy management system** if the application cannot comply with these restrictions.

Application configuration example



After you have created the application, send it to the controllers. Select *Write plant configuration to the device* . After this, only the controller connected to the PC utility software has the application configuration.

The application configuration can then be sent from this controller to all the other controllers. Select *Broadcast plant application* .

6.3.1 Open PMS parameters in battery/storage and solar controllers

You can use open PMS with iE 150 Battery, iE 150 Solar, ASC 150 Storage, ASC 150 Solar, ASC-4 Battery, ASC-4 Solar, iE 150 Mains, AGC 150 Mains and/or AGC-4 Mk II Mains.

To use open PMS, you must configure these parameters in each battery/storage and solar controller.

Battery/storage and solar controller parameters

Parameter	Name	Range	Default	Details
6071	Operation mode	(See the software - only <i>Power</i>	Power management	This parameter must be Power management .

Parameter	Name	Range	Default	Details
		<i>management is relevant)</i>		
8022	Mode update	Update local Update all	Update all	Update all: When the mode is changed in the controller, the mode is changed in all open PMS controllers. Update local: When the mode is changed in the controller, the other open PMS controllers are not affected.
8351	Open PMS	Not enabled, Enabled	Not enabled	To use open PMS, this parameter must be Enabled .
8352	Open PMS mode	Peak shaving Fixed power Mains Power Export	Mains Power Export	If this controller is connected to an external mains measurement, use this parameter to set the open PMS mode. If this controller is not connected to an external mains measurement, this parameter is ignored.



More information

See [Using an external mains](#) for the configuration and parameters required when using an external mains in open PMS.



More information

See [Using a mains controller](#) for the configuration and parameters required when using a mains controller in open PMS.

NOTE If the application does not include any mains, the controller with the lowest ID is the plant controller.

6.3.2 Using external gensets

You can use open PMS with external gensets. For each controller, you can configure and connect up to 16 external genset power measurements and breaker feedbacks.


Application configuration

The application configuration must not include a *Genset* source. Open PMS detects that external genset(s) are present when:

- *Open PMS* (parameter 8351) is *Enabled* in the controller.
- In the utility software, under *I/O & Hardware setup > Ext. P/Q sources, Ext. source [1 to 16]*:
 - *Type* is *GEN*
 - The nominal power is configured
 - The *P source* (required) is selected
 - The *Q source* (optional) is selected.

If you need to use DEIF genset controllers in open PMS, select *GEN power comm [1 to 16]*. In *GEN meter prot.* (parameter 7721), select *DEIF genset control*.

Example of external genset configuration



	Type	Nominal P (kW)	P source	Q source
Ext. source 1	GEN	1500	GEN power meter comm. 01	GEN power meter comm. 01
Ext. source 2	GEN	1500	GEN power meter comm. 02	GEN power meter comm. 02
Ext. source 3	GEN	1500	GEN power meter comm. 03	GEN power meter comm. 03
Ext. source 4	OFF	0	No source selected	No source selected
Ext. source 5	OFF	0	No source selected	No source selected
Ext. source 6	OFF	0	No source selected	No source selected

Genset power measurements

The setup of the genset power measurements and breaker feedbacks for open PMS is the same as the setup for single-controller applications.



More information

See [Power measurements and connection status](#) for how to set up the genset power measurements and breaker feedback.

Different types of gensets or power meters

For each controller, you can only have one genset meter protocol (parameter 7721). If the application has more than one set of genset and/or power meter types, connect each set to separate controllers.

Alternatively, if you have a PLC, you can use the DEIF open protocol. The PLC can read the genset power from the different genset and/or power meter types, then write it to the controller.

6.3.3 Start and stop external gensets

You can configure the battery/storage controller to activate an output to start and run external gensets based on the load and/or the ESS SOC. You can deactivate the output based on the load to ensure that the genset minimum load requirement is met. You can use start based on the load and/or the SOC to ensure that the load is supplied and the ESS gets enough power to charge.

When the controller activates the output to start and run one or more external gensets (*Start/Stop Ext. GEN*), the external generator controller must start the genset(s) (including synchronisation and generator breaker closing).

When the controller needs to stop the external genset(s), the controller regulates the ESS to take over the genset load. When the breaker open point is reached, the controller deactivates the output to stop the last external genset. The external generator controller should bring the genset to a controlled stop. If required, this should include a load ramp down to unload the genset. After opening the generator breaker, the generator controller should ensure that there is a cooldown sequence before stopping the genset.

Start-stop output

On the *Inputs/Outputs* page in the USW, choose a digital output to use as the output. Select the *Start/Stop Ext. GEN* function.

Alternative setup using M-Logic

You can also control the *Start/Stop Ext. GEN* output by using M-Logic, for more flexibility. For example, the request to start the genset can be used in combination with the command timers. This enables scheduling of the genset start and stop. The request to stop the gensets from M-Logic overrules any start request from the SOC, system load, and M-Logic.

You can find the M-Logic functions under *Output, Command GEN*:

- Request ext. Gen to start
- Request ext. Gen to stop

External genset breaker open

External control > External GEN start/stop

Parameter	Name	Range	Default	Description
15180	Ext. GEN breaker open	0 to 100 % of total external genset nominal power	5 %	When the total external genset power reaches this point, the controller deactivates the <i>Start/Stop Ext. GEN</i> output.

External genset start/stop alarm

External control > External GEN start/stop

Parameter	Name	Range	Default	Description
15170	Ext. GEN start error	1 to 1000 s	30 s	The alarm is activated if a genset start request is active, but the controller has not received feedback from a genset. The alarm timer also starts running if the only genset connected to the busbar is disconnected.*

NOTE * If the ESS supports it, the system can run on battery power (grid-forming) either alone, or together with solar power.

6.3.4 Starting external gensets connected to other controllers

In an open PMS system, energy may be needed by a controller that is not connected to external genset(s). In addition, even if a controller is connected to external genset(s), when energy is needed, you may also want to start the genset(s) connected to other controllers.

The *Open PMS - global/local start of external genset* function let you manage which other controllers can activate the controller's *Start/Stop ext. GEN* output.

I/O & Hardware setup > Ext. P/Q sources > Open PMS - global/local start of external genset


The screenshot shows the DEIF control interface. The left sidebar contains a menu with 'Monitoring' and 'Configuration' sections. The 'Configuration' section is expanded, showing 'Application configuration', 'Parameters', 'I/O & Hardware setup' (highlighted), and 'External I/O (CIO)'. The main area displays the 'Ext. P/Q sources' configuration page, which includes settings for 'Ext. source 15' and 'Ext. source 16'. Below this is the 'Open PMS - external mains' section, which includes 'Enabled/Disabled' and 'P source (channel 7005)' and 'Q source (channel 7009)' settings. The bottom section is 'Open PMS - global/local start of external genset', which includes a table for selecting controllers to activate the genset start output. The table has columns for 'Mode', 'Battery25', 'Battery26', 'Battery27', 'Battery28', 'Battery29', 'Battery30', 'Battery31', and 'Batt'. The 'Mode' column is set to 'Local'. The 'Battery25' through 'Battery31' columns have checkboxes that are all checked. The 'Batt' column has a checkbox that is unchecked. Below the table is the 'Power meter protocol' section, which is set to 'Send commands' and 'DEIF Genset Control'.

Setting	Range	Default	Description
Mode	Local, Global	Local	Local: If any of the selected controllers require a genset start, then the controller activates its <i>Start/Stop ext. GEN</i> output. Global: If any controller in the Open PMS system requires a genset start, then the controller activates its <i>Start/Stop ext. GEN</i> output.

Examples

The system has five batteries, and each battery has its own controller. Controllers 25 and 29 each have a digital output that is connected to an external genset. For each controller:

- *SOC GEN control* (parameter 15155) is **Local SOC** and **Enabled**.
- *SOC GEN start limit* (parameter 15151) is **30 %**.
- *SOC GEN stop limit* (parameter 15153) is **50 %**.



Local start of external genset

For controller 25, the *Ext. GEN start* mode is **Local**. Controllers 26 and 27 are selected.

If the state of charge (SOC) falls below 30 % in batteries 25, 26 and/or 27, then controller 25 starts its genset (that is, it activates its *Start/Stop ext. GEN* output). Controller 25 runs its genset (that is, it keeps the *Start/Stop ext. GEN* output active) until the SOC that fell below 30 % has risen to at least 50 %.

The controller 25 genset is not affected by the SOC in batteries 28 and 29.



Global start of external gensets

For controller 25, the *Ext. GEN start* mode is **Global**. The controller selection is irrelevant.

If the SOC falls below 30 % in **any** of the batteries, then controller 25 starts its genset.



Mix of local and global start of external gensets

For controller 25, the *Ext. GEN start* mode is **Global**. For controller 29, the *Ext. GEN start* mode is **Local**. Controllers 28 is selected.

If the SOC falls below 30 % in controller 28 or 29, then controller 29 starts its genset, and controller 25 also starts its genset.

If the SOC falls below 30 % in controller 25, 26 or 27, then only controller 25 starts its genset.

6.3.5 Using an external mains

You can use open PMS with an external mains. Configure and connect the external mains power measurement and breaker feedback to one battery/storage/solar controller. The set points in this controller are used as the open PMS plant set points.

Application configuration

For an external mains, the application configuration must not include a *Mains* source. Open PMS detects that an external mains is present when:

- *Open PMS* (parameter 8351) is *Enabled* in the battery/storage/solar controller.
- *Mains power measure* (parameter 7005): A mains power measurement is selected.
- *Mains Q measure* (parameter 7009) (optional): A mains reactive measurement is selected.
- In the utility software, under *I/O & Hardware setup > Ext. P/Q sources > Open PMS - external mains*, *Ext. mains* is **ENABLED**.

Example of external main configuration

The screenshot shows the DEIF configuration interface. The sidebar on the left has three main sections: Monitoring, Configuration, and Tools. Under Configuration, 'I/O & Hardware setup' is selected. The main area displays a table for 'Ext. P/Q sources' with columns for Type, Nominal P (kW), P source, and Q source. Below this is a section for 'Open PMS - external mains' with fields for Enabled/Disabled, P source (channel 7005), and Q source (channel 7009).

Type	Nominal P (kW)	P source	Q source
Ext. source 1	DG	1500	DG power meter comm. 01
Ext. source 2	DG	1500	DG power meter comm. 02
Ext. source 3	DG	1500	DG power meter comm. 03
Ext. source 4	OFF	0	No source selected
Ext. source 16	OFF	0	No source selected

Open PMS - external mains

Enabled/Disabled	P source (channel 7005)	Q source (channel 7009)
Ext. mains	ENABLED	4th CT power meas (internal)

Auto start/stop

To start the application automatically, the battery/storage controller with the external mains power measurement must get an *Auto start/stop* signal. This can be from a digital input, M-Logic (*Output > Command*), or Modbus communication.

NOTE For *Local* (in *Start/stop*, parameter 8021), the operator can use the display push-button to start the application.

Operation for an external mains

For an external mains, the open PMS operating mode is configured in the battery/storage controller that is connected to the external mains measurement. This battery/storage controller operates as an *mains lite* controller. The open PMS application uses the battery/storage controller set point from the battery/storage controller that is connected to the external mains measurement. The battery/storage controller that is connected to the external mains measurement sends power references to the other open PMS controllers.

Open PMS supports three power management modes.

For an external mains, it is not possible for the open PMS to synchronise the mains breaker. That is, back sync is not possible.

Parameters for the battery/storage controller with an external mains

Parameter	Name	Range	Default	Details
6071	Operation mode	See the software.	Power management	This parameter must be Power management .
7001, 7002, 7006, 7011-7014	Peak shaving and mains power export parameters	-	-	If <i>Peak shaving</i> or <i>Mains power export</i> is selected in parameter 8352, open PMS uses these set points for the plant.
7051	Fixed power	0 to 20000 kW	500 kW	If <i>Fixed power</i> is selected in parameter 8352, open PMS uses this set point for the plant.
8022	Mode update	Update local Update all	Update all	Update all: When the mode is changed in the controller, the mode is changed in all open PMS controllers. Update local: When the mode is changed in the controller, the other open PMS controllers are not affected.

Parameter	Name	Range	Default	Details
8351	Open PMS	Not enabled, Enabled	Not enabled	To use open PMS, this parameter must be Enabled .
8352	Open PMS mode	Peak shaving Fixed power Mains Power Export	Mains Power Export	Use this parameter to set the open PMS mode. If the controller is not connected to an external mains measurement, this parameter is ignored.

Mains power measurements

The setup of the mains power measurements and breaker feedbacks for open PMS is the same as the setup for single-controller applications.



More information

See [Power measurements and connection status](#) for how to set up the mains power measurements and breaker feedback.

NOTE For power meter communication, there can be up to 16 mains nodes (parameter 7726).

NOTE If digital inputs are used for the external mains breaker feedback, you must use digital input 47 for *MB position on* and digital input 48 for *MB position off*.

NOTE For external mains, the mains breaker position feedbacks do not activate the position failure alarm.

6.3.6 Using a mains controller

You can use open PMS with an iE 150 mains, AGC 150 mains, or AGC-4 Mk II mains controller.

Application configuration

For open PMS, the configuration of the mains controller is the same as for standard power management. No additional configuration is needed.

The mains controller must have a controller ID and be included in the application configuration.

Auto start/stop

To start the application automatically, the mains controller must get an *Auto start/stop* signal. This can be from a digital input, M-Logic (*Output > Command Power management*), or Modbus communication.

NOTE For *Local* (in *Start/stop*, parameter 8021), the operator can use the display push-button to start the application.

Operation

The open PMS operating mode is configured in the mains controller. The open PMS application uses the mains controller set point.

Open PMS supports the standard mains controller power management functions, including cos phi set points and mains breaker control.

Mains controller parameters

Parameter	Name	Range	Default	Details
6070	Plant mode	Auto mains failure Peak shaving Fixed power Mains power export Load take over	Auto mains failure	Use this parameter to set the plant mode.
7001 to 7253	Mains parameters	-	-	Configure these parameters as required for the application and plant mode.

Parameter	Name	Range	Default	Details
7842	CAN B Protocol	OFF PMS Primary AOP2 PMS Secondary Ext. Modules DEIF	PMS Primary	Select PMS Primary or PMS Secondary . Select the same protocol in the battery/storage and solar controllers.
8021	Start/stop	Remote, Local	Remote	Remote: For auto start/stop using a Modbus command, M-Logic, or a digital input. Local: Start/stop the application using the display start/stop buttons.

6.4 Open PMS in operation

When the application is running, open PMS automatically supplies the power that is necessary. This includes active (required) and reactive (optional) power. As a power management system, open PMS supplies power efficiently, safely and reliably.

Power from the external power sources (gensets and/or mains) is included in the available power. Open PMS uses the available power to supply the load.

For maximum efficiency, open PMS automatically maximises the PV power. Open PMS charges and uses the batteries according to the configured settings. As far as possible, open PMS makes sure that the gensets are not run below the minimum load. Rather, open PMS tries to use the mains, solar and battery power so that the gensets run at the optimal genset load.


Open PMS balances the load between the open PMS controllers.

In AUTO mode, open PMS controllers automatically close and open their breakers.



Finally, if there is M-Logic, open PMS deploys the M-Logic in the controller(s).

NOTE Open PMS does not control the load sharing, or the connection of the external gensets. Open PMS indirectly controls the power of the external gensets by adjusting the solar, battery and mains set points.

Examples of controller displays for open PMS




Grid-tied with external mains




Grid-tied with mains controller

Solar



Battery/Storage
(connected to gensets)




7. Battery functions

7.1 Managing charging and discharging

7.1.1 State of charge

The controller reads the state of charge from the energy storage system (ESS). The controller ensures that the state of charge (SOC) conditions are met.

State of charge conditions



NOTE The drawing is based on the default parameter values.

Charging: If the SOC is below maximum, the ESS can charge. See **ESS charging source** for more information.

Discharging: If the SOC is above minimum, the ESS can discharge.

*Below threshold 1: The ESS can discharge until the SOC reaches the minimum. The ESS must then recharge to threshold 1 before it can discharge again.

Battery assisting operation: The ESS can be battery assisting if the SOC is above threshold 1.

*Below threshold 1: The ESS can discharge as battery assisting until the SOC reaches the minimum. The ESS must then recharge to threshold 1 before it can discharge again.

Battery leading operation: The ESS can be battery leading if the SOC is above threshold 2.

**Below threshold 2: The ESS can discharge as battery leading until the SOC reaches threshold 1. The ESS must recharge to threshold 2 before it can be battery leading again.

State of charge parameters

Storage > SOC settings

Parameter	Name	Range	Default	Details
17055	SOC Settings	SOC Setting [1 to 3]	SOC Setting 1	The controller has three sets of state of charge parameters. This parameter selects which set to use.
17056	SOC resolution	1%, 0.1%, 0.01%	1%	The resolution for the SOC from the ESS. This parameter affects the SOC regulation and the SOC that the controller displays. Note: You cannot use this parameter to get a better resolution than the SOC resolution that comes from the ESS.

Storage > SOC/SOH alarms > SOC alarms

Parameter	Name	Range	Default	Details
17110	SOC Low	0 to 100 %	20 %	The SOC low alarm.
17120	SOC High	0 to 100 %	80 %	The SOC high alarm.

Storage > SOC settings > SOC setting [1 to 3]

Parameter	Name	Range	Default	Details
17051, 17061, 17071	SOC. Minimum [1 to 3]	0 to 100 %	20 %	The ESS must not discharge when this minimum is reached. The ESS is not allowed to provide any power until the SOC reaches threshold 1.
17053, 17063, 17073	SOC. Thr. 1.[1 to 3]	0 to 100 %	40 %	Below threshold 1, the ESS can discharge as battery assisting until the SOC reaches the minimum. The ESS must then recharge to threshold 1 before it can discharge again. Below threshold 1, the ESS cannot discharge as battery leading. The ESS must recharge to threshold 2 before it can be battery leading again.
17054, 17064, 17074	SOC. Thr. 2.[1 to 3]	0 to 100 %	80 %	Below threshold 2, the ESS can discharge as battery assisting until the SOC reaches the minimum. The ESS must then recharge to threshold 1 before it can discharge again. Below threshold 2, the ESS can discharge as battery leading until the SOC reaches threshold 1. The ESS must recharge to threshold 2 before it can be battery leading again.
17052, 17062, 17072	SOC. Maximum [1 to 3]	0 to 100 %	90 %	The ESS must not charge when this maximum is reached. The ESS can be a battery assisting or battery leading.

7.1.2 Charging the ESS

The energy management system automatically manages the ESS charging when the conditions for charging are met.

Charging rules

Between SOC threshold 1 and the maximum (if neither of the thresholds has been crossed), the battery/storage controller uses this rule:

If the system requires power, the ESS reduces charging.
If power is still required, the ESS stops charging and supplies the load.

Maximum rate

The ESS will charge at the maximum rate, unless you configure the maximum charge rate for the ESS. If there are charge restrictions from other sources, the battery/storage controller uses the lowest charge rate that is referenced.

Negative numbers indicate flow into the battery (charge the ESS), and positive numbers indicate flow out of the battery (discharge the ESS).

Storage > Dispatch limits

Parameter	Name	Range	Default	Details
17093	Minimum dispatch	-100 to 100 % of the ESS nominal apparent power (S)	-100 %	The maximum charge rate for the ESS.

Storage > DC protection

Parameter	Name	Range	Default	Details
17161	Max charge volt.	0 to 3200 V Not enabled, Enabled	960 V, Not enabled	Enabled: The controller uses this value to overwrite the maximum allowed DC charge voltage read from the BMS. Not enabled: The controller does not change the maximum allowed DC charge voltage.

7.1.3 Discharging from the ESS

The energy management system automatically manages the ESS discharging when the conditions for discharging are met.

Discharging rules

Between the SOC maximum and threshold 1 (if neither of the thresholds has been crossed), the controller uses the following rules:

1. If the ESS is battery leading, the ESS discharges.
2. If the ESS is battery assisting and there is peak load demand, the ESS discharges.
3. If the system has excess power, the controller reduces the power that the ESS supplies. If there is still excess power, the ESS can start charging.

Maximum rate

The ESS will discharge at the maximum rate, unless you configure the maximum discharge rate for the ESS. If there are discharge restrictions from other sources, the controller uses the lowest discharge rate that is referenced.

Negative numbers indicate flow into the battery (charge the ESS), and positive numbers indicate flow out of the battery (discharge the ESS).

Storage > Dispatch limits

Parameter	Name	Range	Default	Details
17094	Maximum dispatch	-100 to 100 % of the ESS nominal apparent power (S)	100 %	The maximum discharging rate for the ESS.

Storage > DC protection

Parameter	Name	Range	Default	Details
17163	Min charge volt.	0 to 3200 V Not enabled, Enabled	720 V, Not enabled	Enabled: The controller uses this value to overwrite the minimum allowed DC charge voltage read from the BMS. Not enabled: The controller does not change the minimum allowed DC charge voltage.

7.1.4 Force charging/discharging

You can use M-Logic commands to force ESS charging (*Output > Command Battery > Force charging*) or discharging (*Output > Command Battery > Force discharging*). Force charging/discharging is active as long as the M-Logic command is active.

Force charging

Force charging is used to only allow battery charging. The controller charges the battery as much as it can, while complying with the state of charge thresholds and charging source requirements.

For example, if the battery is under SOC threshold 2, it charges as much as it can from PV, mains and/or genset(s), while complying with the charging source priority and other requirements. When the battery is over SOC threshold 2, it charges as much as it can from PV until SOC maximum.

If charging is not possible, the controller keeps P ref at 0 kW.

When the M-Logic *Force charging* command is no longer active, the controller returns to its condition before force charging was activated (unless a threshold was crossed during the forced charging).

Force discharging

Force discharging is used to only allow battery discharging. The controller discharges the battery as much as it can, while complying with the minimum state of charge threshold and the mains set point.

If discharging is not possible, the controller keeps P ref at 0 kW.

7.1.5 Freeze charging/discharging

You can use M-Logic commands to freeze charging (*Output > Command Battery > Freeze charging*) or discharging (*Output > Command Battery > Freeze discharging*). These commands pause the battery charging/discharging. Freeze charging/discharging is active as long as the M-Logic command is active.

Freeze charging/discharging is similar to force charging/discharging. However, if the system needs energy from the battery, the battery can discharge during *freeze charging*. Similarly, if the system needs the battery to take up energy, the battery can charge during *freeze discharging*.

NOTE When *Freeze charging* is active, the battery charging power is zero (and discharging is allowed). Similarly, when *Freeze discharging* is active, the battery discharging power is zero (and charging is allowed).

7.1.6 Maintenance charge

The ESS SOC is an estimate of the state of charge in the energy storage system. SOC is generally suitable for ESS charging and discharging. However, to refresh and rebalance the ESS, it is sometimes necessary to allow charging above 100 % SOC.

Maintenance charge allows the battery/storage controller to charge the ESS based only on the maximum charge capacity value from the BMS.

Storage > Maintenance charge


Parameter	Name	Range	Default	Details
17400	Maintenance charge	Not enabled, Enabled	Not enabled	Enabled: The controller ignores the SOC and charges the ESS based only on the maximum charge capacity from the BMS. The controller attempts to charge the battery until reaching the setting in parameter 17401.
17401	Charge cap. thr	0 to 20000 kW	0 kW	Maintenance charging stops when the maximum charge capacity from the BMS decreases to this value.

NOTE If the *SOC high* alarm action is *Shutdown*, *Trip ESB*, or *Trip MB*, you need to disable this alarm during maintenance charging.

7.1.7 System power genset control


The battery/storage controller can start and stop the genset based on the system load. The controller calculates the system load from the ESS and genset power.

High load genset start



When the load is high, start the generator to make sure that there is enough power.

Low load genset stop



When the load is low, stop the generator, so that it does not run at a low load.

System power parameters

External control > External GEN start/stop

Parameter	Name	Range	Default	Description
15161	Sys P GEN start limit	0 to 20000 kW	200 kW	When the system load is above the start limit (and the timer has run out), the controller activates the output.

Parameter	Name	Range	Default	Description
		0 to 3200 s	10 s	
15163	Sys P GEN stop limit	0 to 20000 kW 5 to 3200 s	50 kW 15 s	When the system load is below the stop limit (and the timer has run out), the controller deactivates the output.
15165	Sys P GEN control	Enabled Not enabled	Not enabled	Select <i>Enable</i> to activate the Sys P GEN start function.

7.2 Battery leading or assisting operation

The battery leading and battery assisting functions determine the source priority. These functions are not directly related to grid-forming and grid-following.

A mains connection does not have any effect on the source priorities. With a mains connection, the controllers use the power sources to meet the mains set point.

7.2.1 Battery leading operation

For battery leading (previously called "energy source"), the controller prioritises battery power over genset power. As a result, the system uses as much battery power as possible before starting any genset.


Battery leading

The ESS is designed to supply the load, and can be the only grid-forming source connected to the busbar. Selecting *Battery leading* gives the ESS the higher priority (after PV, if this is present).

The battery/storage controller includes the ESS generation capacity in the spinning reserve. If there is enough spinning reserve, the power management system can stop all the gensets.

If both a generator and an ESS are connected (and the optimum genset load function is not activated), the ESS supplies the load so that the generator runs at its minimum load.

ESS acts as a battery leading



If the state of charge falls below *Threshold 1*, the controller automatically changes to battery assisting, and starts the required number of gensets. The controller remains in battery assisting until the state of charge reaches *Threshold 2*.

NOTE For battery leading, the ESS must be able to do grid-forming operation.

7.2.2 Battery assisting operation


For battery assisting (previously called "power source") operation, the battery/storage controller operates parallel to other sources. Genset power is prioritised over battery power. This mode is used to ensure that spinning reserve requirements are met

Battery assisting operation

The ESS is used to supply peak loads while additional gensets are starting, and to improve power quality. The ESS is not designed to be the only grid-forming source connected to the busbar. Selecting *Battery assisting* gives the gensets the higher priority (after PV, if this is present).

The power management system includes the ESS generation capacity in the spinning reserve requested from PV. This stops the system from connecting excessive gensets.

ESS acts as a battery assisting



7.2.3 Battery leading or assisting parameter

Storage > Operation modes

Parameter	Name	Range	Default
17081	Operation mode	Battery leading Battery assisting	Battery assisting

7.2.4 ESS black busbar start

If the battery leading requirements are met, the ESS can start and supply the load alone. This includes a black busbar start. Other sources do not have to be connected.

7.2.5 ESS as the only energy source

If the battery leading requirements are met, the ESS can supply the load alone. Other sources do not have to be connected.

If the ESS discharges so that the battery leading requirements are not met, the controller changes to battery assisting operation. The controller then requests that other power sources start and connect.

7.3 ESS charging source

The ESS can recharge from PV, gensets and/or mains. Use the battery/storage controller parameters to configure which function to use for charging, as well as the maximum charging rate.

7.3.1 Charging from PV

When enabled, and charging is allowed, charging from PV has the highest priority. That is, charging from genset and/or mains charging is only possible if the battery is charging as much as possible from PV, and the battery still has charging capacity.

Parameter	Name	Range	Default	Details
17041	PV charging	0 to 100 % of the excess PV power Not enabled, Enable	100 %, Not enabled	Enabled: The ESS can recharge from PV. The set point is the maximum charging rate. Not enabled: The ESS cannot recharge from PV.

7.3.2 Charging from gensets

The controller can charge the ESS from connected gensets so that the gensets can run at their minimum load. These conditions must be met:

1. If charging from PV is enabled, the ESS must charge as much as possible from the PV, and still have charging capacity.
2. The plant must be in island operation. That is, the plant must not run in parallel to mains.
 - In a PMS application, the battery/storage controller operation mode (parameter 6071) must be *Power management*.
 - In a single controller application, the controller operation mode (parameter 6071) can be *Island operation* or *Automatic mains failure* (but not *Fixed power*).
3. The ESS state of charge (SOC) must be below the *SOC maximum* and below *SOC Threshold 2*.
4. *GEN Charge mode* (parameter 17033) must be *Enabled*.

Parameter	Name	Range	Default	Details
17031	GEN Charge pct	0 to 100 % of the connected genset(s) nominal power	100 %	The set point is the maximum charging rate from gensets in percent. This is only active if parameter 17033 is enabled and set to <i>Percent</i>. Consider the load-dependent start-stop settings when selecting this set point. If you want to minimise genset starts, this set point should be below the load-dependent start setting. If you want genset(s) to start when charging is needed, this set point must be above the load-dependent start setting. Note that this parameter does not take other loads into account. When the connected load is high, the ESS might not be able to charge.
17032	GEN Charge P	0 to 5000 kW	200 kW	This power must be available as spinning reserve while the ESS is recharging. This should be above the genset start limit. This is only active if parameter 17033 is enabled and set to <i>Power</i>.
17033	GEN Charge Mode	GEN Charge in Percent GEN Charge in Power Not enabled, Enabled	GEN Charge in Percent, Not enabled	Enabled: The ESS can recharge from the gensets. This parameter determines whether parameter 17031 (Percent) or 17032 (Power) is used. Not enabled: The ESS cannot recharge from the gensets.


7.3.3 Genset minimum load

If the state of charge (SOC) and SOC settings allow battery charging, the battery/storage controller can ensure that the load on the connected genset(s) does not fall below the minimum load. This function can be used in both single controller and energy management system applications.

External control > Min. GEN load settings

Parameter	Name	Range	Default	Description
15011	Min GEN load 1	0 to 100 %	30 % of the genset's nominal power	The controller calculates the ESS power set point to ensure that the load on the connected genset(s) does not fall below the minimum load.
15012	Min GEN load 2	0 to 100 %	30 % of the genset's nominal power	
15013	Min GEN load set	Min. GEN load set 1 Min. GEN load set 2	Min. GEN load set 1	This determines whether the controller uses the setting in parameter 15011 or 15012.

Using battery charging for minimum genset load (very low power consumption)




7.3.4 Genset optimum load

The battery/storage controller can ensure that the connected genset(s) run at their optimum load (as far as possible). For optimum genset load, during high power consumption, the state of charge (SOC) and SOC settings must allow battery discharging. During low power consumption, the SOC and SOC settings must allow battery charging. This function can be used for both single controller and energy management system applications.


External control > Optimal GEN load settings

Parameter	Name	Range	Default	Description
15014	Opt GEN load % 1	0 to 100 %	80 % of the genset's nominal power	The controller calculates the ESS power set point to ensure that the load on the connected genset(s) is optimum.
15015	Opt GEN load % 2	0 to 100 %	70 % of the genset's nominal power	
15016	Opt GEN load set	Optimal GEN load set off Optimal GEN load set pct 1 Optimal GEN load set pct 2 Optimal GEN load set pct 1 + Dynamic ST/ST Optimal GEN load set pct 2 + Dynamic ST/ST	Optimal GEN load set off	This determines whether the controller uses the optimal GEN load function, or the setting in parameter 15014 or 15015. Dynamic start/stop is selected: The battery/storage controller starts a genset if the controller can transfer the load to that genset so that it runs at its optimal load point. Similarly, the battery/storage controller can stop the last genset and take over its load. Note: The application cannot include PV power.

Using battery discharging for optimum genset load (high power consumption)




High power consumption, without battery




High power consumption, with battery discharging

Using battery charging for optimum genset load (low power consumption)



Low power consumption, without battery



Low power consumption, with battery charging

NOTE The battery charging rate is governed by the set point for charging (parameter 17031). If this is the same as the optimal load point (parameter 15014), you will have the operation shown above.

7.3.5 Charging from mains

The controller can charge the ESS from mains to help create the negative load required to meet the mains set point. For example, the ESS can help reach negative MPE set points, or ensure that no power is exported. These conditions must be met:

1. If charging from PV is enabled, the ESS must charge as much as possible from the PV, and still have charging capacity.
2. The ESS state of charge (SOC) must be below the *Threshold 2*.
3. *Operation mode* (parameter 17081) must be *Battery leading*.
4. *Mains charging* (parameter 17022) must be *Enabled*.
5. *Mains charge mode* (parameter 17025) must be *SOC + plant assist charging*.

If *SOC-based charging only* is selected in parameter 17025, the controller does not try to help to meet the mains set point. Instead, the controller charges from the mains based on the ESS SOC. *SOC-based charging only* is recommended if the battery has limited charge cycles.

Storage > Charge scheme

Parameter	Name	Range	Default	Details
17022	Mains Charging	0 to 100 % of battery nominal power Not enabled, Enabled	100 %, Not enabled	Enabled: The ESS can recharge from mains. The set point is the maximum charging rate. If the ESS is running as an energy function, it will not recharge from mains. Not enabled: The ESS cannot recharge from mains.
17024	PS charging limit	Not enabled, Enabled	Not enabled	If enabled, for peak shaving operation, the controller uses the peak shaving set point as the mains charging limit.
17025	Mains charge mode	SOC-based charging only SOC + plant assist charging	SOC + plant assist charging	For plant assist charging, if the state of charge allows, the battery discharges as required to help meet the plant set points. For example, for peak shaving, the battery can discharge to prevent consumption that exceeds the set point.

7.4 Grid-forming or grid-following

These modes are controlled by the battery/storage controller using the PCS and BCU.

Grid-forming

Grid-forming is also called island, or V/f mode. For grid-forming mode, the controller can act as the only energy source. The battery can provide the grid-forming power in island operation, and work together with non-grid-forming sources, like solar and wind.

If the system includes gensets, these are stopped if the load level, battery capacity, and state of charge conditions are fulfilled. When the battery is discharged or the load increases beyond the battery capacity, the gensets are reconnected. The controller can also suppress genset starts from solar controller spinning reserve requests.

Grid-following

Grid-following is also called parallel, or P/Q mode. For grid-following mode, the controller is always connected to another grid-forming source, like a mains or genset. The battery can be used as power buffer, providing spinning reserve and peak shaving. The battery can also be used for time of use (TOU) applications.

Droop mode/VSG mode

If the ESS supports this, the controller can run the ESS in droop mode for both Grid-forming and Grid-following. The controller controls the storage charge and discharge using V/f or P/Q set points from the configured droop curve (that is, like a virtual synchronous generator (VSG)).

7.4.1 Battery droop (VSG)

When the protocol selected in parameter 7561 supports droop, you can configure droop for the battery/storage controller. Adding droop to the battery regulation increases the system stability.

NOTE If battery/storage controller droop parameters are used, make sure that the droop parameters in the PCS matches the controller parameters.



More information

See **DEIF hybrid controller compatibility** for the systems that support droop.

Regulation > Droop

Parameter	Name	Range	Default	Details
2801	Droop config.	ASC parameters BESS comm. reading	ASC parameters	ASC parameters: Parameters 2803 and 2804 are used. BESS comm. reading: This function applies for all protocols, except ATESS Growatt. Parameters 2803 and 2804 are ignored.
2803	Droop f slope	0 to 200 %P/Hz	40 %P/Hz	Change the energy storage system frequency set point in response to load deviations from the nominal load.
2804	Droop U slope	0 to 200 %Q/V	5 %Q/V	Change the energy storage system voltage set point in response to reactive load deviations from the nominal reactive load.
2805	Droop f offset	-10 to 10 Hz	0 Hz	A constant offset to the frequency droop slope while a mains or genset(s) is connected. You can use this to compensate for PCS measurement errors.
2806	Droop U offset	-10 to 10 V	0 V	A constant offset to the voltage droop slope while a mains or genset(s) is connected. You can use this to compensate for PCS measurement errors.



Power-frequency droop example

Settings: Nominal P = 1000 kW, Nominal f = 60 Hz, Droop f slope (2803) = 60 %P/Hz. Power reference = - 50 kW.

Frequency offset = Power reference / (Nominal power x Droop slope) + Nominal frequency

Frequency offset = -50 kW / (1000 kW x 0.60 P/Hz) + 60 Hz = -0.08 Hz + 60 Hz = 59.92 Hz



Reactive power-voltage droop example

Settings: Nominal Q = 1000 kvar, Nominal U = 400 V, Droop U slope (2804) = 5 %Q/V. Reactive power reference = 100 kvar.


Voltage offset = Reactive power reference / (Nominal reactive power x Droop slope) + Nominal voltage

Voltage offset = 100 kvar / (1000 kvar x 0.05 Q/Hz) + 400 V = 2 V + 400 V = 402 V



Droop curve example

The left diagram shows the droop slope. The right diagram shows the frequency offset due to the droop.



7.4.2 Setting the mode

The controller dynamically changes the mode based on the configuration and operating conditions. You can override the mode from M-Logic. Under *Output, Command Battery*, you can select:

- **Set mode to Droop:** The ESS runs in droop mode.
- **Set mode to P/Q:** The ESS runs in grid-following mode.
- **Set mode to V/f:** The ESS runs in grid-forming mode.


7.5 AC- or DC-coupled

7.5.1 AC-coupled connections

The system can include PV (controlled by a solar controller) and an ESS (controlled by a battery/storage controller). These can each be connected to the AC busbar separately.

You can then configure parameters for the ESS charging and discharging. You can also determine which sources (for example, PV, mains and/or gensets) can charge the ESS.


PV and ESS with separate AC connections to the busbar



7.5.2 DC-coupled connections

Alternatively, the photovoltaic and energy storage systems can have a DC power connection to each other. They then only have one AC connection to the grid, and only need one power converter. The PV system does not need an inverter, only a charger for the ESS. To control the ESS charging, the battery/storage controller must control the PDS.

PV and ESS with one AC connection to the busbar



7.5.3 AC- or DC-coupled parameter

Storage > Operation modes

Parameter	Name	Range	Default	Description
17082	Operation mode	DC-Coupled Battery AC-Coupled Battery	AC-Coupled Battery	For DC-Coupled Battery, the PV is not connected to the busbar, but supplies the ESS directly. The ESS power is based on the battery/storage controller parameters. For example, if the ESS is charging from the busbar, then the current from the PDS is reduced.

7.5.4 PDS spinning reserve

You can configure a local PDS spinning reserve in the battery/storage controller. This reserved power can be used to power the load if the PV suddenly fails.

Two spinning reserve parameters are available. For example, one spinning reserve parameter can be used during the day, and the other at night.

Storage > PDS operation

Parameter	Name	Range	Default	Details
17201	PDS spin. res. %1	0 to 100 %	90 %	For the default setting, 90 % of the battery power is reserved for a PV failure. Only 10 % is available to the power management system.
17202	PDS spin. res. %2	0 to 100 %	60 %	For the default setting, 60 % of the battery power is reserved for a PV failure. 40 % of the battery power is available to the power management system.
17203	PDS spin. res. set	PDS Spinning reserve pct 01, PDS Spinning reserve pct 02	PDS Spinning reserve pct 01	Select the PDS spinning reserve parameter to use.

7.6 Using nominal settings

The controller uses the nominal settings as the basis for control (including power management) and protection. That is, set points are configured as a percentage of the nominal setting.

You can have more than one set of nominal settings. Using sets of nominal settings allow users to quickly move equipment to new applications.



More information

See [Nominal settings](#) for general nominal settings information.

7.6.1 Setting the nominal apparent power (S)

The nominal apparent power (S) is the basis of all the PMS calculations. The nominal apparent power is the AC capacity of the power converter. The controller calculates the power converter set point from the nominal apparent power. The maximum power converter set point is the nominal apparent power.

For parameter set 1, configure *Nom. S 1* (parameter 6006). Use the power converter nameplate apparent power (S).

7.6.2 Setting the nominal reactive power (Q)

The nominal reactive power (Q) limits the reactive power that the ESS generates.

For parameter set 1, configure *Nom. Q 1* (parameter 6005). Use the power converter nameplate reactive power (Q).

7.6.3 Setting the nominal power (P)

The nominal power (P) is the total DC capacity of the power converter.

The controller reads the charging capacity (CC) and generating capacity (GC) from the BMS. The controller compares this with the PCS capacity and nominal power. The lowest value is used for the set point for charging and discharging.

For parameter set 1, configure *Nom. P 1* (parameter 6002). Use the power converter nameplate power (P).

7.7 Flowcharts

7.7.1 Functions

The following flowcharts show the most important function principles. The functions included are:


- Start sequence

- Stop sequence

Flowcharts for the mode descriptions are in the **Designer's handbook** for the genset controller.


NOTE These simplified flowcharts are only for guidance.

7.7.2 Start sequence



NOTE * Use *ESB close seq.* (parameter 2350) to enable automatic closing or wait for ESS OK.

7.7.3 Stop sequence




7.8 Modes of operation

7.8.1 ESS operation

The controller can be operated in automatic mode (remote) or manual (local). In automatic, the system will close the ES breaker (if present) and start ESS charging or discharging if the plant has a start signal.

Rules for ESS operation:

- The ESS can only be alone on the busbar if V-f mode (voltage and frequency) or droop mode is supported by the PCS.
- The ESB can only be closed if the busbar voltage and frequency are inside the defined window.
- If the ESB is open, the ESS is stopped.




Operation

Once configured, the controller can run automatically. Alternatively, the display unit allows an operator to start and stop the ESS, and open and close the ES breaker.

NOTE In some cases, the controller does not control the ESS stop. If an ESS stop is required, the controller sends a power set point of 0 kW to the ESS. This effectively stops the ESS.

7.8.2 Island operation

Single-line diagram



NOTE If island operation is selected, the *MB closed* digital input must not be activated.


AUTO mode

The controller automatically starts the ESS and closes the ESS breaker at a digital start command. When the stop command is given, the ESS breaker is tripped, and the ESS is stopped. The start and stop commands are used by activating and deactivating a digital input or with the time-dependent start/stop commands. If time-dependent start/stop commands are used, then AUTO mode must also be used. The display buttons cannot be used in AUTO mode.

MANUAL mode


The operator can use the display buttons to start the ESS, close the ESS breaker, open the ESS breaker, and stop the ESS.

Island operation flowchart (AUTO mode)



7.8.3 Peak shaving

Single-line diagram




AUTO mode

When the mains import increases above the maximum mains import set point, the ESS supplies the extra load, to keep the mains import at the maximum import level.

When the load drops below the maximum mains import set point, the ESS can recharge.

The mains power measurement is required. See **Mains power measurement**.

Peak shaving example



MANUAL mode

When the ESS is parallel to the mains, the ESS is controlled according to the peak shaving set point. The maximum mains import is not exceeded in spite of the MANUAL mode.

Power set points > Mains power export and peak shaving > Day/night power set point


Parameter	Text	Range	Default
7001	Day setting	-20000 to 20000kW	750 kW
7002	Night setting	-20000 to 20000kW	1000 kW
7006	MPE/PS scale	1kW:1kW 1kW:10kW 1kW:100kW 1kW:1000kW	1kW:1kW

You can also adjust these parameters from the utility software. Under *Application supervision*, open the *Plant settings* window.

Power set points > Mains power export and peak shaving > Day/night settings

Parameter	Text	Range	Default
7011	Start hour	0 to 23	8
7012	Start minute	0 to 59	0
7013	Stop hour	0 to 23	16
7014	Stop minute	0 to 59	0


Peak shaving flowchart



NOTE You can enable a [Peak shaving charging limit](#) in parameter 17024.

7.8.4 Mains power export

Single-line diagram




AUTO mode

The mains power export mode can be used to maintain a constant level of exported or imported power through the mains breaker.

The controller monitors the mains power. As required, the ESS charges or discharges to keep the mains power at a fixed level regardless of the load.

The mains power measurement is required. See **Mains power measurement**.

Mains power export example



NOTE The set point of the mains power export can be set to 0 kW. This means that the ESS is parallel to the mains but there is no power import or export.


MANUAL mode

When the ESS is paralleled to the mains, it is controlled according to the mains power export set point.

Parameters

See **Peak shaving**.

Mains power export flowchart



7.8.5 Automatic mains failure

The ESS can automatically supply power if there is a mains failure (see the flowchart below). The ESS does this if the battery/storage controller operation mode parameter (6071) is *Auto. Mains Failure*. Alternatively the mode shift parameter (7081) can be used to change the mode to AMF if there is a mains failure.

The controller starts the AMF function when the mains voltage or frequency are outside the configured range for the configured time. Depending on the ESS breaker auto close condition parameter (2360), the controller can keep the mains breaker closed until the ESS is ready to take over.

The ESS power supply during AMF cannot be below the minimum dispatch or above the maximum dispatch.

For the controller to stop the AMF function, the mains voltage and frequency must be within the hysteresis range for the configured time. If the back synchronisation parameter (7084) is enabled, the controller can close the mains breaker while the ESS is still running.

Mains failure parameters

Mains > AMF functions > Modeshift

Parameter	Name	Range	Default
7081	Mode shift	Mode shift off Mode shift on	Mode shift off

Mains > Voltage and frequency limits > Voltage settings

Parameter	Name	Range	Default
7063	Low voltage	30 to 100 % of nominal voltage	90 %
7064	High voltage	100 to 120 % of nominal voltage	110 %

Mains > AMF functions > AMF voltage timers

Parameter	Name	Range	Default
7061	U mains failure	0.5 to 990 s	5 s

Mains > Voltage and frequency limits > Frequency settings

Parameter	Name	Range	Default
7073	Low frequency	80 to 100 % of nominal frequency	95 %
7074	High frequency	100 to 120 % of nominal frequency	105 %

Mains > AMF functions > AMF frequency timers

Parameter	Name	Range	Default
7071	f mains failure	0.5 to 990 s	5 s

Operation during AMF parameters**Storage > Dispatch limits**

Parameter	Name	Range	Default
17093	Minimum dispatch	-100 to 100 % of ESS nominal power	-100 %
17094	Maximum dispatch	-100 to 100 % of ESS nominal power	100 %

Mains OK parameters**Mains > Voltage and frequency limits > Voltage settings**

Parameter	Name	Range	Default
7091	Low volt. hyst.	0 to 70 % of nominal voltage	0 %
7092	High volt. hyst.	0 to 20 % of nominal voltage	0 %

Mains > AMF functions > AMF voltage timers

Parameter	Name	Range	Default
7062	Mains OK delay U	2 to 9900 s	60 s


Mains > Voltage and frequency limits > Frequency settings

Parameter	Name	Range	Default
7093	Low freq. hyst.	0 to 20 % of nominal frequency	0 %
7094	High freq. hyst.	0 to 20 % of nominal frequency	0 %

Mains > AMF functions > AMF frequency timers

Parameter	Name	Range	Default
7072	Mains OK delay f	2 to 9900 s	60 s

AMF flowchart



7.9 Regulation

7.9.1 ESS power reference

The power reference is the value that the controller sends to the ESS to regulate the power produced by the ESS. You can enable an active power (P) and/or a reactive power (Q) reference. To accommodate the ESS's self-consumption, you can also specify a constant and/or a dynamic gain for the P reference.

Regulation > Enable regulation

Parameter	Name	Range	Default	Details
2781	P reference	Not enabled, Enabled	Enabled	Enabled: The controller sends the active power reference to the ESS. Not enabled: Only if parameter 7564 is Single register 0x06 , the controller does not send the active power reference to the ESS.
2782	Q reference	Not enabled, Enabled	Enabled	Enabled: The controller sends the reactive power reference to the ESS. Not enabled: Only if parameter 7564 is Single register 0x06 , the controller does not send the reactive power reference to the ESS.

Regulation > P reference gain

Parameter	Name	Range	Default	Details
2671	P ref. const. gain	0 to 10 % of nominal apparent power (S)	0 %	Adds a percentage of the nominal apparent power to the active power reference. You can use this parameter to compensate for a constant power loss.
2672	P ref. dyn. gain	0 to 10 % of the P reference	0 %	Dynamically adds a percentage of the power reference to the power reference. You can use this parameter to compensate for a dynamic power loss.



Example of P reference gain

The ESS nominal power is 1500 kW, and the apparent power is 1875 kVA.

If parameter 2671 is 1 %, the controller always adds 187.5 kW to the power reference. If parameter 2672 is 10 %, the controller multiplies the power reference by 110 %.

For example, without the gain, the power reference is 500 kW. With the gain, the controller sends a power reference of $(500 \times 1.1 + 187.5) \text{ kW} = 737.5 \text{ kW}$ to the ESS.

7.9.2 Voltage reference

Regulation > U/f ref. origin

Parameter	Name	Range	Default	Description
2661	U ref. origin	Nominal value Busbar measurement	Nominal value	By default, the controller uses the nominal voltage as the regulation voltage reference. To improve regulation and avoid high Q when closing the ESB, you can configure the controller to use the busbar voltage measurement when the mains is connected.
2663	Uf origin config	Mains on busbar Mains or genset only Any voltage source on busbar	Mains on busbar	This parameter determines when the voltage and frequency reference parameters are active.
2664	U ref. gain	-100 to 100 %	0	You can set a custom voltage reference gain. This gain is added the nominal voltage. This can be useful for adjusting the voltage for the internal transformers of the PCS.

7.9.3 Frequency reference

Regulation > U/f ref. origin

Parameter	Name	Range	Default	Description
2662	f ref. origin	Nominal value Busbar measurement	Nominal value	By default, the controller uses the nominal frequency as the regulation frequency reference. To improve regulation and avoid high frequency when closing the ESB, you can configure the controller to use the busbar frequency measurement when the mains is connected.

7.9.4 Reactive power (kvar)

You can use a variety of reactive power regulation methods to regulate the reactive power from the energy storage system.

There are parameters for grid-tied and off-grid modes:

Power set points > Fixed power

Parameter	Name	Range	Default	Grid-tied	Off-grid	Details
7052	Cosphi ref	0.6 to 1	0.9	●		Use this parameter to configure the fixed power cos phi set point. When the ESS is running in parallel to the utility with fixed cos phi reference, it follows this set point.

Power set points > Q ref. grid-tied

Parameter	Name	Range	Default	Details
7053	Cosphi ref	Inductive, Capacitive	Inductive	This parameter makes it possible to select inductive or capacitive reference from the cos phi dispatch.
7054	Contr. sett. Q	-20000 to 20000 kvar	500 kvar	For a fixed Q [kvar], the power converter uses the set point in this parameter.
7055	Q type grid-tie	See below.	Cosphi superior	See the section below.


Power set points > Q ref. off-grid

Parameter	Name	Range	Default	Details
7031	GEN cosphi lim I	0.1 to 1	0.8	The limit of the genset cos phi on the inductive side. For example, if set to 0.95, the genset will only deliver reactive load up to a maximum of 0.95 inductive. If the actual load has characteristic of 0.9, the power converter carries the remainder from 0.95 to 0.9. If there are multiple battery/storage controllers in the application, the set point for this parameter must be the same in each controller.
7032	GEN cosphi lim C	0.10 to 1.00	0.80	The limit of the genset cos phi on the capacitive side. If set to for example 1.00, the genset will not be able to operate with the capacitive power factor (under-excited). If the menu 7031 is set to 1.00 and 7032 is set to 1.00, the genset will not carry any Q at all. The power converter supplies all Q (under the assumption they support it). If there are multiple battery/storage controllers in the application, the set point for this parameter must be the same in each controller.
7033	Q type off-grid	Off, Q share	Off	Q share: Equal var sharing (in percent) between the gensets and the power converter is enabled.

Parameter	Name	Range	Default	Details
				Off: The settings in parameters 7031 or 7032 (that is, the GEN cosphi limit) is used. The ESS produces reactive power to help the genset within the cosphi limits.
7034	GEN cosphi min I	Not enabled, Enabled 0.00 to 1.00	Not enabled, 1.00	When enabled, the controller adds reactive power to the ESS to ensure that this is the minimum inductive power factor for the gensets. The controller only uses this parameter during off-grid operation.

7055, Method of var regulation

- **Off:** No Q control when the MB is closed or when fixed power mode is selected.
- **Cosphi fixed:** The power converter maintains a fixed cos phi (set in parameter 7052).
- **Cosphi imp/exp:** The power converter is regulated against a cos phi set point in parameter 7052.
 - **Measured at the point of connection:** A power meter or measurement transducers are needed to measure the reactive power imported to or exported from the plant. The power converter is regulated accordingly.



- **Cosphi superior:** This is used if the application is a power management application and the cos phi set point is controlled at the mains controller. If one or several battery/storage controllers are used, it is often more convenient to adjust the cos phi set point from a central point. That is, the mains controller adjusts the set point, and then transmits the set point to the controller(s). All battery/storage controllers with this setting will follow the mains controller. If one or several battery/storage controllers do not use this setting, they may, for example, use a fixed cos phi set point.
- **Q fixed:** The controller uses the setting in parameter 7054.
- **Q imp/exp:** This requires a power meter/transducer (see **Cosphi imp/exp**) and the Q ref will maintain measure at the point of connection.

7.9.5 Peak shaving charging limit

When the battery/storage controller peak shaving limit is enabled, if the power from the mains is above the peak shaving set point, the ESS cannot charge from the mains. Instead, the battery/storage controller tries to use the remaining SOC to produce power, to get the mains power below the peak shaving set point. For power management, the peak shaving set point is configured in the mains controller.

Battery/storage controller configuration

Storage > Charge scheme

Parameter	Name	Range	Default	Details
17024	PS charging limit	Not enabled Enabled	Not enabled	To optimally charge the ESS in peak shaving operation, enable this parameter.

Mains controller configuration

Parameter	Name	Range	Default	Details
7011	Peak Shaving	-20000 to 20000 kW	750 kW	The peak shaving set point.



More information

See [Charging from mains](#) for how to use energy from the battery (discharging) to help to meet the plant set points.

7.9.6 External set point control

Power set points > External power set point


Parameter	Name	Range	Default	Details
7501	Comm. bus control P	Enabled Not enabled	Not enabled	Enabled: Allows the P reference value to be changed over Modbus. Not enabled: The P reference value cannot be changed over Modbus.
7502	Comm. bus ctrl cosphi	Enabled Not enabled	Not enabled	Enabled: Allows the cosphi reference value to be changed over Modbus. Not enabled: The cosphi reference value cannot be changed over Modbus.
7503	Comm. bus control Q	Enabled Not enabled	Not enabled	Enabled: Allows the Q reference value to be changed over Modbus. Not enabled: The Q reference value cannot be changed over Modbus.
7504	Comm. bus P Q scale	1% 0.1% 0.01%	1%	Change the scale of the external P and Q set points.

7.9.7 Hotel load

You can use the hotel load function to compensate for the power consumption that is outside the battery/storage controller control. The controller adjusts the ESS power reference and nominal power to make sure that there is enough power for the hotel load. The hotel load can be ESS self-consumption, and/or a load can be connected directly the ESS.

To use the hotel load function, the controller needs a measurement of the load from a transducer.

Example of hotel load application



Parameters

Parameter	Name	Range	Default	Details
2821	Hotel load setup	Multi input [20 to 23], Not enabled, Enabled	Multi input 20, Not enabled	When enabled, the controller uses the selected multi-input to calculate the hotel load.
2823	Hotel load range max	0 to 20 000 kW	0 kW	The load that corresponds to the multi-input maximum.



Hotel load example

The controller is in a power management system. The ESS nominal power is 480 kW. The transducer measuring the hotel load is connected to Multi input 20. The hotel load range max is 100 kW. Multi input 20 is configured for a 4-20 mA signal (so 4 mA corresponds to a hotel load of 0 kW, and 20 mA corresponds to 100 kW).

The power management system requires 200 kW, and the hotel load is 50 kW (12 mA).

- For the power management system calculations, the controller adjusts the ESS nominal power to $480 \text{ kW} - 50 \text{ kW} = 430 \text{ kW}$.
- For the power reference to the ESS, the controller uses $200 \text{ kW} + 50 \text{ kW} = 250 \text{ kW}$.

Counters

In the *Counters* window, under the *Hotel load* tab, you can see the total hotel load. You can also see the hotel load for the past day, week, month, and year.

7.9.8 Load ramps

To avoid oscillations, load ramps (up and down) can be configured for both power and reactive power.

Regulation > ESS loading and deloading > Ramp up rates

Parameter	Name	Range	Default	Details
2611	P ramp up	0.1 to 20 % of ESS nominal P/s	2 %/s	Limits the rate of power increase from the battery.
2641	Q ramp up	0.1 to 100 % of ESS nominal Q/s	2 %/s	Limits the rate of reactive power increase from the battery.

Regulation > Frequency ramp limits

Parameter	Name	Range	Default	Details
2900	Over freq. ramp limit	0.00 to 5.00 % of ESS nominal f	0.00 %	If enabled, if the measured frequency is above the nominal frequency by more than this set point, then the ramp down is skipped.
2910	Under freq. ramp limit	0.00 to 5.00 % of ESS nominal f	0.00 %	If enabled, if the measured frequency is below the nominal frequency by more than this set point, then the ramp up is skipped.

Regulation > ESS loading and deloading > Ramp down and offload rates

Parameter	Name	Range	Default	Details
2621	P ramp down	0.1 to 100 % of ESS nominal P/s	2 %/s	Limits the rate of power decrease from the battery.
2622	Ramp open point	1 to 20 % of ESS nominal P	5 %	The breaker cannot open after the ramp down until the load is below this point.
2651	Q ramp down	0.1 to 100 % of ESS nominal Q/s	2 %/s	Limits the rate of reactive power decrease from the battery.

Regulation > ESS loading and deloading > Ramp delays

Parameter	Name	Range	Default	Details
2681	P ramp delay	0.0 to 2.0 s	1.0 s	Minimum time between controller updates to the power reference during a power ramp.
2682	Q ramp delay	0.0 to 2.0 s	1.0 s	Minimum time between controller updates to the reactive power reference during a reactive power ramp.

Regulation > ESS loading and deloading

Parameter	Name	Range	Default	Details
2612	Island ramp	Enabled, Not enabled	Not enabled	Not enabled: The battery will always ramp up to the full load. Enabled: If the battery is in an island PMS and no other power sources are connected, it will take the full load immediately.
2642	Q ramp lim. max	1 to 110 % of ESS nominal Q	90 %	The controller ignores the ramp if the reactive power is above this limit.
2652	Q ramp lim. min	-20 to 50 % of ESS nominal Q	-10 %	The controller ignores the ramp if the reactive power is below this limit.

The reactive power ramp rates are adjusted according to the nominal rating of the power converters ($S=[kVA]$).

If the genset has reverse power, the ramps are ignored.

7.9.9 Heartbeat

Regulation > Heartbeat timer

Parameter	Name	Range	Default	Details
2810	Heartbeat timer	0 to 28800 s Not enabled, Enabled	20 s, Enabled	Enabled: The controller transmits this value to the PCS. If the PCS does not receive a heartbeat signal for this amount of time, the PCS activates an error.

Parameter	Name	Range	Default	Details
				Not enabled: The timeout value is not transmitted to the PCS.

7.9.10 Droop deadband for the ESS

The user can enable the droop deadband functions, and select values for the voltage and frequency droop deadbands. The controller then sends the ESS these values. If the ESS supports these functions, it uses the droop deadbands from the controller. If the ESS does not support droop deadband, then these parameters have no effect.

The functions can also be enabled and disabled from Modbus and M-Logic. You can also use Modbus to set the values for these parameters.

Regulation > Droop deadband

Parameter	Name	Range	Default	Description
2831	Droop DB over f	0.0 to 5.0 Hz	0.0 Hz	Droop deadband region for frequencies above the nominal frequency.
2832	Droop DB under f	0.0 to 5.0 Hz	0.0 Hz	Droop deadband region for frequencies below the nominal frequency.
2833	Droop DB over U	0.00 to 10.00 %	0.00 %	Droop deadband region for voltages above the nominal voltage.
2834	Droop DB under U	0.00 to 10.00 %	0.00 %	Droop deadband region for voltages below the nominal voltage.

7.10 Fail class

All activated alarms must be configured with a fail class. The fail classes define the category of the alarms and the subsequent alarm action. The following tables show the action of each fail class when the energy storage system is running or stopped.

7.10.1 Energy storage system running

Fail class/action	Alarm horn relay	Alarm display	Trip ES breaker	Stop energy storage system
Warning	●	●		
Trip ESB	●	●	●	
Shutdown	●	●	●	●
Trip MB	●	●		

Example: An alarm with the fail class *Shutdown* is activated:

- The controller activates the alarm horn relay.
- The controller displays the alarm on the alarm info screen.
- The controller opens the ES breaker immediately.
- The controller stops the energy storage system immediately.
- The energy storage system cannot be started from the controller (see next table).

7.10.2 Energy storage system stopped

Fail class/action	Alarm horn relay	Alarm display	Block energy storage system start	Block ESB sequence
Warning	●	●		
Trip ESB	●	●		●
Shutdown	●	●	●	●
Trip MB	●	●		

7.11 Alarm inhibit

To limit when the alarms are active, each alarm has configurable inhibit settings. The inhibits are only available in the USW.

Each alarm has a drop-down window where you can select which conditions have to be present to inhibit the alarm. You can select more than one inhibit. The alarm is inhibited as long as at least one of the selected inhibits is active.

Inhibit	Description
Inhibit 1	M-Logic outputs: The conditions are programmed in M-Logic.
Inhibit 2	
Inhibit 3	
ESB ON	The ESS breaker is closed.
ESB OFF	The ESS breaker is open.
Run status	The ESS voltage and frequency is okay, and the timer in parameter 6160 has expired.
Not run status	The ESS is off, or the timer in parameter 6160 has not expired.
ESS voltage > 30 %	The ESS voltage is above 30 % of the nominal voltage.
ESS voltage < 30 %	The ESS voltage is below 30 % of the nominal voltage.
MB on	The mains breaker is closed (single controller application).
MB off	The mains breaker is open (single controller application).
Parallel	Both the ESB and MB are closed.
Not parallel	Either the ESB or MB can be closed, but not both.

NOTE Function inputs such as remote start or access lock are never inhibited. Only alarm inputs can be inhibited.

7.12 Mode overview

The controller has four running modes and one block mode:

- **AUTO:** The controller operates automatically, and the operator cannot initiate any sequences manually.
- **MANUAL:** The operator has to initiate all sequences. This can be done using the buttons, Modbus commands, or digital inputs. When started, the ESS runs at the nominal values.

7.12.1 MANUAL mode

The controller can be operated in MANUAL mode. This means that the controller does not initiate any sequences automatically. It only initiates sequences if external signals are given.

An external signal may be given by:

1. Buttons on the display
2. Digital inputs*

3. Modbus commands

NOTE * The controller has a limited number of digital inputs. See **Digital inputs** for availability.

MANUAL mode commands

Command	Description
Start	The ESS start sequence is initiated
Stop	The ESS is stopped.
Close ESB	The controller closes the energy storage system breaker if the mains breaker is open, or synchronise and close the energy storage system breaker if the mains breaker is closed.
Open ESB	The controller ramps down and opens the energy storage system breaker at the breaker open point if the mains breaker is closed. The controller opens the energy storage system breaker instantly if the mains breaker is open or the controller is in island operation.
Close MB	The controller closes the mains breaker if the energy storage system breaker is open, or synchronises and closes the mains breaker if the energy storage system breaker is closed.
Open MB	The controller opens the mains breaker instantly.

NOTE Before software version 1.30, MANUAL mode was called SEMI-AUTO mode.

7.12.2 Not in AUTO mode

This function activates an alarm if the system is not in AUTO mode.


Functions > Not in Auto

Parameter	Text	Range	Default
6541	Timer	10.0 to 900.0 s	300.0 s
6544	Enable	OFF ON	OFF
6545	Fail class	Fail classes	Warning

7.13 ESS power measurements


The battery/storage controller terminals can be connected to measure the AC power from the ESS. This is the default configuration.

Controller does the AC measurements



Alternatively, the controller can receive the AC power measurements from the ESS. Select *ESS communication* in parameter 7021.

Controller gets the AC measurements from the ESS



Basic settings > Measurement setup > Wiring connection > Power measure origin

Parameter	Name	Range	Default	Details
7021	ESS power measures	ASC measurements ESS communication DEIF open communication Power meter comm. ASC measurements average	ASC measurements	ASC measurements: The controller uses its own measurements for the ESS power. ESS communication: The controller receives the ESS power values from the ESS. * DEIF open communication: The controller receives the ESS power values over Modbus. Power meter comm.: The controller receives the ESS power values from a power meter. ASC measurements average: The controller uses its own measurements for the ESS power, and uses averaging to smooth them.

NOTE * You can also get the busbar/ESS voltage and frequency measurements from the ESS communication.

Basic settings > Measurement setup > Wiring connection > Busbar/ESS measures

Parameter	Name	Range	Default	Details
7022	BB/ESS V/f meas.	ASC measurements ESS communication	ASC measurements	ASC measurements: The controller uses its own measurements for the busbar/ESS voltage and frequency. ESS communication: The controller uses the ESS measurements for the busbar/ESS voltage and frequency.
7023	V/f from com. fail	0 to 100 s	3 s	This alarm is activated if ESS communication fails and the alarm timer runs out.

V/f from communication failure

If the ESS communication fails, the controller activates the *V/f from com. fail* (menu 7023) alarm. To avoid dangerous situations, the default alarm action is *Shutdown*.

When this alarm is activated, on the display folio, the ESS icon, mains icon, and load lines LEDs flash yellow, red and green.

7.13.1 ESS meter

To use an ESS meter, select *Power meter comm.* in parameter 7021.

Parameter	Name	Range	Default	Details
7702	ESS meter ID	1 to 247	3	Select the ESS power meter ID.
7723	ESS protocol	See DEIF Hybrid controller compatibility	Off	Select the protocol that matches your power meter. Additional protocols may be available. Contact DEIF for details.
7740	ESS meter err.	0 to 60 s Fail classes	0 s Warning	If enabled, this alarm activates when there is no communication from the ESS power meter.

You can also configure these settings from the display, under `Settings > Communication > Power meter > ESS meter settings`

NOTE You can only use an ESS meter if you have *Premium* software.

7.14 Breaker control

7.14.1 Energy storage breaker control

If the ESS allows this, the ESB can close before there is voltage and frequency on the busbar.

Breakers > ES breaker > Breaker configuration

Parameter	Name	Range	Default	Description
2360	Auto close cond	Default Auto start and running	Default	Default: The ESB can close when any of these conditions are met: • The BESS is running and an auto start signal is activated. • A mains is connected. • A genset in auto mode is connected. Auto start and running: The ESB can only close when the BESS is running and an auto start signal is activated.

7.14.2 No ESS breaker control

If the controller does not control the ESS breaker, this affects the mains breaker control. The controller acts as if the ESS breaker is always closed.

Requirements for mains breaker closing

To close the mains breaker, either the ESS must stop, or back synchronising must be enabled in the battery/storage controller.

Synchronisation > Mains parallel settings

Parameter	Name	Range	Default
7083	Back synchronising	Not enabled, Enabled	Not enabled

Requirements for AMF

When mains power is restored after a mains failure, the battery/storage controller stops the ESS briefly so that the mains breaker can close.

7.14.3 No mains breaker control


If the battery/storage controller does not control the mains breaker, this affects the ESS breaker control. The controller acts as if the mains breaker is always closed. For the ESB to close, synchronisation to mains must be enabled.

Parameter	Name	Range	Default
7084	Sync. to mains	Not enabled, Enabled	Enabled

7.15 Monitoring the ESS

7.15.1 ESS data

In the utility software, under *Application supervision*, select *Inverter data*  to open the *Inverter data* window.



7.15.2 ESS labels

In the utility software, select *Identifiers*  to open the *Identifiers* window. Select *Labels* to see and edit the label names.

Identifiers

Communication

SW versions

Labels

ESS ID

25

Site ID

42

ESS name

Big battery 25

ESB name

ESB 25

MB name

MB 42

Mains name

Mains 42

Device name

ESS controller

Parameter name

Parameter name

7.15.3 State of health

The controller reads the state of health (SOH) from the ESS. The controller activates an alarm if the SOH goes below the configured value.


Storage > SOC/SOH alarms > SOH alarms

Parameter	Name	Range	Default	Details
17130	SOH minimum 01	0 to 100 %	20 %	SOH alarm 1
17140	SOH minimum 02	0 to 100 %	15 %	SOH alarm 2

7.15.4 Run status alarm

An alarm can be configured to activate when the running feedback is active and a time delay has expired.

The diagram shows that after the running feedback is activated, the run status delay expires. When the delay expires, the *Run status* alarm (6160) is activated.



NOTE The timer is ignored if digital running feedback is used.

7.15.5 Running output

⚡ Parameter "Run status" (Channel 6160) X

Timer : 5 sec
0 300

Output A Terminal 5

Output B Not used

Password level : customer

☒ Enable
☒ High Alarm
☐ Inverse proportional

☐ Auto acknowledge
Inhibits... ▾

Commissioning

Actual value : 0

Actual timer value

0 sec 5 sec

★ ▾ Write ▾ OK Cancel

You can configure **6160 Run status** to activate a digital output when the ESS is running. Select the relay in *Output A*, and select *Enable*.

DI 39-40-41	DI 42-43-44	DI 45-46-47	DI 48-49-50	MI 20	MI 21	MI 22	MI 23	DO 5 - 18	Ext. P/Q sources
Function		Alarm			Delay		Password		
Output Function		Alarm function							
Output 5		M-Logic / Limit relay			0		Service		

In the relay menu, the relay set point must be *M-Logic / Limit relay*. If the ESS is running, the relay activates, but an alarm is not activated.

If the relay function is not *M-Logic / Limit relay*, an alarm is activated whenever there is running feedback from the ESS.

7.16 Command schedulers

You can use the scheduler to configure up to 24 schedules for the controller modes and set points.

You can view active scheduler from the display unit (from *Service view*) or from the utility software (select *Scheduler* and *Turn ON Live data*). When the schedulers are enabled and active, the corresponding M-Logic events are also activated.

To configure the schedulers, in the utility software, select *Scheduler*.


Example of Scheduler configuration

Schedulers	Enable	Start day	Start hour	Start minute	Stop day	Stop hour	Stop minute	Function	Modes	Active power SP	Q type	In/cap Cosphi	Reactive power SP
Scheduler 1	☒	MO	8	0	MO	14	0	Operation mode	Fixed power	-200	Cosphi fixed	Inductive	0,8
Scheduler 2	☐	MO	16	0	TU	8	0	Operation mode	Fixed power	0	Off	Inductive	
Scheduler 3	☐	TU	16	0	WE	8	0	Operation mode	Fixed power	0	Off	Inductive	
Scheduler 4	☐	WE	16	0	TH	8	0	Operation mode	Fixed power	0	Off	Inductive	
Scheduler 5	☐	TH	16	0	FR	8	0	Operation mode	Fixed power	0	Off	Inductive	
Scheduler 6	☐	FR	15	0	MO	8	0	Operation mode	Fixed power	0	Off	Inductive	
Scheduler 7	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 8	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 9	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 10	☐	FR	0	0	OFF	0	0	OFF / M-logic					
Scheduler 11	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 12	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 13	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 14	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 15	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 16	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 17	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 18	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 19	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 20	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 21	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 22	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 23	☐	OFF	0	0	OFF	0	0	OFF / M-logic					
Scheduler 24	☐	OFF	0	0	OFF	0	0	OFF / M-logic					

Fallback values			
Enable	Operation mode	Battery source	Q type
☒	Auto. Mains Failure	Battery Power Source	Off
Active power SP	Reactive power SP	In/cap cosphi	Cosphi SP
0	0	Inductive	0

This business has an ESS that supplies power if there is a mains failure during business hours. This is configured by enabling the fallback values and selecting *Auto. Mains Failure* (AMF). On Mondays at 08h00, the controller set points are changed to make sure that the ESS charge is topped up (scheduler 1). The green block shows that this scheduler is currently active.

To make sure that AMF is not activated if the power fails after business hours, schedulers 2 to 6 are used to change the settings to fixed power, with the set point at 0. The mode shift parameter (7081) is also *Mode shift off* to stop the controller from changing to AMF during a mains failure. Finally, if there is a mains failure on a Monday morning while the ESS is being topped up, M-Logic is used to change the controller operation mode to AMF.



If the controller operation mode or set points need to be changed at any time, the operator can do so. When the schedulers are activated, they will still change the controller mode and set points.

How it works

When each scheduler starts, the controller changes its parameters according to the values configured for that scheduler. If a scheduler ends and no other scheduler starts, if the fallback values are enabled, the controller uses the fallback values to change its parameters.

If their functions are different, two schedulers can run and be active on the same time. If two schedulers with the same function are active at the same time, the scheduler with the higher number takes priority.



Conflicting schedulers

Schedulers 10 and 20 are configured to be active at the same time, and both have the *Operation mode* function. However, scheduler 10 is configured for *Fixed power*, while scheduler 20 is configured for *Peak shaving*.

Since there is a conflict, scheduler 20 takes priority, since it has a higher number. The controller therefore only changes the *Operation mode* set point to *Peak shaving* when the schedulers are activated.

7.17 M-Logic



More information

See the **Application notes, M-Logic** spreadsheet for a complete list of the M-Logic functions in the controller.

7.18 Additional functions

7.18.1 Electrical data monitoring

In the utility software, under *Application supervision*, select *Electrical Data* ⚡ to open the *Electrical Data* window.

The screenshot shows a software window titled 'Electrical Data' with a blue header bar. On the left is a sidebar with a 'Battery' button. The main area displays a table titled 'Electrical data for Battery (ASC 150 Storage)'. The table has columns for 'Summary', 'U-ESS', 'f-ESS', 'I', 'P', 'Q', 'S', 'U-bb', and 'f-bb'. The data rows show various electrical parameters and their values.

Summary	U-ESS	f-ESS	I	P	Q	S	U-bb	f-bb
UL1L2					400			V
f1					50,00			Hz
I1					768			A
P total					480			kW
Q total					231			kvar
S total					533			kVA
PF					0,90			
Cosphi					0,90			

A 'Close' button is located at the bottom right of the window.

7.18.2 Allow PCS to inhibit MB, TB, or ESB opening

The controller lets the PCS delay the MB, TB, or ESB opening sequence until the PCS has the required grid mode active. If required, you can use parameter 7086 to disable this function.

NOTE During a mains failure, this function does not delay the MB, TB, or ESB opening sequence.

Parameter	Name	Range	Default
7086	Inhibit MB/TB open	Not enabled, Enabled	Enabled

7.18.3 Unsupported application alarm

The controller has configuration limitations. If a configuration rule is broken, the controller activates the *Unsupported application* alarm. The alarm value shows which rule was broken. You can see the alarm value in the alarm log in the utility software.

Alarm value	Configuration rule
19	For a single battery/storage controller, the application includes an energy storage system breaker, a mains breaker, and external generators. - The controller cannot synchronise to the busbar in this configuration. - If there is no energy storage system breaker, the unsupported application alarm is not activated.
20	The battery/storage controller must have option S3 (extended software package) or S4 (premium software package).
21	For a single battery/storage controller with option S3 (extended software package), there is a mains connection on the application configuration diagram.
22	For a single battery/storage controller with option S3 (extended software package), the mains breaker open and close relays are configured.
32	If more than one mains is connected, the battery/storage controller cannot control the mains breaker.
38	For open PMS, the plant can only have one mains connection (external mains or mains controller).
39	For open PMS, only one controller can be connected to an external mains.
40	For an open PMS application, <i>Diesel gen</i> cannot be included as a power source.
41	For an open PMS application, bus tie breakers are not allowed.
52	For power/energy management, when optimal GEN load point with dynamic start/stop is used, PV is not allowed in the application.

Alarm log example

Event log

Alarm log

Monitoring

Application supervision

Alarms

Logs

TimeStamp

Line

Text

Channel

PPower

QPower

PF

PV U1

PV U2

PV U3

PV I1

PV I2

PV I3

PV F

Bus U1

Bus U2

Bus U3

Bus F

Multi input 20

Multi input 21

Multi input 22

Multi input 23

Alarm value

2023-09-14 13:10:48.45

5

CAN ID 1P MISSING

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

1

2023-09-14 13:10:48.45

6

CAN ID 33P MISSING

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

1

2023-09-14 13:10:48.115

7

Miss. all units

7533

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

1

2023-09-14 13:10:48.115

8

Any DG missing

7535

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

1

2023-09-14 13:10:48.115

9

Any BTB miss.

7871

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

1

2023-09-14 13:10:48.415

10

BTB33 pos fail

2420

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

1

2023-09-14 13:11:40.115

11

Unsupported appl.

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

0

39

8. General functions

8.1 Introduction

This chapter describes general controller functions, based on a genset controller. For the battery/storage controller, replace the references to a generator/genset with battery/ESS.

8.2 Password

The controller has three password levels that can be configured on the controller or from the utility software. Parameter settings cannot be changed with a lower ranking password, but are shown on the display.

Parameters

Basic settings > Controller settings > Password

Parameter	Name	Range	Default	Customer access	Service access	Master access
9111	Customer password	00001 to 32000	2000	●		
9112	Service password	00001 to 32000	2001	●	●	
9113	Master password	00001 to 32000	2002	●	●	●

With the utility software it is possible to protect each parameter with a specific password level. Enter the parameter and select the correct password level.

Parameter "Customer password" (Channel 9111)

Set point : 2000

1 32000

Password level : service

☐ Enable

☐ High Alarm

☐ Inverse proportional

☐ Auto acknowledge

Inhibits... ▾

★ Write OK Cancel

The password level can also be changed from the parameter view in the Level column:

1. Right-click the appropriate field in the Level column.
2. Select *Change access level*.
3. Select the required access level.
 - Customer
 - Service
 - Master

You can see and edit permissions in the utility software on the *Tools > Permissions* page.

8.3 AC measurement systems

The controller is designed for measurement of voltages in systems with nominal voltages between 100 and 690 V AC. The AC system can be three-phase, single-phase, or split phase.



More information

See the **Installation instructions** for how to wire the different systems.



CAUTION



Incorrect configuration is dangerous

Configure the correct AC configuration. If in doubt, contact the switchboard manufacturer for information.

Basic settings > Measurement setup > Wiring connection > AC configuration

Parameter	Text	Range	Default
9131	AC configuration	3 phase 3W4 3 phase 3W3 2 phase L1/L3* 2 phase L1/L2* 1 phase L1*	3 phase 3W4
9132	AC configuration BB	3 phase 3W4 3 phase 3W3	3 phase 3W4

NOTE * If this is selected, the same system is used for the busbar, and parameter 9132 is disabled.

8.3.1 Three-phase system

The three-phase system is the default setting for the controller. When this is used, all three phases must be connected to the controller.

The following configuration is required for three-phase measuring.

Basic settings > Nominal settings > Voltage > ESS nominal U

Parameter	Text	Range	Default	Adjust to value
6004	Nom. U 1	100 to 25000 V	400 V	U _{NOM} . Phase-phase voltage of the source. For example, for a 400/230 V AC system, use 400 V AC.

Basic settings > Measurement setup > Voltage transformer > ESS VT

Parameter	Text	Range	Default	Adjust to value
6041	ES primary U	100 to 25000 V	400 V	Primary VT
6042	ES secondary U	100 to 690 V	400 V	Secondary VT

Basic settings > Nominal settings > Voltage > Busbar nominal U

Parameter	Text	Range	Default	Adjust to value
6053	BB nominal U 1	100 to 25000 V	400 V	U _{NOM}

Parameter	Text	Range	Default	Adjust to value
6051	BB primary U 1	100 to 25000 V	400 V	Primary VT
6052	BB secondary U 1	100 to 690 V	400 V	Secondary VT

NOTE The controller has two sets of busbar transformer settings, which can be enabled individually in this measurement system.

8.3.2 Split-phase system

The split-phase system is a special application, where two phases and neutral are connected to the controller. The controller shows phases L1 and L2/L3 in the display. The phase angle between L1 and L3 is 180 °. Split-phase is possible between L1-L2 or L1-L3.

The following configuration is required for the split phase measuring (example 240/120 V AC).

Parameter	Text	Range	Adjust to value
6004	Nom. U 1	100 to 25000 V	U_{NOM} (120 V AC)

Parameter	Text	Range	Adjust to value
6041	ES primary U	100 to 25000 V	U_{NOM}
6042	ES secondary U	100 to 690 V	U_{NOM}

Parameter	Text	Range	Adjust to value
6053	BB nominal U 1	100 to 25000 V	U_{NOM}

Parameter	Text	Range	Adjust to value
6051	BB primary U 1	100 to 25000 V	U_{NOM}
6052	BB secondary U 1	100 to 690 V	U_{NOM}

The measurement U_{L3L1} shows 240 V AC. The voltage alarm set points refer to the nominal voltage 120 V AC, and U_{L3L1} does not activate any alarm.

NOTE The controller has two sets of busbar transformer settings, which can be enabled individually in this measurement system.

8.3.3 Single-phase system

The single-phase system consists of one phase and the neutral.

The following configuration is required for the single-phase measuring.

Basic settings > Nominal settings > Voltage > ESS nominal U

Parameter	Text	Range	Adjust to value
6004	Nom. U 1	100 to 25000 V	Phase-neutral voltage of the source. For example, for a 230 VAC system, use 230 V AC.

Basic settings > Measurement setup > Voltage transformer > ESS VT

Parameter	Text	Range	Adjust to value
6041	ES primary U	100 to 25000 V	$U_{NOM} \times \sqrt{3}$
6042	ES secondary U	100 to 690 V	$U_{NOM} \times \sqrt{3}$

Basic settings > Nominal settings > Voltage > Busbar nominal U

Parameter	Text	Range	Adjust to value
6053	BB nominal U 1	100 to 25000 V	$U_{NOM} \times \sqrt{3}$

Basic settings > Measurement setup > Voltage transformer > Busbar VT

Parameter	Text	Range	Adjust to value
6051	BB primary U 1	100 to 25000 V	$U_{NOM} \times \sqrt{3}$
6052	BB second. U 1	100 to 690 V	$U_{NOM} \times \sqrt{3}$


NOTE The voltage alarms refer to U_{NOM} (for example, 230 V AC).

NOTE The controller has two sets of busbar transformer settings, which can be enabled individually in this measurement system.

8.3.4 AC measurement averaging

You can use the utility software to set up averaging for a number of AC measurements. The averaged values are then shown on the display unit and in the Modbus values. However, the controller continues to use real-time measurements.

In the utility software, under *I/O & Hardware setup*, select the *AC meas AVG* tab. For each measurement, you can select no averaging (0 ms), averages calculated over 200 ms, or averages calculated over 800 ms.



8.4 Nominal settings

The controller has four sets of nominal settings for the ESS and two sets for the busbar. The four sets of nominal ESS settings can be individually configured.


Alternative configuration > ESS nominal settings

Parameter	Text	Range	Default
6007	Enable nom. set	Nominal setting [1 to 4]	Nominal setting 1

Switch between the nominal settings

You can use the following to switch between the four sets of nominal settings:

1. **Digital input:** M-Logic is used when a digital input is needed to switch between the four sets of nominal settings. Select the required input among the input events, and select the nominal settings in the outputs. For example:



2. **AOP:** M-Logic is used when the AOP is used to switch between the four sets of nominal settings. Select the required AOP button among the input events, and select the nominal settings in the outputs. For example:

The screenshot displays the M-Logic configuration interface. It shows two logic lines, Line 1 and Line 2, each with a title bar indicating the AOP button and the parameter set it activates. Line 1 is titled 'AOP 2 - ID1 (Button 7)' and 'Activate parameter set 1'. It shows a logic diagram where 'Event A' (Button: AOP Buttons) is connected to 'Operator' (OR) and 'Output' (Set parameter 1: Command Param). Line 2 is titled 'AOP 2 - ID1 (Button 8)' and 'Activate parameter set 2'. It shows a similar logic diagram where 'Event A' (Button: AOP Buttons) is connected to 'Operator' (OR) and 'Output' (Set parameter 2: Command Param). The interface includes checkboxes for 'Enable this rule' and a 'Delay (sec.)' field set to 0.

3. **Menu settings:** On the controller or with the utility software.

8.4.1 Default nominal settings

The default nominal settings are settings 1. To use another set of nominal settings, use the parameters under *Alternative configuration*.

Basic settings > Nominal settings > Voltage > ESS nominal U

Parameter	Text	Range	Default
6004	Nom. U 1	100 to 25000 V	400 V

Basic settings > Nominal settings > Voltage > Busbar nominal U

Parameter	Text	Range	Default
6053	BB nominal U 1	100 to 25000 V	400 V

Basic settings > Nominal settings > Current > 3 phase nominal

Parameter	Text	Range	Default
6003	Nom. I 1	0 to 9000 A	867 A

Basic settings > Nominal settings > Current > 4th CT nominal

Parameter	Text	Range	Default
6007	Nom. I E/N/M 1	0 to 9000 A	867 A

Basic settings > Nominal settings > Frequency

Parameter	Text	Range	Default
6001	Nom. f 1	48.0 to 62.0 Hz	50 Hz

Basic settings > Nominal settings > Power > 3 phase nominal

Parameter	Text	Range	Default
6002	Nom. P 1	10 to 20000 kW	480 kW
6005	Nom. Q 1	10 to 20000 kvar	480 kvar
6006	Nom. S 1	10 to 20000 kVA	480 kVA

Parameter	Text	Range	Default
6055	4th CT nom. P 1	10 to 9000 kW	480 kW

8.4.2 Scaling

For applications above 25000 V and below 100 V, adjust the input range to match the actual value of the primary voltage transformer.

Changing the voltage scaling also affects the nominal power scaling.

Parameter	Text	Range	Default	Notes
9030	Scaling	10 to 2500 V 100 to 25000 V 10 to 160000 V 0.4 to 75000 V	100 to 25000 V	10 to 2500 V: This is recommended for power sources up to 150 kVA. The nominal power must be less than 900 kW. 100 to 25000 V: This is recommended for power sources over 150 kVA.

NOTICE

Incorrect configuration is dangerous

Correct all nominal values and the primary VT settings after the scaling (parameter 9030) is changed.

8.5 Step-up and step-down transformers

8.5.1 Step-up transformer


In certain cases, the use of a battery with step-up transformer (called a block) is required. This may be to adapt to the closest grid voltage or to step up the voltage to minimise the losses in cables and also to bring down the cable size. Applications that need a step-up transformer are supported by the controller.

The available functions are:


1. Synchronising with or without phase angle compensation
2. Voltage measurement displayed
3. Battery protections
4. Busbar protections

Typically, the synchronising breaker is on the high voltage (HV) side, and there is no breaker (or only a manually operated one) on the low voltage (LV) side. In some applications, the breaker could also be placed on the LV side. This does not influence the setting in the controller, as long as the breaker and the step-up transformer are both placed between the measuring points used by the controller. The measuring points are shown as black dots.

Battery-transformer block, breaker on LV side



Battery-transformer block, breaker on HV side



The phase angle compensation would not be an issue if there was no phase angle shift across the step-up transformer, but in many cases there is. In Europe, the phase angle shift is described using the vector group description. Instead of vector group, this could also be called clock notation or phase shift.

NOTE When voltage measurement transformers are used, these must be included in the total phase angle compensation.

Example

A 10000 V/400 V step-up transformer is installed after a battery with the nominal voltage of 400 V. The nominal voltage of the busbar is 10000 V. Now, the voltage of the busbar is 10500 V. The battery is running 400 V before synchronising starts, but when attempting to synchronise, the voltage set point will be changed to: $U_{BUS-MEASURED} \cdot U_{BAT-NOM}/U_{BUS-NOM} = 10500 \cdot 400/10000 = 420 \text{ V}$

8.5.2 Vector group for step-up transformer

Vector group definition

The vector group is defined by two letters and a number:

- The first letter is an upper case D or Y, defining whether the HV side windings are in Delta or Wye configuration.
- The second letter is a lower case d, y or z, defining whether the LV side windings are in delta, wye or zigzag configuration.
- The number is the vector group number, defining the phase angle shift between HV and LV side of the step-up transformer. The number is an expression of the LV side lag compared to the HV side voltage. The number is an expression of the lag angle divided by 30 °.

Example

Dy11 = HV side: Delta, LV side: Wye, vector group 11: Phase shift = $11 \times (-30) = -330 \text{ °}$.

Typical vector groups


Vector group	Clock notation	Phase shift	LV lag degrees compared to HV
0	0	0 °	0 °
1	1	-30 °	30 °
2	2	-60 °	60 °
4	4	-120 °	120 °
5	5	-150 °	150 °
6	6	-180 °/180 °	180 °
7	7	150 °	210 °
8	8	120 °	240 °
10	10	60 °	300 °
11	11	30 °	330 °

Parameter	Name	Range	Default	
9141	Angle comp. BB/ESS 1	-179.0 to 179.0 °	0.0 °	Angle compensation for busbar parameter set 1 (selected in parameter 6054)
9142	Angle comp. BB/ESS 2	-179.0 to 179.0 °	0.0 °	Angle compensation for busbar parameter set 2 (selected in parameter 6054)

Vector group 0

The phase angle shift is 0 ° (parameter setting: 0 °).

Yy0 example




1L1 to 2L1 phase angle is 0 °.

Vector group 1

The phase angle shift is -30 ° (parameter setting: 30 °).

Dy1 example




1L1 to 2L1 phase angle is -30 °.

Vector group 11

The phase angle shift is 11 x (-30) = -330/+30 ° (parameter setting: -30 °).

Dy11 example




1L1 to 2L1 phase angle is $-330/+30^\circ$.

Vector group 6


The phase angle shift is $6 \times 30 = 180^\circ$ (parameter setting: 180°).

Yy6 example



1L1 to 2L1 phase angle is $-180/+180^\circ$.

Wiring



- The wiring shown in the diagram should always be used when the controller is used for an energy storage system.
- Select 179° in parameter 9141 when vector group 6 is used.

Comparison table between different terminologies

Vector group	Clock notation	Phase shift	LV lag degrees compared to HV	LV side lagging	LV side leading
0	0	0°	0°	0°	
1	1	-30°	30°	30°	
2	2	-60°	60°	60°	
4	4	-120°	120°	120°	
5	5	-150°	150°	150°	
6	6	$-180^\circ/180^\circ$	180°	180°	180°
7	7	150°	210°		150°
8	8	120°	240°		120°
10	10	60°	300°		60°
11	11	30°	330°		30°

Table to read parameter 9141 compared to a step-up transformer

Vector group	Step-up transformer types	Parameter 9141
0	Yy0, Dd0, Dz0	0°
1	Yd1, Dy1, Yz1	30°
2	Dd2, Dz2	60°
4	Dd4, Dz4	120°

Vector group	Step-up transformer types	Parameter 9141
5	Yd5, Dy5, Yz5	150 °
6	Yy6, Dd6, Dz6	180 °
7	Yd7, Dy7, Yz7	-150 °
8	Dd8, Dz8	-120 °
10	Dd10, Dz10	-60 °
11	Yd11, Dy11, Yz11	-30 °

NOTE DEIF does not take responsibility for the compensation being correct. Before closing the breaker, always validate that systems are aligned.

The settings shown in the table above do not include any phase angle shift made by measurement transformers.

The settings shown in the table above are not correct if a step-down transformer is used (see **Setup of step-down and measurement transformers**).

8.5.3 Setup of step-up and measurement transformers


If the HV side of the transformer transforms the voltage up to a voltage level higher than 690 V AC, you must use measurement transformers. Set up all these parameters from the utility software.

Example

The transformer is a Dz4 step-up transformer with nominal settings of 10/400 V. The energy storage system (ESS) has a nominal voltage of 400 V, a nominal current of 250 A and a nominal power of 140 kW. The measurement transformer has a nominal voltage of 10/100 V and no phase angle twist. The nominal voltage of the busbar (BB) is 10000 V.

Since the ESS nominal voltage is 400 V, there is no need for a voltage measurement transformer on the LV side in this example. The controller can handle up to 690 V, but current transformers must still be set up on the LV side.

In this example, the current transformers have a nominal current of 300/5 A. Because the step-up transformer is a Dz4, there is a phase angle twist of -120 °.



Parameters for step-up and measurement transformers example

Parameter	Path	Comment	Setting
6002	Basic settings > Nominal settings > Current > 3 phase nominal	ESS nominal power	140
6003	Basic settings > Nominal settings > Power > 3 phase nominal	ESS nominal current	250
6004	Basic settings > Nominal settings > Voltage > ESS nominal U	ESS nominal voltage	400

Parameter	Path	Comment	Setting
6041	Basic settings > Measurement setup > Voltage transformer > ESS VT > ES primary U	ESS voltage transformer primary side	400
6042	Basic settings > Measurement setup > Voltage transformer > ESS VT > ES secondary U	ESS voltage transformer secondary side	400
6043	Basic settings > Measurement setup > Current transformer > 3 phase CT > ES Primary I	ESS current transformer primary side	300
6044	Basic settings > Measurement setup > Current transformer > 3 phase CT > ES Secondary I	ESS current transformer secondary side	5
6051	Basic settings > Measurement setup > Voltage transformer > Busbar VT > BB primary U 1	Busbar voltage transformer primary side	10000
6052	Basic settings > Measurement setup > Voltage transformer > Busbar VT > BB second. U 1	Busbar voltage transformer secondary side	100
6053	Basic settings > Nominal settings > Voltage > Busbar nominal U	Busbar nominal voltage	10000
9141	Synchronisation > Angle offset > Angle comp. BB/ESS 1	Phase angle compensation BB/ESS	120 °

The controller can handle nominal voltage levels between 100 and 690 V. If the voltage level in the application is higher or lower, you must use measurement transformers to transform the voltage so that it is between 100 and 690 V.

8.5.4 Vector group for step-down transformer

In some applications, a step-down transformer can also be used. This could be to transform a grid voltage down, so the load can handle the voltage level. The controller is able to synchronise the busbar with the mains, even if there is a step-down transformer with a phase angle shift. The transformer must be between the measuring points for the controller.

If a step-down transformer is used, these settings must be set in parameter 9141 to compensate the phase angle shift.

Vector group	Step-down transformer types	Parameter 9141
0	Yy0, Dd0, Dz0	0 °
1	Yd1, Dy1, Yz1	-30 °
2	Dd2, Dz2	-60 °
4	Dd4, Dz4	-120 °
5	Yd5, Dy5, Yz5	-150 °
6	Yy6, Dd6, Dz6	180 °
7	Yd7, Dy7, Yz7	150 °
8	Dd8, Dz8	120 °
10	Dd10, Dz10	60 °
11	Yd11, Dy11, Yz11	30 °


8.5.5 Setup of step-down and measurement transformers

If the HV side of the transformer has a voltage level higher than 690 V AC, measurement transformers are needed. In this example, the HV side is 690 V, and therefore there is no need for a measurement transformer. The step-down transformer can have a phase angle twist that needs to be compensated for.

Example

The transformer is a Dy1 step-down transformer with nominal settings of 690/400 V. The ESS has a nominal voltage of 690 V, a nominal current of 500 A and a nominal power of 480 kW. There is no measurement transformer in this application, because the controller can measure the voltage levels directly. The nominal voltage of the busbar (BB) is 400 V.

Current transformers are required. In this example, the current transformers have a nominal current of 500/1 A. The step-down transformer is a Dy1, and there is a phase angle twist of +30 °.



Parameters for step-down and measurement transformers example

Parameter	Path	Comment	Setting
6002	Basic settings > Nominal settings > Current > 3 phase nominal	ESS nominal power	480
6003	Basic settings > Nominal settings > Power > 3 phase nominal	ESS nominal current	500
6004	Basic settings > Nominal settings > Voltage > ESS nominal U	ESS nominal voltage	690
6041	Basic settings > Measurement setup > Voltage transformer > ESS VT > ESS primary U	ESS voltage transformer primary side	690
6042	Basic settings > Measurement setup > Voltage transformer > ESS VT > ESS secondary U	ESS voltage transformer secondary side	690
6043	Basic settings > Measurement setup > Current transformer > 3 phase CT > ES primary I	ESS current transformer primary side	500
6044	Basic settings > Measurement setup > Current transformer > 3 phase CT > ES secondary I	ESS current transformer secondary side	1
6051	Basic settings > Measurement setup > Voltage transformer > Busbar VT > BB primary U 1	Busbar voltage transformer primary side	400
6052	Basic settings > Measurement setup > Voltage transformer > Busbar VT > BB second. U 1	Busbar voltage transformer secondary side	400
6053	Basic settings > Nominal settings > Voltage > Busbar nominal U	Busbar nominal voltage	400
9141	Synchronisation > Angle offset > Angle comp. BB/ESS 1	Phase angle compensation BB/G 1	-30 °

8.6 Breakers

8.6.1 Breaker types

There are five breaker type settings. Set the breaker type with the utility software under *Application configuration*.



More information

See **Utility software** for how to set up applications.

Continuous NE and Continuous ND

Continuous NE is a normally energised signal, and *Continuous ND* is a normally de-energised signal. These settings are usually used in combination with a contactor.

The controller only uses the *Close breaker* output:

- Closed: This closes the contactor.
- Open: This opens the contactor.

The *Open breaker* output can be configured for another function.

Pulse

This setting is usually used in combination with a circuit breaker. The controller uses these outputs:

- To close the circuit breaker, the *Close breaker* output is activated (until there is breaker close feedback).
- To open the circuit breaker, the *Open breaker* output is activated (until there is breaker open feedback).

External/ATS no control

This setting is used to show the position of the breaker, but the breaker is not controlled by the controller.

Compact

This setting is usually used in combination with a direct controlled motor driven breaker. The controller uses these outputs:

- The *Close breaker* output closes briefly to close the compact breaker.
- The *Open breaker* output closes to open the compact breaker. The output stays closed long enough to recharge the breaker.

If the compact breaker is tripped externally, it is recharged automatically before next closing.

8.6.2 Breaker spring load time


To avoid breaker close failures in situations where the breaker close command is given before the breaker spring has been loaded, the spring load time can be adjusted.

Principle

You could have a close failure if:

1. The ESS is in AUTO mode, the Auto start/stop input is active, the ESS is running, and the ESB is closed.
2. The Auto start/stop input is deactivated, the stop sequence is executed, and the ESB is opened.
3. If the Auto start/stop input is activated again before the stop sequence is finished, the controller activates an ESB close failure, since the ESB needs time to load the spring before it is ready to close.

The diagram shows an example where a single ESS in island mode is controlled by the Auto start/stop input.



- When the Auto start/stop input deactivates, the breaker opens.
- The Auto start/stop is re-activated immediately after the breaker has opened, for example by the operator using a switch in the switchboard.
- The controller waits a while before sending the close signal again, because the spring load time must expire.

Ensuring time to reload

If the breaker needs time to reload the spring after it has opened, the controller can take this delay into account. This can be controlled through timers in the controller or through digital feedbacks from the breaker, depending on the breaker type:

1. **Timer-controlled.** A load time set point for breakers with no feedback indicating that the spring is loaded. After the breaker has been opened it will not be allowed to close again before the delay has expired. When the timer is running, the remaining time is shown in the display.
2. **Digital input.** A configurable input is used for feedback from the breaker. After the breaker has been opened it cannot close before the configured inputs are active.

If both a timer and breaker feedbacks are used, both requirements must be met before the breaker is allowed to close.

8.6.3 Breaker position failure

The breaker position failure alarm is activated if a controller has no breaker position feedback, or if both feedbacks from the breaker are high.

When a controller has a breaker position failure, it informs the other controllers in the application. The system then blocks the section with the breaker position failure. Sections that are not affected by the breaker position failure can continue to operate.

You can assign a fail class to try to trip the faulty breaker when the controller discovers a breaker position failure.

8.6.4 Breaker sync function

The controller can activate a digital output when the two sides of the breaker are synchronised. That is, the voltage, frequency and phase match across the breaker.

On the *I/O & Hardware setup* page in the utility software, select a digital output, and select the *In Sync* function. When the two sides are synchronised, the digital output is activated.

8.7 M-Logic

The main purpose of M-Logic is to give the operator/designer more flexibility.

M-Logic is used to execute different commands at predefined conditions. M-Logic is not a PLC but substitutes one, if only very simple commands are needed.

M-Logic is a simple tool based on logic events. One or more input conditions are defined, and at the activation of those inputs, the defined output will occur. A great variety of inputs can be selected, such as digital inputs, alarm conditions and running conditions. A variety of the outputs can also be selected, such as relay outputs, change of modes.

You can configure M-Logic in the utility software.

8.7.1 General shortcuts

You can configure your own shortcuts with M-Logic in the utility software. You can see the configured shortcuts when you push the *Shortcut*  button and select *General shortcuts*. If you have not configured a shortcut, then the *General shortcuts* menu is empty.

For a pulse shortcut, the command is sent each time you select the shortcut and press OK in the display menu.

For a switch shortcut, the switch is toggled (on/off) each time you select the shortcut.

Use the *Translations* interface to rename the shortcut.

Example of shortcut pulse

Logic 1

Shortcut to reset horn

Event A

NOT

☐

Shortcut - Pulse 1: Shortcut - Pulse

X

Event B

Not used

X

Event C

Not used

X

Operator

OR

OR

Delay (sec.)

0

Output

Reset horn: Command

X

Enable this rule

☒

Rename SC Pulse 1 to Reset horn.

Example of shortcut switch

Logic 2

Shortcut to select parameter set 1

Event A

NOT

☐

Shortcut - Switch 2: Shortcut - Switch

X

Event B

Not used

X

Event C

Not used

X

Operator

OR

OR

Delay (sec.)

0

Output

Set parameter 1: Command Parameter set

X

Enable this rule

☒

Logic 3

Shortcut to select parameter set 2

Event A

NOT

☒

Shortcut - Switch 2: Shortcut - Switch

X

Event B

Not used

X

Event C

Not used

X

Operator

OR

OR

Delay (sec.)

0

Output

Set parameter 2: Command Parameter set

X


Enable this rule

☒

Rename SC Switch 2 on to Use parameter set 1. Rename SC Switch 2 off to Use parameter set 2.

8.7.2 Oneshots

Description	Notes
Oneshot set [1-16]	The oneshot is activated for a short time (about 100 ms) when the logic is true. If the logic remains true, the oneshot is not activated again. When the logic is false, the function is reset.



Oneshots

Description	Notes
Oneshot output [1-16]	The event is active when the oneshot output is activated.

8.7.3 M-Logic



More information

See the **Application notes, M-Logic** spreadsheet for a complete list of the M-Logic functions in the controller.

8.8 Timers and counters

8.8.1 Command timers

Command timers are used to execute a command at a specific time. For example, to start and stop the genset automatically at specific times on certain weekdays. In AUTO mode, this function is available in island operation, load take-over, mains power export, and fixed power operation.

Up to four command timers can be configured with M-Logic. Each command timer can be set for the following time periods:

- Individual days (MO, TU, WE, TH, FR, SA, SU)
- MO, TU, WE, TH
- MO, TU, WE, TH, FR
- MO, TU, WE, TH, FR, SA, SU
- SA, SU

To start in AUTO mode, the Auto start/stop command can be programmed in M-Logic or in the input settings. The time-dependent commands are flags that are activated when the command timer is in the active period.

8.8.2 USW counters

You can view and adjust a number of counters using the USW. Click the Σ icon to open the counters window.

Battery/storage controller counters example

Counters

OperationsRunning hoursEnergyReEnergyGensetsBatteryBB: EnergyBB: ReEnergy

Export total0kWh

Export year0kWh

Export month0kWh

Export week0kWh

Export day0kWh

Import total0kWh

Import year0kWh

Import month0kWh

Import week0kWh

Import day0kWh


The **Import** counters show the ESS charged energy, while the **Export** counters show the ESS discharged energy.

Counters	Details
Operations	Breaker operations
Running hours	ESS running hours
Energy	Energy to/from the ESS
ReEnergy	Reactive energy to/from the ESS
Gensets	Energy from the gensets
Battery	Counters for each state of charge threshold
BB: Energy	Energy to/from the mains
BB: ReEnergy	Reactive energy to/from the mains

8.9 Interfaces

8.9.1 Additional operator panel, AOP-2

The AOP-2 is an additional operator panel that can be connected to the controller using a CAN bus communication port. It can be used as an interface to the controller for indication of status and alarms together, and with buttons for, for example, alarm acknowledge and mode selection.



The configurable LEDs are named 1 to 16, and the buttons are named 1 to 8.

CAN Node ID configuration

The CAN Node ID for the AOP-2 can be set to 1-9:

1. Press buttons 7 and 8 simultaneously to activate the CAN ID change menu. The LED for the present CAN ID number is ON, and LED 16 is flashing.
2. Use button 7 (increase) and button 8 (decrease) to change the CAN ID according to the table below.
3. Press button 6 to save the CAN ID and return to normal operation.

CAN ID	Indication of CAN ID selection
0	LED 16 flashes (CAN bus OFF)
1	LED 1 ON. LED 16 flashes (default value).
2	LED 2 ON. LED 16 flashes.
3	LED 3 ON. LED 16 flashes.
4	LED 4 ON. LED 16 flashes.
5	LED 5 ON. LED 16 flashes.

Programming

Use the utility software to program the AOP-2. See the **Help** in the utility software.

8.9.2 Access lock

With the access lock on, the operator cannot change controller parameters or running modes. The input to be used for the access lock function is defined in the utility software.

Access lock is typically activated from a key switch installed behind the door of the switchboard cabinet. As soon as access lock is activated, changes from the display cannot be made.

Access lock only locks the display and does not lock any AOP or digital input. AOP can be locked by using M-Logic. It is still possible to read all parameters, timers and the state of inputs in the service menu.

You can read alarms, but not acknowledge them when access lock is activated. Nothing can be changed from the display.

This function is ideal for rental or critical equipment. The operator cannot change anything. If there is an AOP-2, the operator is still able to change up to 8 different predefined things.

NOTE The *Stop* button is not active in MANUAL and NoReg mode when the access lock is activated. For safety reasons, an emergency stop switch is recommended.

8.9.3 Language selection

The controller can show several languages. The default master language is English, which cannot be changed. Different languages can be configured with the utility software.

Basic settings > Controller settings > Language

Parameter	Text	Range	Default
6081	Language selection	English Language [1 to 11]	English

8.10 RRCR external set point control

The grid can use a Radio Ripple Control Receiver (RRCR) for load management. The controller can use the RRCR signals for power and reactive power regulation.

You can use four binary inputs (from an external RRCR) to configure 16 signal combinations. Each of the 16 signal combinations can be used for a set point for *Power*, and a set point for *Reactive Power* or *cos phi*.

You can also make combined set points, for example, *Power* and *Reactive Power*, using the same inputs.

You can use four relay outputs to configure 16 signal combinations for communication with the inverters. These outputs can only be used to represent the *Power* set point.



More information

See **RRCR configuration** in the **AGC-4 Mk II Designer's handbook** for how to use the utility software to configure RRCR.

9. AC protections

9.1 About protections

9.1.1 Protections in general

All protection set points are a percentage of the nominal values.

For most of the protections a set point and time delay is selected. When the timer runs out, the output is activated. The operate time is the delay setting + the reaction time.

When setting up the controller, the measuring class of the controller and an adequate safety margin has to be taken into consideration, for example:

- A power generation system must not reconnect to a network when the voltage is $< 85\%$ of $U_{NOM} \pm 0\%$ or $> 110\% \pm 0\%$. To ensure reconnection within this interval, the controller's tolerance/accuracy has to be taken into consideration. If the reconnection tolerance is $\pm 0\%$, set a controller's set points 1-2 % higher/lower than the actual set point.

General parameter ranges for protections

Setting	Range
Output A	Not used
Output B	12 relays: 5, 6, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18 External I/O: Relays available in the connected CIO(s) Limits
Enable	OFF ON
Fail class	See the controller type

Inhibits

You can only select inhibits using the utility software. Each alarm has a selection list for the inhibit conditions. Inhibit of the alarm is active as long as one of the selected inhibit functions are active.

9.1.2 Phase-neutral voltage trip

If the voltage alarms are to work based on phase-neutral measurements, the voltage detection type for both generator and busbar must be set to phase neutral.

AC configuration and protections > Voltage protections > Voltage detect. type

Parameter	Text	Range	Default
1201	ES U detection type	Ph-Ph Ph-N	Ph-Ph

Busbar > Voltage protections > Voltage detect. type

Parameter	Text	Range	Default
1202	BB U detection type	Ph-Ph Ph-N	Ph-Ph

As shown in the vector diagram below, there is a difference in voltage values at an error situation for the phase-neutral voltage and the phase-phase voltage.


Example: Actual measurements at a 10 % under-voltage situation in a 400/230 volt system

	Phase-neutral	Phase-phase
Nominal voltage	400/230	400/230
Voltage, 10 % error	380/207	360/185

The alarm will occur at two different voltage levels, even though the alarm set point is 10 % in both cases.

The 400 V AC system below shows that the phase-neutral voltage must change 20 %, when the phase-phase voltage changes 40 volts (10 %).

Example



$U_{NOM} = 400/230 \text{ V AC}$

Error measurements

- $U_{L1L2} = 360 \text{ V AC}$
- $U_{L3L1} = 360 \text{ V AC}$
- $U_{L1-N} = 185 \text{ V AC}$
- $\Delta U_{PH-N} = 20 \%$

9.1.3 Phase sequence error and phase rotation

The controller monitors the rotation of the voltage, and activates an alarm if the voltage is rotating in the wrong direction. The controller can monitor the rotation in both directions.

AC configuration and protections > AC configuration > Phase sequence error ES

Parameter	Text	Range	Default
2153	Fail class	Fail classes	Warning

AC configuration and protections > AC configuration > Phase rotation

Parameter	Text	Range	Default
2154	Set point	L1L2L3 L1L3L2	L1L2L3

Busbar > AC configuration > Phase sequence error BB

Parameter	Text	Range	Default
2156	Fail class	Fail classes	Warning

9.1.4 4th current transformer input

The 4th current transformer input (terminals 60-61) can be used for one of these functions:

- **Mains power measurement:** Place the CT on L1 of the mains connection.
- **Neutral line over-current protections:** Place the CT on the N line from the genset.

- **Earth current (ground fault) protections:** Place the CT on the ESS star point ground connection. The function includes third harmonics filtering of the signal.

Basic settings > Measurement setup > Current transformer > 4th CT

Parameter	Text	Range	Default
6045	E/N/M I primary	5 to 9000 A	1000 A
6046	E/N/M I secondary	1 A 5 A	1 A

4th CT input selection

Select what the 4th current transformer input is used for.

Basic settings > Measurement setup > 4th CT protection > 4th CT trip selector

Parameter	Text	Range	Default
14201	4th CT trip select	OFF Mains/BB current Neutral current Earth fault current	OFF

9.2 ESS protections

The *operate time* is defined in IEC 447-05-05 (from the instant when the need for protection arises, to when the controller output has responded). For each protection, the *operate time* is given for the minimum user-defined time delay.


Protection	IEC symbol (IEC 60617)	ANSI (IEEE C37.2)	Operate time	Alarms
Over-voltage	U>, U>>	59	< 200 ms	2
Under-voltage	U<, U<<	27P	< 200 ms	3
Unbalanced voltage	UUB>	47	< 200 ms*	1
Negative sequence voltage high		47	< 400 ms*	1
Zero sequence voltage high		59U ₀	< 400 ms*	1
Over-current	3I>, 3I>>	50TD	< 200 ms	4
Fast over-current	3I>>>	50P	< 40 ms	2
Unbalanced current	IUB>	46	< 200 ms*	1
Directional over-current		67	< 100 ms	2
Inverse time over-current	It>	51	-	1
Neutral inverse time over-current		51N	-	1
Earth fault inverse time-over current		51G	-	1
Negative sequence current high		46I ₂	< 200 ms*	1
Zero sequence current high		50I ₀	< 400 ms*	1
Over-frequency	f>, f>>	81O	< 300 ms	3
Under-frequency	f<, f<<	81U	< 300 ms	3
Overload	P>, P>>	32F	< 200 ms	5
Reverse power	P<, P<<	32R	< 200 ms	2
Over-excitation or reactive power export	Q>, Q>>	40O	< 200 ms	1
Under-excitation or reactive power import	Q<, Q<<	40U	< 200 ms	1

NOTE * These operate times include the minimum user-defined delay of 100 ms.

9.2.1 Over-voltage (ANSI 59)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Over-voltage	U>, U>>	59	< 200 ms

The alarm response is based on the highest phase-to-phase voltage, or the highest phase-to-neutral voltage, from the source, as measured by the controller. The phase-to-phase voltage is the default.




AC configuration and protections > Voltage protections > Over-voltage > ES U> [1 or 2]

Parameter	Text	Range	ES U> 1	ES U> 2
1150 or 1160	Set point	100 to 130 %	103 %	105 %
	Timer	0.1 to 100 s	10 s	5 s
	Enable	OFF ON	OFF	OFF
	Fail class	Fail classes	Warning	Warning

9.2.2 Under-voltage (ANSI 27P)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Under-voltage	U<, U<<	27P	< 200 ms

The alarm response is based on the lowest phase-to-phase voltage, or the lowest phase-to-neutral voltage, from the source, as measured by the controller. The phase-to-phase voltage is the default.



AC configuration and protections > Voltage protections > Under-voltage > ES U< [1 to 3]

Parameter	Text	Range	ES U< 1	ES U< 2	ES U< 3
1170, 1180 or 1190	Set point	40 to 100 %	97 %	95 %	95 %
	Timer	0.1 to 100 s	10 s	5 s	5 s
	Enable	OFF ON	OFF	OFF	OFF
	Fail class	Fail classes	Warning	Warning	Warning


9.2.3 Unbalanced voltage (ANSI 47)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Unbalanced voltage	UUB>	47	< 200 ms*

NOTE * The operate time includes the minimum user-defined delay of 100 ms.

The alarm response is based on the highest difference between any of the three phase-to-phase voltage or phase-to-neutral true RMS values and the average voltage, as measured by the controller. The phase-to-phase voltage is the default.

If phase-to-phase voltages are used, the controller calculates the average phase-to-phase voltage. The controller then calculates the difference between each phase-to-phase voltage and the average voltage. Finally, the controller divides the maximum difference by the average voltage to get the voltage unbalance.



AC configuration and parameters > Voltage protections > Voltage unbalance > ES
Unbalance U

Parameter	Text	Range	Default
1510	Set point	0 to 50 %	10 %
	Timer	0.1 to 100 s	10 s
	Enable	OFF ON	OFF
	Fail class	Fail classes	Trip ESB

9.2.4 Negative sequence voltage high (ANSI 47)


Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Negative sequence voltage high		47	< 400 ms*

NOTE * The operate time includes the minimum user-defined delay of 100 ms.

Negative sequence voltages arise when the virtual representation of the phase rotation for an unbalanced system appears negative.

Negative sequence voltages can occur where there are single phase loads, unbalanced line short circuits and open conductors, and/or unbalanced phase-to-phase or phase-to-neutral loads.

The alarm response is based on the estimated phase-to-neutral voltage phasors, as measured from the source.



AC configuration and protections > Voltage protections > Negative seq. voltage > ES neg. seq. U

Parameter	Text	Range	Default
1550	Set point	1 to 100 %	5 %
	Timer	0.2 to 100 s	0.5 s
	Enable	OFF ON	OFF
	Fail class	Fail classes	Trip MB

AC configuration and protections > Voltage protections > Negative seq. voltage > Neg. seq select

Parameter	Text	Range	Default
1561	Set point	ESS measurement BB measurement	ESS measurement

9.2.5 Zero sequence voltage high (ANSI 59U₀)


Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Zero sequence voltage high		59U ₀	< 400 ms*

NOTE * The operate time includes the minimum user-defined delay of 100 ms.

Zero sequence voltages arise when the phases rotation is positive, but the vector zero value (star point) is displaced. This zero sequence voltage protection can be used instead of using zero voltage measurement or summation transformers (zero sequence transformers).

This protection is used for detecting earth faults.

The alarm response is based on the estimated phase-to-neutral voltage phasors, as measured from the source.



AC configuration and protections > Voltage protections > Zero sequence voltage > ES zero seq. U

Parameter	Text	Range	Default
1580	Set point	0 to 100 %	5 %
	Timer	0.2 to 100 s	0.5 s
	Enable	OFF ON	OFF
	Fail class	Fail classes	Trip MB


AC configuration and protections > Voltage protections > Zero sequence voltage > Zero seq select

Parameter	Text	Range	Default
1591	Type	ESS measurement BB measurement	ESS measurement

9.2.6 Over-current (ANSI 50TD)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Over-current	3I>, 3I>>	50TD	< 200 ms

The alarm response is based on the highest phase current true RMS value from the source, as measured by the controller.



AC configuration and protections > Current protections > Over-current > I> [1 to 4]


Parameter	Text	Range	I> 1	I> 2	I> 3	I> 4
1030, 1040, 1050 or 1060	Set point	50 to 200 %	115 %	120 %	115 %	120 %
	Timer	0.1 to 3200 s	10 s	5 s	10 s	5 s
	Enable	OFF ON	ON	ON	ON	ON
	Fail class	Fail classes	Warning	Trip ESB	Trip ESB	Trip ESB

9.2.7 Fast over-current (ANSI 50P)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Fast over-current	3I>>>	50P*	< 40 ms

NOTE * ANSI 50 applies when the Delay parameter is 0 s.

The alarm response is based on the highest phase current true RMS values from the source, as measured by the controller.



AC configuration and protections > Current protections > Fast over-current > I>> [1 or 2]


Parameter	Text	Range	I>> 1	I>> 2
1130 or 1140	Set point	150 to 300 %	150 %	200 %
	Timer	0 to 3200 s	2 s	0.5 s
	Enable	OFF ON	OFF	OFF
	Fail class	Fail classes	Trip ESB	Trip ESB

9.2.8 Unbalanced current (ANSI 46)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Unbalanced current	IUB>	46	< 200 ms*

NOTE * The operate time includes the minimum user-defined delay of 100 ms.

The alarm response is based on the highest difference between any of the three phase current true RMS values, as measured by the controller. You can choose either the *Average* method (ANSI) or the *Nominal* method to calculate the current unbalance.



AC configuration and protections > Current protections > Unbalance current > Unbalance I [1 or 2]

Parameter	Text	Range	Unbalance I 1	Unbalance I 2
1500 or 1710	Set point	0 to 100 %	30 %	40 %
	Timer	0.1 to 100 s	10 s	10 s
	Enable	OFF ON	OFF	OFF
	Fail class	Fail classes	Trip ESB	Trip ESB

AC configuration and protections > Current protections > Unbalance current > Type

Parameter	Text	Range	Default
1203	Type	Ref. to nominal Ref. to average	Ref. to nominal

NOTE The *Average method* is very sensitive at low loads.

The average method uses the ANSI standard calculation method to determine current unbalance. The controller calculates the average current for the three phases. The controller then calculates the difference between each phase current and the average current. Finally, the controller divides the maximum difference by the average current to get the current unbalance.



Average method example

The controller controls an ESS with a nominal current of 100 A. The L1 current is 80 A, the L2 current is 90 A, and the L3 current is 60 A.

The average current is 76.7 A. The difference between the phase current and the average is 3.3 A for L1, 13.3 A for L2 and 16.7 A for L3.

The current unbalance is therefore $16.7 \text{ A} / 76.7 \text{ A} = 0.22 = 22 \%$.

With the nominal method the controller calculates the difference between the phase with the highest current, and the phase with the lowest current. Finally, the controller divides the difference by the nominal current to get the current unbalance.



Nominal method example

The controller controls an ESS with a nominal current of 100 A. The L1 current is 80 A, the L2 current is 90 A, and the L3 current is 60 A.

The current unbalance is $(90 \text{ A} - 60 \text{ A}) / 100 \text{ A} = 0.3 = 30 \%$.

9.2.9 Voltage-dependent over-current (ANSI 51V)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Voltage-dependent over-current	Iv>	51V	-

This protection is activated when a short circuit is present and the voltage drops. The current rises briefly, before it falling to a lower level.

The short circuit current level can drop below the rated current of the ESS, and thus the short circuit will not be tripped, if a standard ANSI 50/50TD is used. When the short circuit is present, the voltage will be low. This can be used for tripping at a lower current, when the voltage is low.

AC configuration and protections > Current protections > Voltage dependent over-current


Parameter	Text	Range	Default
1101	ES Iv> (50 %)	50 to 200 %	110 %
1102	ES Iv> (60 %)	50 to 200 %	125 %
1103	ES Iv> (70 %)	50 to 200 %	140 %
1104	ES Iv> (80 %)	50 to 200 %	155 %
1105	ES Iv> (90 %)	50 to 200 %	170 %
1106	ES Iv> (100 %)	50 to 200 %	200 %
1110	Fail class	Fail classes	Trip ESB

Example

There are six current and voltage level set points. The voltage levels are pre-set, so only the current levels must be set. All values are in percentage of the nominal settings. The default values are shown in the table below.

Parameter	Voltage level (not adjustable)	Current level (adjustable)
1101	50 %	50 %
1102	60 %	55 %
1103	70 %	65 %
1104	80 %	80 %
1105	90 %	100 %
1106	100 %	130 %

The set points can be shown on a curve:




When the operating values are above the curve, the breaker is tripped. The ESB also trips when the ESS voltage is below 50 % of rated, and the current is above 50 % of rated.

9.2.10 Directional over-current (ANSI 67)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Directional over-current		67	< 100 ms

The alarm response is based on the highest phase current true RMS value, with the direction from the active power from the source, as measured by the controller.



AC configuration and protections > Current protections > Directional over-current > I>direct. [1 or 2]

Parameter	Text	Range	I> direct. 1	I> direct. 2
1600 or 1610	Set point	-200 to 200 %	120 %	130 %
	Timer	0 to 3200 s	0.1 s	0.1 s
	Enable	OFF ON	OFF	OFF
	Fail class	Fail classes	Trip MB	Trip MB


NOTE For a positive set point, the alarm trigger level is *High*. When a negative set point is written to the controller, then the controller automatically changes the alarm trigger level to *Low*.

9.2.11 Neutral over-current (4th CT)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Neutral over-current (4th CT)			-

This is the over-current alarm for the neutral current measurement.

The alarm response is based on the unfiltered neutral current, as measured by the 4th current.



AC configuration and protections > Current protections > Neutral over-current (4th CT)
> 4th CT In> [1 or 2]


Parameter	Text	Range	In> 1	In> 2
14210 or 14220	Enable	OFF ON	OFF	OFF
	Set point	2 to 120 %	30 %	30 %
	Timer	0.1 to 3200 s	10 s	10 s
	Fail class	Fail classes	Warning	Warning

9.2.12 Earth fault over-current (4th CT)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Earth fault over-current (4th CT)			-

This is the over-current alarm for the earth current measurement.

The alarm response is based on the ground current, as measured by the 4th current measurement filtered to attenuate the third harmonic (at least 18 dB).



AC configuration and protections > Current protections > Earth fault over-current (4th CT)
> 4th CT Ie> [1 or 2]


Parameter	Text	Range	Ie> 1	Ie> 2
14230 or 14240	Enable	OFF ON	OFF	OFF
	Set point	2 to 120 %	10 %	10 %
	Timer	0.1 to 3200 s	10 s	10 s
	Fail class	Fail classes	Warning	Warning

9.2.13 Inverse time over-current (ANSI 51)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Inverse time over-current	It>	51	-

The alarm response is based on the highest phase current true RMS values, as measured by the controller.

The alarm response time depends on an approximated integral of the current measurement over time. The integral is only updated when the measurement is above the activation threshold (dotted curve on the diagram). See the description below for more details.



NOTE The diagram on the right is a simplified representation of this alarm. The diagram does not show the integral over time.

Inverse time over-current calculation method

The controller uses this equation from IEC 60255-151 to calculate the time that the current measurement may be over the set point before the inverse time over-current alarm is activated:

$$t(G) = TMS \left(\frac{k}{\left(\frac{G}{G_s} \right)^\alpha - 1} + c \right)$$

where:

- $t(G)$ = Theoretical operating time value at G , in seconds
- k , c and α = Constants for the selected curve (k and c in seconds, α (alpha) has no unit)
- G = Measured value, that is, I_{phase}
- G_s = Alarm set point ($G_s = I_{\text{nom}} \cdot \text{Limit} / 100 \%$)
- TMS = Time multiplier setting

AC configuration and protections > Current protections > Inverse time over-current


Parameter	Text	Range	Default
1081	I> inverse type	IEC Inverse IEC Very Inverse IEC Extremely inverse IEEE Moderately Inv. IEEE Very Inverse IEEE Extremely Inv. Custom	IEC Inverse
1082	I> inverse Limit	50 to 200 %	110 %
1083	I> inverse TMS	0.01 to 100.00	1.00
1084	I> inverse k	0.001 to 32.000 s	0.140 s
1085	I> inverse c	0.000 to 32.000 s	0.000 s
1086	I> inverse a	0.001 to 32.000 s	0.020 s
1088	Enable	OFF ON	ON
1089	Fail class	Fail classes	Trip ESB

Standard inverse time over-current curves

The controller includes these standard inverse time over-current curves, in accordance with IEC 60255-151.

Curve name	k	c	alpha (α, or a)
IEC inverse	0.14 s	0 s	0.02
IEC very inverse	13.5 s	0 s	1
IEC extremely inverse	80 s	0 s	2
IEEE moderately inverse	0.0515 s	0.114 s	0.02
IEEE very inverse	19.61 s	0.491 s	2
IEEE extremely inverse	28.2 s	0.1217 s	2


Standard curve shapes for inverse time over-current, with time multiplier setting (TMS) = 1



Definite time characteristic

G_D is the point where the alarm shifts from an inverse curve to a definite time characteristic, as the following graph shows. That is, after this point, the curve is flat, and a current increase does not have any effect on the alarm response time. In IEC60255, this point is defined as $G_D = 20 \times G_s$.

Inverse time over-current time characteristic graph





Influence of the CT primary current rating on G_D example

A current transformer has a primary rating of 500 A and a secondary rating of 5 A. The nominal current of the system is 350 A, and the three-phase inverse time over-current alarm *Limit* is 100 %.

G_D of the inverse time over-current characteristic graph according to IEC60255 is 7000 A.

- $G_D = 20 \times G_S = 20 \times (I_{nom} \times (Limit / 100)) = 20 \times (350 \times (1 / 1)) = 7000 \text{ A}$

However, the highest G_D value where measurements can be made is 1500 A.

- Because the secondary current rating is 5 A, the formula to calculate the measurable G_D is $G_D = 3 \times I_{CT \text{ primary}}$.
- $G_D = 3 \times I_{CT \text{ primary}} = 3 \times 500 = 1500 \text{ A}$

NOTE If the performance of the inverse time over-current protection is important, use a current transformer that is rated for a 1 A secondary current (that is, -/1 A).

9.2.14 Inverse time neutral over-current (ANSI 51N)


Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Neutral inverse time over-current		51N	-

This is the inverse time over-current alarm for the neutral current measurement.

The alarm response is based on the unfiltered (except for anti-aliasing) neutral current, as measured by the 4th current measurement.

The alarm response time depends on an approximated integral of the current measurement over time. The integral is only updated when the measurement is above the activation threshold.

NOTE The diagram on the right is a simplified representation of this alarm. The diagram does not show the integral over time.



AC configuration and protections > Current protections > Neutral inverse time over-current

Parameter	Text	Range	Default
1721	In> inverse Type	IEC Inverse IEC Very Inverse IEC Extremely inverse IEEE Moderately Inv. IEEE Very Inverse IEEE Extremely Inv. Custom	IEC Inverse
1722	In> inverse Limit	2. to 120 %	30 %
1723	In> inverse TMS	0.01 to 100.00	1.00
1724	In> inverse k	0.001 to 32.000 s	0.140 s
1725	In> inverse c	0.000 to 32.000 s	0.000 s
1726	In> inverse a	0.001 to 32.000 s	0.020 s
1727	Enable	OFF ON	OFF
	Fail class	Fail classes	Trip ESB

**More information**

See **Inverse time over-current (ANSI 51)** for the calculation method, the standard curves, and information about the definite time characteristic.

9.2.15 Earth fault inverse time over-current (ANSI 51G)


Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Earth fault inverse time over-current		51G	-

This is the inverse time over-current alarm for the ground current measurement.

The alarm response is based on the ground current, as measured by the 4th current measurement filtered to attenuate the third harmonic (at least 18 dB).

NOTE

The diagram on the right is a simplified representation of this alarm. The diagram does not show the integral over time.



AC configuration and protections > Current protections > Earth fault inverse time over-current

Parameter	Text	Range	Default
1731	le> inverse Type	IEC Inverse IEC Very Inverse IEC Extremely inverse IEEE Moderately Inv. IEEE Very Inverse IEEE Extremely Inv. Custom	-
1732	le> inverse Limit	2 to 120 %	10 %
1733	le> inverse TMS	0.01 to 100.00	1.00
1734	le> inverse k	0.001 to 32.000 s	0.140 s
1735	le> inverse c	0.000 to 32.000 s	0.000 s
1736	le> inverse a	0.001 to 32.000 s	0.020 s
1738	Enable	OFF ON	OFF
1739	Fail class	Fail classes	Trip ESB

**More information**

See **Inverse time over-current (ANSI 51)** for the calculation method, the standard curves, and information about the definite time characteristic.

9.2.16 Negative sequence current high (ANSI 46I₂)


Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Negative sequence current high		46I ₂	< 400 ms*

NOTE * The operate time includes the minimum user-defined delay of 100 ms.

Negative sequence currents arise when the virtual representation of the phase rotation for an unbalanced system appears negative.

Negative sequence currents can occur where there are single phase loads, unbalanced line short circuits and open conductors, and/or unbalanced phase-phase or phase-neutral loads.

The alarm response is based on the estimated phase-to-neutral current phasors, from the source, as measured by the controller.



AC configuration and protections > Current protections > Negative sequence current > Negative. seq. I.

Parameter	Text	Range	Default
1540	Set point	1 to 100 %	20 %
	Timer	0.2 to 100 s	0.5 s
	Enable	OFF ON	OFF
	Fail class	Fail classes	Trip MB

9.2.17 Zero sequence current high (ANSI 50I₀)


Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Zero sequence current high		50I ₀	< 400 ms*

NOTE * The operate time includes the minimum user-defined delay of 100 ms.

Zero sequence currents arise when the phases rotation is positive, but the vector zero value is displaced.

This protection is used for detecting earth faults.

The alarm response is based on the estimated current phasors from the source, as measured by the controller.




AC configuration and protections > Current protections > Zero sequence current > Zero seq. I

Parameter	Text	Range	Default
1570	Set point	0 to 100 %	20 %
	Timer	0.2 to 100 s	0.5 s
	Enable	OFF ON	OFF
	Fail class	Fail classes	Trip MB

9.2.18 Over-frequency (ANSI 81O)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Over-frequency	f>, f>>	81O	< 300 ms

The alarm response is based on the fundamental frequency (based on phase voltage), due to the selection made in parameter 1204.



AC configuration and protections > Frequency protections > Over-frequency > ES f> [1 to 3]

Parameter	Text	Range	ES f> 1	ES f> 2	ES f> 3
1210, 1220 or 1230	Set point	100 to 120 %	103 %	105 %	105 %
	Timer	0.2 to 100 s	10 s	5 s	5 s
	Enable	OFF ON	OFF	OFF	OFF
	Fail class	Fail classes	Warning	Warning	Warning


AC configuration and protections > Frequency protections > Frequency detection type

Parameter	Text	Range	Default
1204	Type	L1 L2 L3 L1 or L2 or L3 L1 and L2 and L3	L1 or L2 or L3

9.2.19 Under-frequency (ANSI 81U)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Under-frequency	f<, f<<	81U	< 300 ms

The alarm response is based on the highest fundamental frequency (based on phase voltage), from the source. This ensures that the alarm only activates when all of the phase frequencies are below the set point.




Parameter	Text	Range	ES f< 1	ES f< 2	ES f< 3
1240, 1250 or 1260	Set point	80 to 100 %	97 %	95 %	95 %
	Timer	0.2 to 100 s	10 s	5 s	5 s
	Enable	OFF ON	OFF	OFF	OFF
	Fail class	Fail classes	Warning	Warning	Warning

9.2.20 Overload (ANSI 32F)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Overload	P>, P>>	32F	< 200 ms

The alarm response is based on the active power (all phases), from the source, as measured by the controller.




Parameter	Text	Range	P> 1	P> 2	P> 3	P> 4	P> 5
1450, 1460, 1470, 1480 or 1490	Set point	-200 to 200 %	100 %	110 %	100 %	110 %	100 %
	Timer	0.1 to 3200 s	10 s	5 s	10 s	5 s	10 s
	Enable	OFF ON	OFF	OFF	OFF	OFF	OFF
	Fail class	Fail classes	Warning	Trip ESB	Trip ESB	Trip ESB	Trip ESB

9.2.21 Reverse power (ANSI 32R)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Reverse power	P<, P<<	32R	< 200 ms

The alarm response is based on the active power (all phases), to the source, as measured by the controller.




Parameter	Text	Range	-P> 1	-P> 2	-P > 3
1000, 1010 or 1070	Set point	-200 to 0 %	-5 %	-5 %	-5 %
	Timer	0.1 to 100 s	10 s	10 s	10 s
	Enable	OFF ON	ON	ON	OFF
	Fail class	Fail classes	Trip ESB	Trip ESB	Trip ESB

9.2.22 Over-excitation or reactive power export (ANSI 400)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Over-excitation or reactive power export	Q>, Q>>	400	< 200 ms

The alarm response is based on the reactive power (Q) from the source, as measured and calculated by the controller. Reactive power export is when the ESS is feeding an inductive load.




Parameter	Text	Range	Default
1530	Set point	0 to 100 %	60 %
	Timer	0.1 to 100 s	10 s
	Enable	OFF ON	OFF
	Fail class	Fail classes	Warning

9.2.23 Under-excitation or reactive power import (ANSI 40U)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Under-excitation or reactive power import	Q<, Q<<	40U	< 200 ms

The alarm response is based on the reactive power (Q) to the source, as measured and calculated by the controller. Reactive power import is when the ESS is feeding a capacitive load.



Parameter	Text	Range	Default
1520	Set point	0 to 150 %	50 %
	Timer	0.1 to 100 s	10 s
	Enable	OFF ON	OFF
	Fail class	Fail classes	Warning

9.3 Busbar standard protections


Protection	IEC symbol (IEC 60617)	ANSI (IEEE C37.2)	Operate time	Alarms
Over-voltage	U>, U>>	59	< 50 ms	3
Under-voltage	U<, U<<	27	< 50 ms	4
Voltage unbalance	UUB>	47	< 200 ms*	1
Positive sequence under-voltage	U ₁ <	27D	< 40 ms	1
Over-frequency	f>, f>>	81O	< 50 ms	3
Under-frequency	f<, f<<	81U	< 50 ms	4
Vector shift	dφ/dt	78	< 40 ms	1
Rate of change of frequency ROCOF (df/dt)	(df/dt)	81R	< 120 ms	1

NOTE * The operate time includes the minimum user-defined delay of 100 ms.

9.3.1 Busbar over-voltage (ANSI 59)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Over-voltage	U>, U>>	59	< 50 ms

The alarm response is based on the highest phase-to-phase voltage, or the highest phase-to-neutral voltage, from the busbar, as measured by the controller.



Busbar > Voltage protections > Over-voltage > BB U> [1 to 3]


Parameter	Text	Range	BB U> 1	BB U> 2	BB U> 3
1270, 1280 or 1290	Set point	100 to 120 %	103 %	105 %	105 %
	Timer	0.04 to 99.99 s	10 s	5 s	5 s
	Enable	OFF ON	OFF	OFF	OFF
	Fail class	Fail classes	Warning	Warning	Warning

Parameter	Text	Range	Default
1202	BB U detect. type	Phase-Phase Phase-Neutral	Phase-Phase

9.3.2 Busbar under-voltage (ANSI 27)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Under-voltage	U<, U<<	27	< 50 ms

The alarm response is based on the lowest phase-to-phase voltage, or the lowest phase-to-neutral voltage, from the busbar, as measured by the controller.



Parameter	Text	Range	BB U< 1	BB U< 2	BB U< 3	BB U< 4
1300, 1310, 1320 or 1330	Set point	40 to 100 %	97 %	95 %	97 %	95 %
	Timer	0.04 to 99.99 s	10 s	5 s	10 s	5 s
	Enable	OFF ON	OFF	OFF	OFF	OFF
	Fail class	Fail classes	Warning	Warning	Warning	Warning

Parameter	Text	Range	Default
1202	BB U detect. type	Phase-Phase Phase-Neutral	Phase-Phase


9.3.3 Busbar voltage unbalance (ANSI 47)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Voltage unbalance (voltage asymmetry)	UUB>	47	< 200 ms*

NOTE * The operate time includes the minimum user-defined delay of 100 ms.

The alarm response is based on the highest difference between any of the three busbar phase-to-phase voltage or phase-to-neutral true RMS values and the average voltage, as measured by the controller. The phase-to-phase voltage is the default.

If phase-to-phase voltages are used, the controller calculates the average phase-to-phase voltage. The controller then calculates the difference between each phase-to-phase voltage and the average voltage. Finally, the controller divides the maximum difference by the average voltage to get the voltage unbalance. See the example.



Parameter	Text	Range	Default
1620	Set point	0 to 50 %	6 %
	Timer	0.1 to 100 s	10 s
	Enable	OFF ON	OFF
	Fail class	Fail classes	Warning



Busbar voltage unbalance example

The busbar has a nominal voltage of 230 V. The L1-L2 voltage is 235 V, the L2-L3 voltage is 225 V, and the L3-L1 voltage is 210 V.

The average voltage is 223.3 V. The difference between the phase-to-phase voltage and the average is 12.7 V for L1-L2, 2.7 V for L2-L3 and 13.3 V for L3-L1.

The busbar voltage unbalance is $13.3 \text{ V} / 223.3 \text{ V} = 0.06 = 6 \%$

9.3.4 Positive sequence under-voltage (ANSI 27d)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Positive sequence under-voltage	$U_2 <$	27d	< 40 ms

As a result of the generator's power production to the consumers, the positive sequence system represents the fault-free part of the voltages.


The controller measures the voltage state on the positive sequence voltage part of the voltage phasors of the busbar or mains. The alarm response is based on the lowest positive voltage value measured at the zero crossing point of each phase.

Parameter	Text	Range	Default
1441	Set point	10 to 110 %	70 %
1442	Timer	1 to 9 Periods	2 Periods
1445	Enable	OFF ON	OFF
1446	Fail class	Fail classes	Trip MB

9.3.5 Busbar over-frequency (ANSI 81O)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Over-frequency	$f >, f >>$	81O	< 50 ms

The alarm response is based on the lowest fundamental frequency (based on phase voltage), from the busbar. This ensures that the alarm only activates when all of the phase frequencies are above the set point.



Busbar > Frequency protections > Over-frequency > BB f> [1 to 4]


Parameter	Text	Range	BB f> 1	BB f> 2	BB f> 3	BB f> 4
1350, 1360, 1370 or 1920	Set point	100 to 120 %	103 %	105 %	105 %	102 %
	Timer	0.04 to 99.99 s	10 s	5 s	5 s	5600 s*
	Enable	OFF ON	OFF	OFF	OFF	OFF
	Fail class	Fail classes	Warning	Warning	Warning	Warning

NOTE * The range for this alarm is 1500 to 6000 s.

9.3.6 Busbar under-frequency (ANSI 81U)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Under-frequency	f<, f<<	81U	< 50 ms

The alarm response is based on the highest fundamental frequency (based on phase voltage), from the busbar. This ensures that the alarm only activates when all of the phase frequencies are below the set point.



Busbar > Frequency protections > Under-frequency > BB f< [1 to 5]

Parameter	Text	Range	BB f< 1	BB f< 2	BB f< 3	BB f< 4	BB f< 5
1380, 1390, 1400, 1410 or 1930	Set point	80 to 100 %	97 %	95 %	97 %	95 %	95 %
	Timer	0.04 to 99.99 s	10 s	5 s	10 s	5 s	5600 s*
	Enable	OFF ON	OFF	OFF	OFF	OFF	OFF
	Fail class	Fail classes	Warning	Warning	Warning	Warning	Warning

NOTE * The range for this alarm is 1500 to 6000 s.

9.3.7 Vector shift (ANSI 78)

Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
Vector shift	dφ/dt	78	< 40 ms


Vector shifts can arise when a mains failure occurs while a generator is running parallel with the mains.

Vector shifts can occur because the stator magnetic field lags behind the rotor magnetic field. When a mains failure occurs, the phase angle between the stator and rotor magnetic fields changes. This change in the phase angle, is also known as a vector shift.


The alarm response is based on the change in the phase angle that occurred due to the mains failure. The alarm response can be based on the change in an individual phase, or on the change in all the phases.

In grids where fast automatic reconnection attempts are expected, this protection opens the breaker to prevent damaging failures. Fast changes in frequency can also activate this alarm. Too sensitive configuration can lead to too many unwanted detections of vector shift.


Vector shift in phase L1 only



Vector shift causes the instantaneous phase angle change ($\Delta\phi$)



Vector shift in all phases



Busbar > Additional protections > Vector shift

Parameter	Text	Range	Default
1431	Set point	1 to 90 °	10 °
1434	Enable	OFF ON	OFF
1435	Fail class	Fail classes	Trip MB
1436	Type	Individual phases All phases	All phases

9.3.8 Rate of change of frequency (ANSI 81R)


Protection	IEC symbol (IEC60617)	ANSI (IEEE C37.2)	Operate time
ROCOF (df/dt)	df/dt	ANSI 81R	Standard: < 120 ms

When a mains failure occurs, the measured frequency might change within a short period of time, if the generators are either instantly overloaded or instantly deloaded.

If the generator overloads instantly, it slows down, and the generator frequency might decrease shortly. Similarly, if the generator deloads instantly, it speeds up, and the generator frequency might increase shortly.

The alarm response is based on the rate of change of the measured frequency, within a specified time period.

In grids where fast automatic reconnection attempts are expected, this protection opens the breaker to prevent damaging failures.



Busbar > Additional protections > df/dt (ROCOF)

Parameter	Text	Range	Default
1421	Set point	0.200 to 10.000 Hz/s	5.000 Hz/s
1422	Periods	3 to 20 Periods	6 Periods
1423	Timer	0.00 to 3.00 s	0.00 s
1426	Enable	OFF ON	OFF
1427	Fail class	Fail classes	Trip MB

10. General purpose PID

10.1 Introduction

The general purpose PID controllers are principally similar to the PID controllers for regulation. They consist of a proportional, an integral and a differential part, and the integral and differential parts are dependent on the proportional gain.

The general purpose PIDs are slightly less responsive. They are meant to control temperature, fans and so on. Configuration of the general purpose PIDs is documented by describing the possibilities of the general purpose PID interface, and with examples of configuration for different purposes.


10.1.1 General purpose PID controllers in the battery/storage controller

You can use the general purpose PID controller to supplement the default battery/storage controller. You can control several set points, including these:

- Reference 1 (power reference sent to the ESS)
- ESS actual frequency
- ESS voltage
- ESS active power
- ESS reactive power
- Busbar frequency
- Busbar voltage
- ESS frequency reference
- ESS voltage reference
- ESS active power ramped reference
- ESS reactive power ramped reference
- ESS nominal voltage
- BB nominal voltage

10.1.2 General purpose PID analogue loop

The analogue regulation in the general purpose PIDs is handled by a PID loop. The diagram below shows which elements the PID loop consists of.



1. **Input:** This is the analogue input that measures the process the controller is trying to regulate.
2. **Reference:** This is the set point that the controller is trying to bring the input to match.
3. **Kp:** The proportional gain of the PID loop.
4. **Ti:** The integral gain of the PID loop.
5. **Td:** The derivative gain of the PID loop.

6. **Inverse:** Enabling inverse will give the output a negative sign.
7. **Offset:** The offset is added on the function and displaces the regulation range.
8. **Output:** This is the final output from the PID, controlling the transducer.

10.1.3 General purpose PID interface in the utility software

Configure the four general purpose PID’s input and output settings using the PID interface in the utility software. This cannot be done from the controller.

Monitoring

Device
Application supervision
Alarms
Logs
Inputs/Outputs
Trending

Configuration

Application configuration
Parameters
Advanced Protection
ECU & D-AVR configuration
I/O & Hardware setup
External I/O (CIO)
3rd Party Integration

Tools

Ethernet setting (TCP/IP)
M-Logic & AOP
Modbus Configurator
Option & Firmware
Translations
General Purpose PID
Display views
Permissions
Compare offline files

PID1 inp.

PID1 outp.

PID2 inp.

PID2 outp.

PID3 inp.

PID3 outp.

PID4 inp.

PID4 outp.

PID1 Input Configuration

Activation of PID1

Off

Input 1 Configuration

Input 1

Input 20

Input 1 min.

0

%

Input 1 max.

100

%

Setpoint 1

Reference 1

Setpoint 1 min.

0

%

Setpoint 1 max.

100

%

Setpoint 1 offset

0

Reference 1

50

Weight 1

1

Enable 1

Off

Input 2 Configuration

Input 2

Input 21

Input 2 min.

0

%

Input 2 max.

100

%

Setpoint 2

Reference 2

Setpoint 2 min.

0

%

Setpoint 2 max.

100

%

Setpoint 2 offset

0

Reference 2

50

Weight 2

1

Enable 2

Off

10.2 Inputs

Each output can have up to three inputs. Only one input at a time is used for calculation of the output signal.

Explanation of general purpose PID settings

The screenshot displays the 'PID1 Input Configuration' window. It features three tabs: 'PID1 inp.', 'PID1 outp.', and 'PID1 inp.'. The 'PID1 inp.' tab is active, showing the configuration for three inputs. The settings are as follows:

Input	Input Source	Input min.	Input max.	Setpoint	Setpoint min.	Setpoint max.	Setpoint offset	Reference	Weight	Enable
Input 1	EIC Cooling water ti	0	100	Reference 1	0	100	0	50	1	Off
Input 2	Input 21	0	100	Reference 2	0	100	0	50	1	Off
Input 3	Input 22	0	100	Reference 3	0	100	0	50	1	Off

1. **Activation:** Enable the PID, or allow it to be enabled from M-Logic.
2. **Input 1:** Select the source of this input here.
3. **Input 1 min. and Input 1 max.:** Define the scale of the input value evaluated.
4. **Setpoint 1:** Select **Reference 1** to define the set point in this box. Alternatively, select a set point source (from the same options as Input 1).
5. **Setpoint 1 min. and Setpoint 1 max.:** Define the scale of the set point value evaluated.
6. **Setpoint 1 offset:** The offset for set point 1.
7. **Reference 1:** Select the set point for this input. **Reference 1** must be selected for **Setpoint 1**.
8. **Weight 1:** The input value is multiplied by the weight factor.
 - A weight factor of 1 means that the real input value is used in calculations.
 - A weight factor of 3 means that the input value is treated as three times as big in calculations.
9. **Enable:**
 - On: This input will be evaluated.
 - Off: This input will not be evaluated.

10.2.1 Dynamic input selection

Each general purpose PID holds the possibility of up to three active inputs. All activated inputs are evaluated constantly, and the input causing the greatest or smallest output is selected. Priority of great or small output is selected in the output settings.

Example: Dynamic input selection Ventilation of a container fitted with a genset inside is a realistic example for use of the dynamic input selection. The following three variables depend on the ventilation, hence it makes sense to let them share the output.

- The container is fitted with a temperature sensor for internal container temperature. Due to lifetime of electronics inside the container, maximum maintained temperature is desired to be 30 °C. (Input 1).
- The engine air intake is located inside the container, hence turbo compressor inlet temperature depends on the air temperature in the container. Maximum maintained intake air temperature is 32 °C. (Input 2).
- The alternator is cooled by air in the container, hence the alternator winding temperature depends on the air temperature in the container. Maximum maintained winding temperature is 130 °C. (Input 3).

This is the data that is used to configure the inputs in the screenshot in the previous paragraph (Inputs). All inputs are configured with both full range of measurement (0 to 100 %) and a weight factor of 1. The common output to the ventilator speed drive is configured to prioritise maximum output as explained in the next chapter, "Output". This configuration is meant to ensure that none of the input set points are continuously exceeded, unless maximum ventilation is reached.

A scenario of operation could be that the controller has been using input 1, and a temperature of 30 °C is maintained in the container. At a point, the air filter housing is heated by radiation from the engine, causing input 2 to rise more above 32 °C than input 1 is above 30 °C. This means that input 2 now has the greatest positive deviation. All inputs are configured with a weight factor of 1 and maximum output is prioritised, hence the greatest positive deviation results in maximum output, or, to put it in another way, input 2 is now the one selected.

The genset is running at full load with a maximum of reactive load, and the alternator windings heat up beyond the 130 °C set point due to high currents. At some point, input 3 will result in maximum output and hence be selected as the input used in output calculation. Ventilation is increased and the winding temperature may reach a steady state of 130 °C with a container room temperature of 27 °C and a compressor inlet temperature of 30 °C. As long as this is the situation, input 3 will remain the selected input, as this is the input causing the greatest output.

In case of high ambient temperatures, the ventilation might not be able to influence the temperature enough, and the temperatures start to rise above set point. The output will stay at 100 % as long as any of the inputs are continuously above their set points.

Weight factor applies to dynamic input selection as well. In the event that different weight factors have been configured for any of the three inputs, maximum deviation cannot be equated to maximum output. If two inputs with similar deviation to their respective set points are configured with weight factors of 1 and 2 respectively, the latter will result in twice the output as the first.

10.3 Outputs


10.3.1 Explanation of output settings

Explanation of general purpose PID settings

The screenshot displays the 'PID1 Output Configuration' window. At the top, there are tabs for PID1 inp., PID1 outp., PID2 inp., PID2 outp., PID3 inp., PID3 outp., PID4 inp., and PID4 outp. The 'PID1 outp.' tab is selected. The configuration is divided into three sections: 'PID1 Output Configuration', 'Analogue Settings', and 'Relay Settings'. The 'PID1 Output Configuration' section includes 'Priority' (set to 'Maximum output') and 'Output type' (set to 'Analogue'). The 'Analogue Settings' section includes 'Analogue Kp' (0,50), 'Analogue Ti' (60,00 s), 'Analogue Td' (0 s), 'Analogue output' (Disabled), 'Analogue output inverse' (OFF), 'Analogue offset' (50 %), 'M-logic min event setpoint' (5 %), and 'M-logic max event setpoint' (95 %). The 'Relay Settings' section includes 'Relay Db' (2 %), 'Relay Kp' (0.5), 'Relay Td' (0 s), 'Relay min. on-time' (0.5 s), 'Relay period time' (2.5 s), 'Relay increase' (Not used), 'Relay decrease' (Not used), and 'PID1 PQ Offset max' (5 %). The interface uses sliders and dropdown menus for most settings.

Setting	Value	Unit
1. Priority	Maximum output	
2. Output type	Analogue	
3. Analogue Kp	0,50	
4. Analogue Ti	60,00	s
5. Analogue Td	0	s
6. Analogue output	Disabled	
7. Analogue output inverse	OFF	
8. Analogue offset	50	%
9. M-logic min event setpoint	5	%
10. M-logic max event setpoint	95	%
11. Relay Db	2	%
12. Relay Kp	0.5	
13. Relay Td	0	s
14. Relay min. on-time	0.5	s
15. Relay period time	2.5	s
16. Relay increase	Not used	
17. Relay decrease	Not used	
18. PID1 PQ Offset max	5	%

1. **Priority:** This setting determines whether the min. or max. output that is prioritised. This setting is used for the dynamic input selection feature. Maximum output results in selection of the input that gives the greatest output. Minimum output results in selection of the input that gives the smallest output.
2. **Output type:** Choose between relay or analogue output. The following parameters marked "analogue" only apply to the use of analogue regulation, in the same way as parameters marked "relay" only apply to relay regulation.
3. **Analogue Kp:** This is the proportional gain value. Increase this to give a more aggressive reaction. Adjusting this value also affects the integral and derivative output. If Kp needs adjustment without affecting the Ti or Td part, adjust these accordingly.
4. **Analogue Ti:** Increase the Ti for a less aggressive integral action.
5. **Analogue Td:** Increase the Td for a more aggressive derivative action.
6. **Analogue output:** Choose the physical internal or external output.
7. **Analogue output inverse:** Enable this to invert the output function.




Direct error = SP - PV

Direct output is used in applications where a rise in analogue output increases the process variable.

Inverse error = PV - SP

Inverse output is used in applications where a rise in analogue output decreases the process variable.

Example explaining direct and indirect regulation




Typically, heating applications use direct output and cooling applications use inverse output. Imagine a container of water, which must be kept at a set point of 20 °C at all times. The container can be exposed to temperatures between 0 and 40 °C, hence it is fitted with both a heating coil and a cooling coil. See the diagrams that show this below.

For this application, two controllers must be configured: one with direct output for the heating pump and one with inverse output for the cooling pump. To achieve the inverse output shown, an offset of 100 % is needed. See **Analogue offset** below for more information.

Temperatures below 20 °C then result in a positive output for the heating pump, in the same way as temperatures above 20 °C result in a positive output for the cooling pump, and the temperature is maintained around the set point.

8. **Analogue offset:** Determines the output starting point. The full range of output can be seen as values in the range between 0 and 100 %. The offset displaces this range. 50 % offset centres the range of output at the set point. 0 and 100 % offset result in having the full range of output above or below the set point. See below for how the output behaves according to the input and with different offsets.




100 % offset is commonly used with inverse output, like in the previous cooling example.

9. **M-Logic min event set point:** The controller activates *Events > General Purpose PID > PID#* at min output in M-Logic.
10. **M-Logic max event set point:** The controller activates *Events > General Purpose PID > PID#* at max output in M-Logic.
11. **Relay Db:** Deadband setting for relay control.
12. **Relay Kp:** Proportional gain value for relay control.
13. **Relay Td:** Derivative output for relay control.
14. **Relay min on-time:** Minimum output time for relay control. Set this to the minimum time that is able to activate the controlled actuator.
15. **Relay period time:** Total time for a relay activation period. When the regulation output is above this period time, the relay output is constantly activated.
16. **Relay increase:** Choose the terminal for the relay used for positive activation.
17. **Relay decrease:** Choose the terminal for the relay used for negative activation.
18. **PID PQ Offset max:** The maximum offset for a power or active power output.

10.3.2 Additional analogue outputs with IOM 230


The controller includes two built-in analogue outputs. The controller also supports up to two IOM 230 analogue interface modules, which can provide four additional analogue outputs.

IOM 230 overview



1. IOM 230 status LED (green = system OK, red = system failure)
2. Terminals 1 to 6
3. GOV adjustment
4. GOV output selector
5. AVR adjustment
6. AVR output selector
7. Terminal 7 to 14
8. CAN status LED (green = system OK, red = system failure)
9. PC port
10. IOM 230 CAN ID selector

GOV and AVR output selector settings


	Output	Switch 1	Switch 2	Switch 3	Switch 4
	+/-25 mA	ON	OFF	Not used	OFF
	0 to 20 mA	OFF	ON		OFF
	+/-12 V DC	ON	OFF		ON
	0 to 10 V DC	OFF	ON		ON

NOTE Switch 1 and 2 cannot have the same position.

IOM 230 Terminals

	Terminal	Description	Comment
	1	+12/24V DC	Power supply
	2	0V DC	
	3	Not used	-
	4	CAN-H	CAN bus interface
	5	CAN-GND	
	6	CAN-L	
	7	GOV out	Governor analogue interface
	8	GOV com	
	9	AVR out	AVR analogue interface
	10	AVR com	
	11	Not used	-
	12	VAr share out	Load sharing lines
	13	Common	
	14	P share out	


CAN bus connections



The cable shield must not be connected to ground, only to the GND terminals.

Use different CAN addresses for the different IDs. Only ID0 participate in the load share functionality.

IOM 230 CAN ID selector settings

	IOM ID	Switch 1	Switch 2	Switch 3	Switch 4
	ID0	OFF	OFF	OFF	OFF
	ID1*	ON	OFF	OFF	OFF
	ID2*	OFF	ON	OFF	OFF

All other combinations = ID0.

NOTE * ID1 is used for PID1 and PID2. ID2 is used for PID3 and PID4.

10.4 M-Logic

All functions of the general purpose PIDs can be activated and deactivated using M-Logic. In the following, events and commands regarding the general purpose PIDs are described.

M-Logic > Events > General Purpose PID

Events

- **PID[1-6] active:** This event is active when the related PID is activated.
- **PID[1-6] at min output:** This event is active when the output is below the output parameter M-Logic min event set point.
- **PID[1-6] at max output:** This event is active when the output is above the output parameter M-Logic max event set point.
- **PID[1-6] output frozen:** This event is active when the output is frozen.
- **PID[1-6] using input [1-3]:** This event is active when dynamic input selection for PID[1-6] has selected input [1-3] for output calculation.
- **PID[1-6] Modbus control:** This event is active when remote Modbus control of this PID is requested.

M-Logic > Output > General Purpose PID commands

Commands

- **PID[1-6] Manual reg ON:** This command activates manual regulation.
- **PID[1-6] Activate:** This command activates the PID controller.
- **PID[1-6] force min. outp. :** This command forces the output to the value set in the output parameter *M-logic min event setpoint*.
- **PID[1-6] force max. outp.** This command forces the output to the value set in the output parameter *M-logic max event setpoint* (for example, for post-cooling purposes).
- **PID[1-6] reset:** This command forces the output to the value set in the output parameter Analogue offset.
- **PID[1-6] freeze output:** This command freezes the output at the current value.
- **PID[1-6] activate input [1-3]:** This command activates input [1-3] for PID[1-6].
- **PID[1-6] deactivate input [1-3]:** This command deactivates input [1-3] for PID[1-6].

10.5 Using general purpose PIDs for ESS regulation

You can use the general purpose PIDs (GPPIDs) to regulate the ESS set points for voltage and frequency, or for the power and reactive power. This may be necessary if the measurements at the ESS are different from the rest of the system due to internal isolation transformers and/or long power cables. Using the GPPIDs allows the ESS response to match the actual measurements.

If the ESS is the only power source on the busbar, the controller regulates the voltage and frequency from the ESS. If there are other power sources, the controller must regulate the ESS power and reactive power. There are separate GPPIDs for each regulated value.

Using M-Logic to detect other power sources on the busbar

You can use M-Logic to detect the operating configuration and set a virtual event. You can then use the virtual event to activate and deactivate the relevant GPPID.

The following M-Logic detects whether there are any other sources on the busbar. If there are other sources on the busbar, the controller activates a virtual event.

Logic 1

Activate virtual event 1 if there are any other sources on the busbar

Event A

☐ Any Gen on hybrid bus

Event B

☐ Any MAINS on hybrid t

Event C

☐ Any other BATTERY on

Operator

OR

OR

OR

Delay (sec.)

0

Output

Virtual event set 1: Virtu

Enable this rule

☒

OR

Logic 1	Operator	Category	Name
Event A	OR	Events	Any Gen on hybrid busbar
Event B	OR	Events	Any MAINS on hybrid busbar
Event C	OR	Events	Any other BATTERY on hybrid busbar
Output		Virtual event set	Virtual event set 1

10.5.1 Voltage regulation

The PID can use the difference between the actual voltage from the ESS and the ESS reference voltage as inputs. The PID controller output is a voltage reference offset. This offset is added to the voltage reference that the controller sends to the ESS.

Example of general purpose PID settings for voltage regulation

PID4 Input Configuration

Activation of PID4

M-Logic

Input 1 Configuration

Input 1

ESS actual L-L volt.

Input 1 min.

0

%

Input 1 max.

100

%

Setpoint 1

ESS voltage ref.

Setpoint 1 min.

0

%

Setpoint 1 max.

100

%

Setpoint 1 offset

0

Reference 1

50

Weight 1

1

Enable 1

On

PID4 Output Configuration

Priority

Maximum output

Output type

Voltage ref. offset

Analogue/Internal offset Settings

Analogue Kp

6

Analogue Ti

0,25

s

Analogue Td

0

s

Analogue output

Analogue output inverse

OFF

Analogue offset

50

%

M-logic min event setpoint

5

%


M-logic max event setpoint

95

%

M-Logic to activate and reset PID4

You can use M-Logic to detect when to activate PID4. You can also use M-Logic to automatically reset PID4 when PID4 is not active.



Logic 2	Operator	Category	Name
Event A	AND	Events - Battery	Droop mode active
Event B	Not, AND	Virtual event output	Virtual event output 1
Output		General Purpose PID commands	PID4 Activate

Logic 3	Operator	Category	Name
Event A	Not	General Purpose PID	PID4 Active
Output		General Purpose PID commands	PID4 reset

10.5.2 Frequency regulation

The PID can use the difference between the actual frequency from the ESS and the ESS reference frequency as inputs. The PID controller output is a frequency reference offset. This offset is added to the frequency reference that the controller sends to the ESS.

Example of general purpose PID settings for frequency regulation

PID3 Input Configuration

Activation of PID3

M-Logic

Input 1 Configuration

Input 1

ESS actual freq.

Input 1 min.

0

%

Input 1 max.

100

%

Setpoint 1

ESS frequency ref.

Setpoint 1 min.

0

%

Setpoint 1 max.

100

%

Setpoint 1 offset

0

%

Reference 1

50

%

Weight 1

1

%

Enable 1

On

PID3 Output Configuration

Priority

Maximum output

Output type

Frequency ref. offs

Analogue/Internal offset Settings

Analogue Kp

6

Analogue TI

0,25

s

Analogue Td

0

s

Analogue output

Analogue output inverse

OFF

Analogue offset

50

%

M-logic min event setpoint

5

%


M-logic max event setpoint

95

%

M-Logic to activate and reset PID3

You can use M-Logic to detect when to activate PID3. You can also use M-Logic to automatically reset PID3 when PID3 is not active.



Logic 4	Operator	Category	Name
Event A	AND	Events - Battery	Droop mode active
Event B	Not, AND	Virtual event output	Virtual event output 1
Output		General Purpose PID commands	PID3 Activate

Logic 5	Operator	Category	Name
Event A	Not	General Purpose PID	PID3 Active
Output		General Purpose PID commands	PID3 reset

10.5.3 Reactive power regulation

The PID can use the difference between the actual reactive power from the ESS and the ESS reference reactive power as inputs. The PID controller output is a reactive power reference offset. This offset is added to the reactive power reference that the controller sends to the ESS.

Example of general purpose PID settings for reactive power regulation

PID2 Input Configuration

Activation of PID2:

Input 1 Configuration

Input 1:

Input 1 min.: %

Input 1 max.: %

Setpoint 1:

Setpoint 1 min.: %

Setpoint 1 max.: %

Setpoint 1 offset:

Reference 1:

Weight 1:

Enable 1:

PID2 Output Configuration

Priority:

Output type:

Analogue/Internal offset Settings

Analogue Kp:

Analogue Ti: s

Analogue Td: s

Analogue output:

Analogue output inverse:


Analogue offset: %

M-logic min event setpoint: %

M-logic max event setpoint: %

M-Logic to activate and reset PID2

You can use M-Logic to detect when to activate PID2. You can also use M-Logic to automatically reset PID2 when PID2 is not active.



Logic 6	Operator	Category	Name
Event A	AND	Events - Battery	Droop mode active
Event B	AND	Virtual event output	Virtual event output 1
Output		General Purpose PID commands	PID2 Activate

Logic 7	Operator	Category	Name
Event A	Not	General Purpose PID	PID2 Active
Output		General Purpose PID commands	PID2 reset

10.5.4 Power regulation

The PID can use the difference between the actual power from the ESS and the ESS reference power as inputs. The PID controller output is an active power reference offset. This offset is added to the power reference that the controller sends to the ESS.

Example of general purpose PID settings for power regulation

PID1 Input Configuration

Activation of PID1

M-Logic

Input 1 Configuration

Input 1

ESS actual P pct.

Input 1 min.

0

%

Input 1 max.

100

%

Setpoint 1

ESS P ramped ref. p

Setpoint 1 min.

0

%

Setpoint 1 max.

100

%

Setpoint 1 offset

0

%

Reference 1

50

%

Weight 1

1

%

Enable 1

On

PID1 Output Configuration

Priority

Maximum output

Output type

Active power ref. of

Analogue/Internal offset Settings

Analogue Kp

0,01

s

Analogue Ti

0,25

s

Analogue Td

0

s

Analogue output

Analogue output inverse

OFF

Analogue offset

50

%

M-logic min event setpoint

5

%


M-logic max event setpoint

95

%

M-Logic to activate and reset PID1

You can use M-Logic to detect when to activate PID1. You can also use M-Logic to automatically reset PID1 when PID1 is not active.



Logic 7	Operator	Category	Name
Event A	Not	General Purpose PID	PID1 Active
Output		General Purpose PID commands	PID1 reset

11. Inputs and outputs

11.1 Digital inputs

11.1.1 Standard digital inputs

The controller has as standard 12 digital inputs, located on the terminals 39 to 50. All inputs are configurable.

Digital inputs

Input	Text	Function	Technical data
39	In	Configurable	Negative switching only, < 100 Ω
40	In	Configurable	Negative switching only, < 100 Ω
41	In	Configurable	Negative switching only, < 100 Ω
42	In	Configurable	Negative switching only, < 100 Ω
43	In	Configurable	Negative switching only, < 100 Ω
44	In	Configurable	Negative switching only, < 100 Ω
45	In	Configurable	Negative switching only, < 100 Ω
46	In	Configurable	Negative switching only, < 100 Ω
47	MB position on*	Configurable (application dependent)	Negative switching only, < 100 Ω
48	MB position off*	Configurable (application dependent)	Negative switching only, < 100 Ω
49	ESB position on	Configurable (application dependent)	Negative switching only, < 100 Ω
50	ESB position off	Configurable (application dependent)	Negative switching only, < 100 Ω

NOTE * For a single controller application with a mains breaker.

11.1.2 Configuring digital inputs

The digital inputs can be configured from the controller or with the utility software (some parameters can only be accessed with the utility software).

NOTE The configuration of digital inputs 39 to 50 has been moved from parameters 3001 to 3116 to *I/O & Hardware setup*.

Configure a digital input with the utility software

In the utility software, in *I/O & Hardware setup*, select the digital input to configure.

The screenshot shows the configuration interface for digital input 39. The top bar lists various system parameters. The main configuration area includes the following settings:

- Preconfigured function: Access lock (1)
- Alarm: Enable (2)
- Alarm when input is: High (3)
- Timer: 10 s (4)
- Fail class: Warning (5)
- Output A: Not used (6)
- Output B: Not used (7)
- Auto acknowledge: OFF (8)
- Inhibits: Inhibits... (9)
- Password: Service (10)
- Modbus address: 185

No.	Text	Description
1	Preconfigured function	Select a function for the digital input.
2	Alarm	Enable the alarm function.
3	Alarm when input is	The alarm is activated when the input is high or low.
4	Timer	The timer setting is the time from the alarm level is reached until the alarm occurs.

No.	Text	Description
5	Fail class	Select the required fail class from the list. When the alarm occurs, the controller reacts according to the selected fail class.
6	Output A	Select the terminal (or <i>Limits</i>) to be activated by an alarm. Limits make the alarm usable as an input event in M-Logic.
7	Output B	Select the terminal (or <i>Limits</i>) to be activated by an alarm. Limits make the alarm usable as an input event in M-Logic.
8	Auto acknowledge	ON: The alarm is automatically acknowledged when the alarm conditions are no longer met.
9	Inhibits	Select the exceptions to when the alarm must be activated.
10	Password level	Select the password level that is needed to modify this parameter.

Select *Write to device*  to write the settings to the controller.

11.2 DC relay outputs

The controller has 12 x DC relay outputs as standard. The outputs are divided in two groups with different electrical characteristics.

All outputs are configurable, unless other stated.

Relay outputs, group 1

Electrical characteristics

- Voltage: 0 to 36 V DC
- Current: 15 A DC inrush, 3 A DC continuous

Relay	Default setting
Relay 05	No default
Relay 06	No default

Relay outputs, group 2

Electrical characteristics

- Voltage: 4.5 to 36 V DC
- Current: 2 A DC inrush, 0.5 A DC continuous

Relay	Default setting
Relay 09	No default
Relay 10	No default
Relay 11	Status OK
Relay 12	No default
Relay 13	No default
Relay 14	No default
Relay 15	MB ON relay*
Relay 16	MB OFF relay*
Relay 17	ESB ON relay**
Relay 18	ESB OFF relay**

NOTE * For a single controller application with a mains breaker. If there is no breaker, these outputs are configurable.
NOTE ** If there is no breaker, these outputs are configurable.

11.2.1 Configure a relay output

Use the utility software, under *I/O setup, DO 5 - 18* to configure the relay outputs.

	<u>Function</u>	<u>Alarm</u>		
	Output Function	Alarm function	Delay	Password
Output 5	Run coil	M-Logic / Limit relay	0	Service

Setting	Description
Output function	Select an output function.
Alarm function	Alarm relay NE M-Logic / Limit relay Alarm relay ND
Delay	The alarm timer.
Password	Select the password level to modify this configuration (cannot be edited by a user with lower privileges).

11.3 Analogue inputs

11.3.1 Introduction

The controller has four analogue inputs (also known as multi-inputs): Multi-input 20, multi-input 21, multi-input 22, and multi-input 23. Terminal 19 is the common ground for the multi-inputs.

The multi-inputs can be configured as:

- 4-20 mA
- 0-10 V DC
- Pt100
- RMI oil pressure
- RMI water temperature
- RMI fuel level
- RMI Custom
- Binary/digital input

The function of the multi-inputs can only be configured with the utility software.

Wiring

The wiring depends on the measurement type (current, voltage, or resistance).



More information

See **Wiring** in the **Installation instructions** for examples of wiring.

11.3.2 Application description

The multi-inputs can be used in different applications. For example:

- Power transducer. If you want to measure the power from another power source, a power transducer sending a 4-20 mA signal could be connected to multi-input 20.
- Temperature sensor. Pt100 resistors are often used to measure temperature. In the utility software, you can choose whether the temperature should be shown as Celsius or Fahrenheit.

- RMI inputs. The controller has three RMI types; oil, water and fuel. It is possible to choose different types within each RMI type. There is also a configurable type. For more information, see the **AGC 150 Genset Mains BTB Designer's handbook**.
- An extra button. If the input is configured as digital, it works like an extra digital input.
- Differential measurement can be used to activate an alarm when two values are too far apart.

11.3.3 Configuring multi-inputs

Configure each multi-input to match the connected sensor.

1. In the utility software, select *I/O & Hardware setup*, then select *MI 20 / 21 / 22 / 23*.

DI 39-40-41
DI 42-43-44
DI 45-46-47
DI 48-49-50
MI 20
MI 21
MI 22
MI 23
DO 5 - 18
DC meas AVG
AC meas AVG
E

Multi input 20

1st alarm: Parameter: 4120, Modbus address: 268
2nd alarm: Parameter: 4130, Modbus address: 269
Wire break: Parameter: 4140, Modbus address: 264

Input type

4-20mA

Scaling

V 1/10

Engineering Unit

Bar/celsius

Last open file name

-

Selected curve

Configurable curve

Open

Save

	Input (mA)	Output
Set point 1	0	0
Set point 2	0	0
Set point 3	0	0
Set point 4	0	0
Set point 5	0	0
Set point 6	0	0
Set point 7	0	0
Set point 8	0	0
Set point 9	0	0
Set point 10	0	0
Set point 11	0	0
Set point 12	0	0
Set point 13	0	0
Set point 14	0	0
Set point 15	0	0
Set point 16	0	0
Set point 17	0	0

1st Alarm

Disable

Alarm when input is

High

Set point

5

Delay

10

Sec.

Fail class

Warning

Output A

Not used

Output B

Not used

Auto acknowledge

OFF

Inhibits

Inhibits...

2nd Alarm

Disable

Alarm when input is

High

Set point

5

Delay

10

Sec.

Fail class

Warning

Output A

Not used

Output B

Not used

Auto acknowledge

OFF

Inhibits

Inhibits...

Wire break detection

Disable

Wire break fail class

Warning

Output A

Not used

Output B

Not used

Delay

1

Sec.

Auto acknowledge

OFF

Inhibits

Inhibits...

2. Select the appropriate *Scaling*.

Designer's handbook 4189341323D EN

Page 206 of 219

Examples

DI 39-40-41
DI 42-43-44
DI 45-46-47
DI 48-49-50
MI 20

Multi input 20
1st alarm: Parameter: 4120. Modbus address: 268
2nd alarm: Parameter: 4130. Modbus address: 269
Wire break: Parameter: 4140. Modbus address: 264

Input type: 4-20mA
Scaling: Perc 1/10

Selected curve

Configurable curve **Open** **Save**

	Input (mA)	Output
Set point 1	4	2
Set point 2	20	5,6
Set point 3	20	5,6
Set point 4	20	5,6

Scaling 1/10

DI 39-40-41
DI 42-43-44
DI 45-46-47
DI 48-49-50
MI 20

Multi input 20
1st alarm: Parameter: 4120. Modbus address: 268
2nd alarm: Parameter: 4130. Modbus address: 269
Wire break: Parameter: 4140. Modbus address: 264

Input type: 4-20mA
Scaling: Perc 1/100

Selected curve

Configurable curve **Open** **Save**

	Input (mA)	Output
Set point 1	4	0,2
Set point 2	20	0,56
Set point 3	20	0,56
Set point 4	20	0,56

Scaling 1/100

11.3.4 Alarms

For each multi-input, two alarm levels are available. With two alarms it is possible to have the first alarm reacting slow, while the second alarm can react faster. For example, if the sensor measures generator current as protection against overload, a small overload is acceptable for a shorter period, but in case of a large overload, the alarm should activate quickly.

Use the utility software to configure the multi-input alarms. Select *I/O & Hardware setup*, then select *MI 20 / 21 / 22 / 23*.

DI 39-40-41 | DI 42-43-44 | DI 45-46-47 | DI 48-49-50 | **MI 20** | MI 21 | MI 22 | MI 23 | DO 5 - 18 | DC meas AVG | AC meas AVG | E

Multi input 20

1st alarm: Parameter: 4120, Modbus address: 268
2nd alarm: Parameter: 4130, Modbus address: 269
Wire break: Parameter: 4140, Modbus address: 264

Input type: 4-20mA
Scaling: Perc 1/10

Engineering Unit: Bar/celsius
Last open file name: -

Selected curve

Configurable curve **Open** **Save**

	Input (mA)	Output
Set point 1	4	2
Set point 2	20	5,6
Set point 3	20	5,6
Set point 4	20	5,6
Set point 5	20	5,6
Set point 6	20	5,6
Set point 7	20	5,6
Set point 8	20	5,6
Set point 9	20	5,6
Set point 10	20	5,6
Set point 11	20	5,6
Set point 12	20	5,6
Set point 13	20	5,6
Set point 14	20	5,6
Set point 15	20	5,6
Set point 16	20	5,6
Set point 17	20	5,6

1st Alarm

Enable: Enable
Alarm when input is: High
Set point: 5,2
Delay: 1 Sec.
Fail class: Warning
Output A: Not used
Output B: Not used
Auto acknowledge: OFF
Inhibits: Inhibits...

2nd Alarm

Enable: Enable
Alarm when input is: High
Set point: 5
Delay: 10 Sec.
Fail class: Warning
Output A: Not used
Output B: Not used
Auto acknowledge: OFF
Inhibits: Inhibits...

Wire break detection

Wire break fail class: Warning
Output A: Not used
Output B: Not used
Delay: 1 Sec.
Auto acknowledge: OFF
Inhibits: Inhibits...

1. Select the desired multi-input tab.
2. Configure the parameters for 1st alarm.
3. Configure the parameters for 2nd alarm.

Sensors with max. output less than 20 mA

If a sensor has a maximum output less than 20 mA, it is necessary to calculate what a 20 mA signal would indicate.

Example: A pressure sensor gives 4 mA at 0 bars and 12 mA at 5 bar.

- $(12 - 4) \text{ mA} = 8 \text{ mA} = 5 \text{ bar}$
- $1 \text{ mA} = 5 \text{ bar} / 8 = 0.625 \text{ bar}$
- $20 - 4 \text{ mA} = 16 \times 0.625 \text{ bar} = 10 \text{ bar}$


Configuring multi-input alarms from the display

Alternatively, you can use the display to configure the multi-input alarms: I/O settings > Inputs > Multi input > Multi input [20 to 23].1 / 2

11.3.5 DC measurement averaging

You can use the utility software to set up averaging for the DC measurements (Multi input 20 to 23). The averaged values are then shown on the display unit and in the Modbus values. However, the controller continues to use real-time measurements.

In the utility software, under *I/O & Hardware setup*, select the *DC meas AVG* tab. For each measurement, you can select OFF, or averages calculated over 100 ms to 10 s.




11.3.6 Wire break

To supervise the sensors/wires connected to the multi-inputs and analogue inputs, you can enable the wire break function for each input. If the measured value on the input is outside the normal dynamic area of the input, it is detected as a short circuit or a break. An alarm with a configurable fail class is activated.

Input	Wire failure area	Normal range	Wire failure area
4-20 mA	<3 mA	4-20 mA	>21 mA
0-10 V DC	≤0 V DC	-	N/A
RMI Oil, type 1	<10.0 Ω	-	>184.0 Ω
RMI Oil, type 2	<10.0 Ω	-	>184.0 Ω
RMI Oil, type 4	<33.0 Ω	-	240.0 Ω
RMI Temp, type 1	<10.0 Ω	-	>1350.0 Ω
RMI Temp, type 2	<18.2 Ω	-	>2400.0 Ω
RMI Temp, type 3	<3.6 Ω	-	>250.0 Ω
RMI Temp, type 4	<32.0 Ω	-	>2500.0 Ω
RMI Fuel, Type 1	<1.6 Ω	-	>78.8 Ω
RMI Fuel, Type 2	<3.0 Ω	-	>180.0 Ω
RMI Fuel, type 4	<33.0 Ω	-	>240.0 Ω
RMI configurable	<lowest resistance	-	>highest resistance
RMI Custom	<lowest resistance	-	>highest resistance
Pt100	<82.3 Ω	-	>194.1 Ω
Level switch	Only active if the switch is open		

Principle

The diagram shows that when the wire of the input breaks, the measured value drops to zero, and the alarm is activated.



Configuring wire break alarms from the utility software or display

You can use the utility software to configure wire break alarms. Alternatively, you can use the display to configure wire break alarms: I/O settings > Inputs > Multi input > Wire fail [20 to 23]

11.3.7 Differential measurement

Differential measurement compares two measurements, and gives an alarm or trip if the difference between two measurements become too large (or too small). To have the alarm activate if the difference between the two inputs is lower than the alarm's set point, remove the check mark from *High Alarm* in the alarm configuration.

It is possible to have up to six comparisons. Two alarms can be configured for each comparison.

Using differential measurement to create an extra analogue alarm

If the same measurement is selected for input A and input B, the controller uses the value of the input for the differential measurement alarm.

Functions > Delta alarms > Set [1 to 6]

Parameter	Text	Range	Default
4601, 4603, 4605, 4671, 4673 or 4675	Input A for comparison set [1 to 6]	See the controller	Multi-input 20
4602, 4604, 4606, 4672, 4674 or 4676	Input B for comparison set [1 to 6]		

Functions > Delta alarms > Set [1 to 6] > Delta ana[1 to 6] [1 or 2]

Parameter	Text	Range	Default
4611, 4631, 4651, 4681, 4701 or 4721	Set point 1	-999.9 to 999.9	1.0
4621, 4641, 4661, 4691, 4711 or 4731	Set point 2	-999.9 to 999.9	1.0
4612, 4632, 4652, 4682, 4702 or 4722	Timer 1	0.0 to 999.0 s	5.0 s
4622, 4642, 4662, 4692, 4712 or 4732	Timer 2	0.0 to 999.0 s	5.0 s

Parameter	Text	Range	Default
4613, 4633, 4653, 4683, 4703 or 4723	Output A set 1	Relays and M-Logic	-
4623, 4643, 4663, 4693, 4713 or 4733	Output A set 2		
4614, 4634, 4654, 4684, 4704 or 4724	Output B set 1		
4624, 4644, 4664, 4694, 4714 or 4734	Output B set 2		
4615, 4635, 4655, 4685, 4705 or 4725	Enable set 1	OFF ON	OFF
4625, 4645, 4665, 4695, 4715 or 4735	Enable set 2		
4616, 4636, 4656, 4686, 4706 or 4726	Fail class set 1	Fail classes	Warning
4626, 4646, 4666, 4696, 4716 or 4736	Fail class set 2		

Differential measurement examples



High ESS voltage alarm

Configure the alarm:

- In parameters 4601 and 4602, select *Voltage DC*.
- In menu 4610, select 25.0 for the set point, select 1.0 s for the timer, and select *ON*.

If the battery voltage rises above 25.0 V for at least 1 second, the controller activates the *Delta ana1 1* warning alarm. Use the translation function to change the alarm text to *High ESS voltage*.



Low state of charge output

Configure the output:

- In parameter 4603 and 4604, select *SOC*.
- In menu 4630:
 - Set point: 30.0
 - Timer: 1.0 s
 - Output A: *Terminal 14*
 - Output B: *Limits*
 - Enable: Select
 - High alarm: De-select

If the state of charge drops below 30.0 % for at least 1 second, the controller activates the terminal 14 relay. The differential alarm is not activated.

11.4 Analogue outputs

The controller has two analogue outputs that are active and galvanically separated. No external supply can be connected.

11.4.1 Using an analogue output as a transducer

You can configure transducers 52 and/or 55 to transmit values to an external system. The values include the controller's set points, and AC measurements.

You can select a scale for some of the values. For example, for the busbar voltage (parameter 5913), select the minimum in 5915, and select the maximum in 5914.

NOTE These values are also available using Modbus.

Transducer range

I/O settings > Outputs > Transducer > Output [52 or 55] limits

Parameter	Name	Range	Details
5802 or 5812	AOUT [52 or 55] limits	-10.5 to 5 V	The transducer minimum limit.
5803 or 5813	AOUT [52 or 55] limits	-5 to 10.5 V	The transducer maximum limit.

Transducer configuration example: Power output

I/O settings > Outputs > Transducer > kW > P output actual

Parameter	Name	Range	Details
5823	P1 output type	Set point Disabled -10 to 10 V Transducer A Disabled Transducer 52 Transducer 55	Select the output.
5824	P1 output max	0 to 20000 kW	ESS active power maximum for the transducer
5825	P1 output min	-9999 to 20000 kW	ESS active power minimum for the transducer

Other transducer values

Parameter	Name	Details
5693, 5694, 5695	P ref	The controller's power set point.
5853, 5854, 5855	S	ESS apparent power
5863, 5864, 5865	Q	ESS reactive power
5873, 5874, 5875	PF	Power factor of the power from the ESS
5883, 5884, 5885	f (ESS)	ESS frequency
5893, 5894, 5895	U (ESS)	ESS L1-L2 voltage
5903, 5904, 5905	I	ESS L1 current
5913, 5914, 5915	U BB	Busbar/mains L1-L2 voltage
5923, 5924, 5925	f BB	Busbar/mains frequency
5933, 5934, 5935	Input 20	The value received by analogue input 20.
5943, 5944, 5945	Input 21	The value received by analogue input 21.
5953, 5954, 5955	Input 22	The value received by analogue input 22.

11.5 Additional inputs and outputs

If more inputs and/or outputs (IOs) are needed, you can use CIO modules with the controller. When the CIOs are installed and the IOs are configured, the CIO IOs act like IOs on the controller.

To use CIOs, in *CIO Enable* (parameter 7891) select *ON*.



More information

See the **CIO 116 Installation and Commissioning guide** under www.deif.com/products/cio-116.

See the **CIO 208 Installation and Commissioning guide** under www.deif.com/products/cio-208.

See the **CIO 308 Installation and Commissioning guide** under www.deif.com/products/cio-308.

12. Small rental application (ESS-Genset) example

12.1 Introduction

As this handbook shows, you can use the application drawing, inputs and outputs, parameters and M-Logic to use the battery/storage controller in a wide variety of applications. To help you to set up a single battery/storage controller quickly, this chapter is an example of a specific, simple, single controller application.



DANGER!




Incorrect configuration is dangerous

Only allow authorised personnel, who understand the risks involved in working with electrical systems, to do the installation and configuration. The configuration given here is an example. Do not blindly follow this example. Be careful to create a configuration that is suitable for your electrical system instead.

12.2 Application setup

Single-line diagram for the application example



System information

- Three-phase system, 50 Hz, 400 V phase-phase
- Storage system: Danfoss Vacon NXP, with Modbus TCP PCS communication
- Genset: 1500 kW, with a DSE 8xxx controller
- Application: Supply power at a building site on weekdays from 07h00 to 19h00:
 - During the day, the battery supplements the genset, and makes sure that the genset runs optimally.
 - At night, and over weekends, the battery supplies power for lighting and the security system. The genset is off.
- Operation strategy:
 - From 07h00 to 18h00, the state of charge parameters (set 1) ensure optimum genset operation.
 - From 18h00 to 19h00, the state of charge parameters (set 2) ensure that the battery is charged (to supply power through the night).
 - From 19h00, the state of charge parameters (set 3) allow the battery to run down (so that the genset does not have to start).

Creating the application drawing in the USW

1. On the *Application configuration* page, use *New plant configuration* to open a *Plant options* window to create a new application.



Plant options [X]

Product type
ASC 150 Storage

Plant type
Single controller

Application properties
☐ Active (applies only when performing a batchwrite)
Name: Rental example


Bus Tie options
☐ Wrap bus bar

Power management CAN
☐ Primary CAN
☐ Secondary CAN
☐ Primary and Secondary CAN
☒ CAN bus off (stand-alone application)

Application emulation
☒ Off
☐ Breaker and engine cmd. active
☐ Breaker and engine cmd. inactive

OK Cancel

2. Under *Area control*, remove Mains from the top area. Since the controller controls the ESB in this example, add the ESB breaker type in the bottom area.



3. Use *Write plant configuration to the device* to write the configuration to the controller.




12.3 Inputs/Outputs

Set up the inputs in the utility software.

Set up the relay to start/stop the genset

On the *I/O & Hardware setup* page, select *DO 5 - 18*.

For *Output 5*, select *Start/Stop Ext. GEN* and *M-Logic / Limit relay*, then write to the controller.



Set up the measurements from the genset controller

On the *I/O & Hardware setup* page, select *Ext. P/Q sources*.

For *Ext. source 1*, select *GEN, 1500, GEN power meter comm. 01* and *GEN power meter comm. 01*, then write to the controller.

	Type	Nominal P (kW)	P source	Q source
Ext. source 1	GEN	1500	GEN power meter comm. 01	GEN power meter comm. 01
Ext. source 2	OFF	0	No source selected	No source selected
Ext. source 3	OFF	0	No source selected	No source selected
Ext. source 4	OFF	0	No source selected	No source selected
Ext. source 5	OFF	0	No source selected	No source selected
Ext. source 6	OFF	0	No source selected	No source selected

12.4 Wiring

The minimum required wiring is listed in the following table.



More information

See the **Installation instructions** for complete wiring information.

Terminal(s)	Function	Details
1-2	Power supply	6.5 to 36 V DC, power for the controller
1-4	Emergency stop	Digital input
1-5	Start-stop genset	Maximum 36 V DC/3 A relay. Connect these terminals to the genset controller. The genset must start when the relay is activated, and stop when the relay is deactivated.
8-17	Close ESS breaker	Maximum 36 V DC/0.5 A relay
8-18	Open ESS breaker	Maximum 36 V DC/0.5 A relay
33	Genset comm DATA + (A)	Connect these terminals to the genset controller Modbus RTU terminals.
35	Genset comm DATA - (B)	
49	ESS breaker closed	+36 V DC with respect to plant supply negative -24 V DC with respect to plant supply negative
50	ESS breaker open	
	Common	
56	S1 (k) L1 AC current	Use an x/1 A or x/5 A current transformer.
59	S2 (l) L1 AC current	
57	S1 (k) L2 AC current	Use an x/1 A or x/5 A current transformer.
59	S2 (l) L2 AC current	
58	S1 (k) L3 AC current	Use an x/1 A or x/5 A current transformer.
59	S2 (l) L3 AC current	
63	L1 ESS voltage	Maximum 690 V AC phase-phase
64	L2 ESS voltage	Maximum 690 V AC phase-phase

Terminal(s)	Function	Details
65	L3 ESS voltage	Maximum 690 V AC phase-phase
67	L1 Busbar voltage	Maximum 690 V AC phase-phase
68	L2 Busbar voltage	Maximum 690 V AC phase-phase
69	L3 Busbar voltage	Maximum 690 V AC phase-phase
Ethernet	Ethernet	Connect the Ethernet to the storage system.

12.5 Parameters

For this example, set the following parameters. Select *Write parameters to the device* when you have finished.

NOTE Not all parameters are shown in the list below. Parameters with factory defaults that are suitable for this example are not included. Irrelevant parameters are not included either.

Parameter	Name	Description
6001	Nom. f 1	Select <i>50 Hz</i> .
6002	Nom. P 1	Use the ESS information to configure the nominal power set point.
6003	Nom. I 1	Use the ESS information to configure the nominal current set point.
6004	Nom. U 1	Use the ESS information to configure the nominal voltage set point.
6005	Nom. Q 1	Use the ESS information to configure the nominal reactive power set point.
6006	Nom. S 1	Use the ESS information to configure the nominal apparent power set point.
6041	ES primary U	The ESS primary voltage. If necessary, adjust this set point.
6042	ES secondary U	The ESS secondary voltage. If necessary, adjust this set point.
6043	ES Primary I	The ESS primary current. If necessary, adjust this set point.
6044	ES secondary I	The ESS secondary current. If necessary, adjust this set point.
6051	BB primary U 1	The busbar primary voltage. If necessary, adjust this set point.
6052	BB second. U 1	The busbar secondary voltage. If necessary, adjust this set point.
6053	BB nominal U 1	The busbar nominal voltage. If necessary, adjust this set point.
6071	Operation mode	Select <i>Island operation</i>
6961	Start timer 1	Select <i>MO-TU-WE-TH-FR</i>
6962	Start timer 1	Select <i>7 Hours</i>
6964	Stop timer 1	Select <i>MO-TU-WE-TH-FR</i>
6965	Stop timer 1	Select <i>18 HOURS</i>
6971	Start timer 2	Select <i>MO-TU-WE-TH-FR</i>
6972	Start timer 2	Select <i>18 Hours</i>
6974	Stop timer 2	Select <i>MO-TU-WE-TH-FR</i>
6975	Stop timer 2	Select <i>19 HOURS</i>
6981	Start timer 3	Select <i>MO-TU-WE-TH-FR</i>
6982	Start timer 3	Select <i>19 Hours</i>
6984	Stop timer 3	Select <i>MO-TU-WE-TH-FR</i>
6985	Stop timer 3	Select <i>7 HOURS</i>
7541	ESS comm. intf.	Select <i>Modbus TCP/IP client</i>

Parameter	Name	Description
7561	ESS protocol	Select <i>Danfoss Vacon NXP</i> .
7681	BMS comm. ID	If necessary, adjust this set point.
7701	GEN meter ID	If necessary, adjust this set point.
7721	GEN meter prot.	Select <i>DSE 8xxx, 7xxx, 6xxx and 4xxx</i>
15011	Min GEN load 1	If necessary, adjust this set point.
15014	Opt. GEN load % 1	If necessary, adjust this set point.
15151	SOC GEN start limit	If necessary, adjust this set point.
15153	SOC GEN stop limit	If necessary, adjust this set point.
15155	SOC GEN control	Select <i>Enable</i> .
15161	Sys P GEN start limit	If necessary, adjust this set point.
15163	Sys P GEN stop limit	If necessary, adjust this set point.
15165	Sys P GEN control	Select <i>Enable</i> .
17031	GEN charge pct	If necessary, adjust this set point.
17032	GEN charge P	If necessary, adjust this set point.
17033	GEN charge mode	Select <i>Enable</i> , and as relevant, select percent or power.
17051	SOC minimum 1	If necessary, adjust this set point.
17052	SOC maximum 1	If necessary, adjust this set point.
17053	SOC thr. 1.1	If necessary, adjust this set point.
17054	SOC thr. 2.1	If necessary, adjust this set point.
17061	SOC minimum 2	Adjust this set point to make sure that the battery is charged up.
17062	SOC maximum 2	Adjust this set point to make sure that the battery is charged up.
17063	SOC thr. 1.2	Adjust this set point to make sure that the battery is charged up.
17064	SOC thr. 2.2	Adjust this set point to make sure that the battery is charged up.
17071	SOC minimum 3	Adjust this set point to allow the battery to discharge as it supplies power through the night.
17072	SOC maximum 3	Adjust this set point to allow the battery to discharge as it supplies power through the night.
17073	SOC thr. 1.3	Adjust this set point to allow the battery to discharge as it supplies power through the night.
17074	SOC thr. 2.3	Adjust this set point to allow the battery to discharge as it supplies power through the night.
17081	Operation mode	Select <i>Battery leading</i> , so that the ESS can supply energy when the genset is not running.
17110	SOC low	If necessary, adjust this set point.
17120	SOC high	If necessary, adjust this set point.

12.6 Timer logic

The utility software screenshot below shows simple logic to change the state of charge parameter set based on the command timers.

Logic 1		Daytime SOC setting for optimum genset operation	
Event A	☐ NOT	Cmd timer 01 active: Cmd Timers	Operator [Box] Delay (sec.) 0
Event B	☐	Not used	
Event C	☐	Not used	
			Output Set SOC setting 1: Battery
			Enable this rule ☒

Logic 2		SOC setting for battery top up charging	
Event A	☐ NOT	Cmd timer 02 active: Cmd Timers	Operator [Box] Delay (sec.) 0
Event B	☐	Not used	
Event C	☐	Not used	
			Output Set SOC setting 2: Battery
			Enable this rule ☒

Logic 3		SOC setting for night time power supply	
Event A	☐ NOT	Cmd timer 03 active: Cmd Timers	Operator [Box] Delay (sec.) 0
Event B	☐	Not used	
Event C	☐	Not used	
			Output Set SOC setting 3: Battery
			Enable this rule ☒

You can also create more complex logic. For example, you can configure a switch to override the timers.

12.7 Commissioning

DANGER!

Incorrect wiring and configuration are dangerous

Before using the system, check that the wiring and parameters are correct for the application.

Before starting operation, check that all the wiring is correct.

Check that the parameters are correct for the application.

Check that the controller can communicate with the ESS and the genset controller.

12.8 Operation

Press the AUTO button on the controller. When the controller is in AUTO mode, the LED next to the AUTO button is green.

The controller automatically ensures that the ESS runs according to its charge scheme, and supplies the required power.

At 07h00, the controller changes to state of charge parameter set 1. If necessary, the controller automatically starts the genset. The controller changes the ESS set point to ensure that the genset never runs below its minimum load. As far as possible, the controller ensures that the genset runs at its optimum load.

At 18h00, the controller changes to state of charge parameter set 2. If necessary, the controller automatically starts the genset to top up the battery charge for the night.

At 19h00, the controller changes to state of charge parameter set 3. The battery is allowed to run down as it supplies a small amount of power for security and lighting.