



SIM6-5


Run



Port 2



EtherCAT OUT



Port 1



EtherCAT OUT

