

DEIF hybrid compatibility

4139341288P

Photovoltaic and energy storage systems, weather and power measurements

Application notes



1. Introduction

1.1 DEIF's hybrid controllers.....	5
1.2 Compatibility and compliance.....	5
1.3 Software versions.....	5

2. Battery

2.1 Overview.....	7
2.1.1 Compatible battery energy storage systems.....	7
2.1.2 Power and droop/VSG modes.....	7
2.1.3 List for BCU control.....	8
2.1.4 List for BCU and PCS control.....	9
2.1.5 List for BMS control.....	10
2.1.6 List for PDS control.....	11
2.2 Protocols.....	11
2.2.1 Any maker (generic protocols).....	11
2.2.2 ABB.....	12
2.2.3 Aggreko.....	12
2.2.4 Alfen.....	12
2.2.5 Allsparkpower.....	13
2.2.6 ATESS-Growatt (深圳时代能创).....	13
2.2.7 Ausar.....	13
2.2.8 BMSer (协能).....	13
2.2.9 BYD (比亚迪-弗迪).....	14
2.2.10 CanadianSolar.....	14
2.2.11 CATL (宁德时代).....	14
2.2.12 Danfoss Vacon.....	14
2.2.13 Delta (台达).....	15
2.2.14 Dynapower.....	15
2.2.15 Enervue.....	16
2.2.16 Enjoypowers (恩玖).....	16
2.2.17 EOS Energy Block.....	16
2.2.18 EPC power.....	16
2.2.19 EVE (亿纬).....	17
2.2.20 FIMER.....	17
2.2.21 Gold (高特).....	17
2.2.22 Gotion (国轩).....	17
2.2.23 GPSS.....	17
2.2.24 GTZKNE (国投高科).....	18
2.2.25 H2.....	18
2.2.26 Hangzhou Huasu (杭州华塑).....	18
2.2.27 HoyCore (青禾).....	19
2.2.28 Huawei (华为).....	19
2.2.29 Jinko (晶科).....	20
2.2.30 Kehua (科华).....	20
2.2.31 Kgoor (科工).....	20
2.2.32 KStar (科士达).....	20
2.2.33 LFP.....	20
2.2.34 Lithium Valley.....	21
2.2.35 LS PowerBRiC.....	21
2.2.36 Matter Energy.....	21

2.2.37 Megarevo (迈格瑞能).....	21
2.2.38 Moura.....	21
2.2.39 Narada (南都).....	22
2.2.40 Ningbo SYL (双一力).....	22
2.2.41 Nomad.....	22
2.2.42 Northvolt.....	23
2.2.43 Ocean Batteries.....	23
2.2.44 Oztek.....	23
2.2.45 Pixii.....	23
2.2.46 Polarium.....	23
2.2.47 PylonTech (派能).....	24
2.2.48 Rolls Royce.....	24
2.2.49 Samsung.....	24
2.2.50 Shenzhen Coslight Power Technology (深圳光宇).....	24
2.2.51 Sicon (先控).....	24
2.2.52 Sinexcel (盛弘).....	25
2.2.53 Sino Soar (中腾).....	26
2.2.54 SMA.....	26
2.2.55 Sungrow (阳光).....	26
2.2.56 Sunwoda (欣旺达).....	28
2.2.57 Tesla.....	28
2.2.58 TRUMPF.....	28
2.2.59 Vertiv.....	29
2.2.60 WEG.....	29
2.2.61 Yingbo (英博).....	29
2.2.62 YUNT PCS (云天).....	30

3. Photovoltaic

3.1 Compatible PV systems.....	31
3.1.1 ABB/Fimer.....	31
3.1.2 CanadianSolar.....	31
3.1.3 Chint (正泰).....	31
3.1.4 CHISAGE (浙江中哲).....	32
3.1.5 DEIF open.....	32
3.1.6 Delta (台达).....	32
3.1.7 Deye (德业).....	32
3.1.8 Each Energy (壹启).....	33
3.1.9 EVVO.....	33
3.1.10 Fimer.....	33
3.1.11 Fronius.....	33
3.1.12 Gamesa.....	34
3.1.13 Goodwe (固德威).....	34
3.1.14 Growatt (古瑞瓦特).....	34
3.1.15 Havells.....	35
3.1.16 HiQ.....	35
3.1.17 Hypontech (海鹏).....	35
3.1.18 Huawei (华为).....	35
3.1.19 Ingeteam.....	37
3.1.20 INVT.....	38
3.1.21 Kaco.....	38

3.1.22 Kehua (科华).....	39
3.1.23 Kostal.....	39
3.1.24 Kstar (科士达).....	39
3.1.25 LIVOLTEK (利沃得).....	39
3.1.26 Matter Energy.....	39
3.1.27 Meteocontrol.....	39
3.1.28 Polycab.....	40
3.1.29 Power One.....	40
3.1.30 Refusol.....	40
3.1.31 SAJ (三晶).....	40
3.1.32 Schneider.....	40
3.1.33 Sineng (上能).....	40
3.1.34 SMA.....	41
3.1.35 Sofar Solar (首航).....	41
3.1.36 SolarEdge.....	42
3.1.37 SolaX Power.....	42
3.1.38 Solis (锦浪(海外版)).....	42
3.1.39 Sungrow (阳光).....	42
3.1.40 Thea.....	43
3.1.41 Vacon.....	43
3.1.42 Yaskawa.....	43
3.1.43 ZCS Azzurro.....	43

4. Weather stations

4.1 Compatible weather stations and forecast systems.....	45
---	----

5. Power measurements

5.1 Power meters.....	46
5.2 Compatible power meters.....	46
5.3 Compatible genset controllers.....	47

1. Introduction

1.1 DEIF's hybrid controllers

The DEIF hybrid controllers allow you to combine renewable energy with other power sources in a wide range of applications.

Controller	Integrate	Documentation
iE 150 Battery Marine	Battery energy and storage	www.deif.com/documentation/ie-150-marine
iE 150 Solar Marine	Photovoltaic power	www.deif.com/documentation/ie-150-marine
ASC 150 Storage	Battery energy and storage	www.deif.com/documentation/asc-150-storage
ASC 150 Solar	Photovoltaic power	www.deif.com/documentation/asc-150-solar
AGC 150 Hybrid	Photovoltaic power	www.deif.com/documentation/agc-150-hybrid
ASC-4 Battery	Battery energy and storage	www.deif.com/documentation/asc-4-battery
ASC-4 Solar	Photovoltaic power	www.deif.com/documentation/asc-4-solar

NOTE For Modbus RTU, for iE 150, ASC 150 and AGC 150, use RS-485 port 1 if galvanic isolation is required.

1.2 Compatibility and compliance

DEIF hybrid controllers are compatible with photovoltaic and battery systems from a wide range of manufacturers.

SunSpec compliance

All DEIF hybrid controllers are compliant with the SunSpec standards (see sunspec.org). DEIF controllers are therefore compatible with new inverters that use the generic SunSpec protocol.

Testing

Many PV inverter makers and battery system makers use the same protocol for a wide range of their products. New PV inverters and battery systems often comply with the older protocol. If a specific inverter or battery management system is not listed here, but the maker is listed, there is a good chance that the DEIF controller is compatible.

If your PV inverter or Battery system is not listed, DEIF can help to confirm compliance using the Modbus protocol documentation.

Implementing new protocols

Since new photovoltaic and battery systems are launched every year, DEIF developers continuously implement new protocols. If your system is not listed, please contact DEIF. We can work with you to quickly implement the required protocol.

1.3 Software versions

This document is valid for the following software versions.

Controller	SW version
iE 150 Battery Marine	1.30
iE 150 Solar Marine	1.30
ASC 150 Storage	1.30
ASC 150 Solar	1.30
AGC 150 Hybrid	1.30

Controller	SW version
ASC-4 Battery	4.29*
ASC-4 Solar	4.29*

NOTE * Some protocols are not available for these controllers.

2. Battery

2.1 Overview

2.1.1 Compatible battery energy storage systems

Controllers

iE 150 Battery Marine, ASC 150 Storage, and ASC-4 Battery support the protocols listed in this chapter.

Interfaces

Controller	Modbus RTU (RS-485)	Modbus TCP	ESS protocol parameter	BMS protocol parameter	PDS protocol parameter
iE 150 Battery Marine	●	●	7561	7682	7912
ASC 150 Storage	●	●	7561	7682	7912
ASC-4 Battery	●	●*	7561	7681	7882

NOTE * An external converter is required. This can be supplied by DEIF.

System types

System	ESS protocol	BMS protocol	PDS protocol
Battery control unit (BCU)	●		
Battery management system (BMS)		●	
Power conversion system (PCS)	●		
Energy storage system (ESS)	●		
Power DC-DC system (PDS)			●

2.1.2 Power and droop/VSG modes

The ESS protocols can support one or more of these power modes.

Power-reactive power (P/Q)

The inverter is grid-following. The inverter matches the busbar voltage and frequency, and generates power based on a P and Q reference. Before the inverter can start, a grid-forming energy source, like a genset or a mains connection, must be connected to the busbar.

If the grid-forming genset or mains trips, the inverter cannot keep the voltage and frequency stable. The inverter therefore also trips, which causes a blackout.

Voltage-frequency (V/f)

The inverter is grid-forming. The inverter tries to keep the output voltage and frequency constant (usually at the nominal voltage and frequency of the grid). This allows the PCS/BCU to generate power and charge without any gensets or mains connected to the busbar.

However, since the inverter keeps the voltage and frequency constant, the inverter generally cannot be connected work in parallel with a genset or mains connection. The constant voltage and frequency would conflict with other voltage and frequency sources. Therefore, if a genset or mains is connected to busbar, the inverter must generally switch back to P/Q mode. Depending on the inverter, a blackout might be required.

Some PCS/BCU support running in V/f mode while parallel with other identical PCS/BCU (which are also in V/f mode).

Droop/VSG

Droop mode is also called VSG-mode (Virtual Synchronous Generator mode). The inverter acts like a generator, which allows the inverter to always be grid-forming. In addition, in droop mode, the output voltage and frequency are controlled using predefined droop slopes. This allows the inverter to be connected in parallel with gensets and sometimes also a mains connection.

If the gensets or mains connection trip, the inverter can then immediately keep the voltage and frequency stable based on the droop slope, to prevent a blackout. The gensets and mains are also able to synchronise back to the inverter.

2.1.3 List for BCU control

Maker	Type	Modbus RTU	Modbus TCP	COC
Any maker	DEIF Generic Modbus protocol for implementation The ASC is the Modbus client.	●	●	
Any maker	DEIF Open Modbus protocol for implementation The ASC is the Modbus server.	●	●	
Alfen	TheBattery Connect	●	●	
Aggreko	Y.Cube		●	
ATESS-Growatt	PCS series	●		●
GPSS	GPSS-240-020K-3P-Cxx		●	●
H2	Enerflow		●	●
Huawei	SACU – LUNA		●	
LS PowerBRiC	E-series		●	
Moura	Moura BESS LFP (100kW/110kWh)		●	
Nomad	12R-1000P-NT		●	
Northvolt	VMS		●	
Rolls Royce	Qinous RDD		●	●
Sungrow	SunGrow LC100 Utility LFP		●	
Sungrow	SunGrow LC100 Utility LFP v1.12		●	
Sungrow	SunGrow local controller	●	●	
Sungrow	SC XXX (Upper Computer Communication Protocol for PCS (V1.2.1.1))	●		
Sungrow	LC200	●	●	
Sungrow	LC200 DPS		●	
Sungrow	LC200 Multi PCS		●	
Sungrow	LC200 Single PCS		●	
Sungrow	PowerStack		●	
Tesla	Tesla Powerpack		●	

COC = Certificate of compliance

2.1.4 List for BCU and PCS control

Maker	Type	Modbus RTU	Modbus TCP	COC
Any maker	DEIF Generic Modbus protocol for implementation The ASC is the Modbus client.	●	●	
Any maker	DEIF Open Modbus protocol for implementation The ASC is the Modbus server.	●	●	
ABB	PQ PluS		●	
Ausar	Ausar MAE	●		
CanadianSolar	BCS100K-B-HM X2	●	●	
CanadianSolar	BCS1725K-B-HUD	●	●	
CanadianSolar	BCS75-175K-B-HM-US X2	●	●	
Danfoss Vacon	Danfoss NXP	●	●	
Delta	EPCS 1200/1500/1725		●	
Delta	PCS100HV		●	
Delta	PCS1000	●		
Dynapower	CPS 1500 and MPS-125 EVH PCS		●	
Enjoypowers	Energy storage PCS	●		
EPC power	CAB1000	●	●	
Fimer	PVS980-58BC	●		
Jinko	PCS 500K	●	●	
Kehua	BCS-B-HUD series	●	●	
KStar	GSE series	●	●	
Matter Energy	Matter Energy PCS	●	●	
Megarevo	MPS series	●	●	
Oztek	OZPCS-RS40	●	●	
Pixii	PowerShaker	●	●	
Sicon	EPCS series	●		
Sinexcel	PWS1-50K to 250K series	●		
Sinexcel	PWS1-500KTL-EX	●		
Sinexcel	PWS1-1750KTL		●	
Sinexcel	PWS2-30K series	●		
Sino Soar	SP100H	●		
SMA	Sunny Island		●	
TRUMPF	TruConvert AC3025		●*	
TRUMPF	TruConvert DC1008		●*	
Vertiv	V1EA series	●	●	
WEG	BIW610	●	●	
Yingbo	Yingbo INPPCS-xxx-0.4/w 50/100 kW	●	●	
YUNT PCS	Mars-125KT	●	●	

NOTE * Modbus UDP/TCP
COC = Certificate of compliance

2.1.5 List for BMS control

Maker	Type	Modbus RTU	Modbus TCP	COC
Any maker	DEIF Generic Modbus protocol for implementation The ASC is the Modbus client.	●	●	
Allsparkpower	Allsparkpower	●	●	
BMSer	BMSer Technology V.1	●	●	
BMSer	BMSER Single Cluster	●	●	
BYD	BYD Cube Pro		●	
CATL	CATL BMS systems		●	
Enervence	Energy Rack		●	
EOS Energy Block	EOS Energy Block		●	
EVE	MBMU BMS		●	
Gold	ESMU		●	
Gotion	Gotion BMS	●		
GTZKNE	FX34	●	●	
GTZKNE	WK-BMS-C	●	●	
Hangzhou Huasu	CELLCHECK H3G-TA	●		
Hangzhou Huasu	Huasus S02/03 LFP 3-Layer BMS		●	
Hangzhou Huasu	Huasus S04 LFP 3-Layer BMS		●	
Hangzhou Huasu	Huasus S06 LFP 3-Layer BMS		●	
Hangzhou Huasu	Huasus Single Cluster		●	
Kgoor	BCMU	●		
LFP	LiFe Po	●		
Lithium Valley	SCU	●	●	
HoyCore	HoyCore Outdoor Liquid-Cooling Battery System	●	●	
Narada	NESP and NPFC series	●		
Ningbo	SYL Golden Sigma - model SU340U170K		●	
Ningbo	Ningbo Golden Sigma	●	●	
Ocean Batteries	PD-003V2 BMS	●		
Polarium	SLB48	●		
PylonTech	PowerCube H1/H2	●		
Samsung	E1	●		
Shenzhen Coslight Power Technology	ESMU		●	
Sunwoda	BCMU		●	
Sunwoda	Main BCMU		●	
WEG	WEG BMS		●	

COC = Certificate of compliance

2.1.6 List for PDS control

Maker	Type	Modbus RTU	Modbus TCP	COC
SinExcel	SinExcel DC/DC PDS	●	●	

PDS = Power DC-DC System

COC = Certificate of compliance

2.2 Protocols

2.2.1 Any maker (generic protocols)

DEIF Generic (PCS or BCU)

Maker	Any
Type	Modbus protocol for implementation
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	DEIF Generic
System	PCS or BCU
Power mode(s)	P/Q, V/f, Droop
Notes	For DEIF Generic, the ASC acts as a Modbus client, while an external PLC acts as a Modbus server. For more information, see the ASC-4 Battery ASC 150 Storage Modbus client tables, and the ASC-4 Modbus client User manual or ASC 150 Storage Modbus client User manual. ESS protocol M-Logic custom input 1: The state of ESS custom input 1 is reflected in bit 3 of the config bits written to the PCS/BCU.

DEIF Generic (BMS)

Maker	Any
Type	Modbus protocol for implementation
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC BMS (7681/7682) protocol	DEIF Generic
System	BMS
Notes	For DEIF Generic, the ASC acts as a Modbus client, while an external PLC acts as a Modbus server. For more information, see the ASC-4 Battery ASC 150 Storage Modbus client tables, and the ASC-4 Modbus client User manual or ASC 150 Storage Modbus client User manual.

DEIF Open

Maker	Any
Type	BESS using the DEIF open protocol
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	DEIF Open
System	PCS or BCU
Power modes	-
Notes	For DEIF Open, the ASC acts as a Modbus server, while an external PLC acts as a Modbus client. For more information, see the ASC-4 Modbus server tables or ASC 150 Modbus server tables, and the ASC-4 Modbus server User manual or ASC 150 Modbus server User manual.

2.2.2 ABB

Maker	ABB
Type	PQ Plus
Interface	Modbus TCP
ASC ESS (7561) protocol	
System	PCS
Power mode(s)	
Notes	Under development. Contact DEIF for more information.

2.2.3 Aggreko

Maker	Aggreko
Type	Y.Cube
Interface	Modbus TCP
ASC ESS (7561) protocol	Aggreko Y-Cube*
System	BCU
Power mode(s)	P/Q
Notes	* Requires a special Aggreko option in ASC-4.

2.2.4 Alfén

Maker	Alfén
Type	TheBattery
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC BMS (7681/7682) protocol	Alfén BCU
System	BCU
Power mode(s)	P/Q, Droop

2.2.5 Allsparkpower

Maker	Allsparkpower
Type	Allsparkpower
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC BMS (7681/7682) protocol	Allsparkpower BMS
System	BMS

2.2.6 ATESS-Growatt (深圳时代能创)

Maker	ATESS-Growatt
Type	PCS
Interface	Modbus RTU (RS-485)
ASC ESS (7561) protocol	ATESS Growatt
System	BCU
Power mode(s)	P/Q, and V/f with Bypass panel.
Notes	Certificate of compliance

2.2.7 Ausar

Maker	Ausar
Type	Ausar MAE
Interface	Modbus RTU (RS-485)
ASC ESS (7561) protocol	Ausar MAE v4*
System	PCS, ESS
Power mode(s)	P/Q, V/f
Notes	ESS protocol M-Logic custom input 1: Enables the "MAE low battery recharge current ripple" mode for maintenance charging."

NOTE * Previously *Ausar MAE v2*.

2.2.8 BMSer (协能)

BMSer Technology V1

Maker	BMSer
Type	BMSer Technology V.1
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC BMS (7681/7682) protocol	BMSer Technology V1
System	BMS
Notes	Ethernet port number 503

BMSer Single Cluster

Maker	BMSer
Type	Battery Cluster Unit

Interface	Modbus RTU (RS-485) or Modbus TCP
ASC BMS (7681/7682) protocol	BMSer Single Cluster
System	BMS

2.2.9 BYD (比亚迪-弗迪)

Maker	BYD
Type	Cube Pro
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	BYD Cube Pro
System	BMS

2.2.10 CanadianSolar

Maker	CanadianSolar
Type	BCS100K-B-HM X2 BCS1725K-B-HUD BCS75-175K-B-HM-US X2
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	Kubank LEMS BCU
System	BCU
Power mode(s)	P/Q, V/f, Droop

2.2.11 CATL (宁德时代)

CATL air cooled BMS

Maker	CATL
Type	CATL BMS systems
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	CATL air cooled BMS*
System	BMS

NOTE * Previously CATL BMS.

CATL liquid cooled BMS

Maker	CATL
Type	CATL BMS systems
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	CATL liquid cooled BMS
System	BMS

2.2.12 Danfoss Vacon

Maker	Danfoss Vacon
Type	Danfoss NXP

Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	Danfoss Vacon NXP
System	PCS
Power mode(s)	P/Q, V/f, Droop
Notes	ESS protocol M-Logic custom input 1: Allows the Danfoss Vacon to be in “Keep zero Q” mode when only a genset/s is connected to the busbar.

2.2.13 Delta (台达)

Delta EPCS 1200/1500/1725

Maker	Delta
Type	PCS/EPCS
Interface	Modbus TCP
ASC ESS (7561) protocol	Delta EPCS 1200/1500/1725
System	PCS
Power mode(s)	P/Q, V/f

Delta PCS 100HV

Maker	Delta
Type	PCS
Interface	Modbus TCP
ASC ESS (7561) protocol	Delta PCS 100HV
System	PCS
Power mode(s)	P/Q, V/f

Delta PCS1000

Maker	Delta
Type	PCS1000
Interface	Modbus RTU (RS-485)
ASC ESS (7561) protocol	*
System	PCS
Power mode(s)	P/Q, V/f
Notes	* Customer-specific version. Not included in standard release.

2.2.14 Dynapower

Dynapower CPS-1500

Maker	Dynapower
Type	CPS 1500
Interface	Modbus TCP
ASC ESS (7561) protocol	Dynapower CPS-1500
System	PCS
Power mode(s)	P/Q, V/f, Droop

Dynapower MPS-125

Maker	Dynapower
Type	MPS-125 EVH PCS
Interface	Modbus TCP
ASC ESS (7561) protocol	Dynapower MPS-125
System	PCS
Power mode(s)	P/Q, V/f, Droop

2.2.15 Enervenue

Maker	Enervenue
Type	Energy Rack
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	Enervenue BMS
System	BMS

2.2.16 Enjoypowers (恩玖)

Maker	Enjoypowers
Type	Energy Storage PCS
Interface	Modbus RTU (RS-485)
ASC BMS (7681/7682) protocol	Enjoy PCS
System	PCS

2.2.17 EOS Energy Block

Maker	EOS
Type	Energy Block
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	EOS Energy Block
System	BMS

2.2.18 EPC power

Maker	EPC power
Type	CAB1000
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	EPC power
System	PCS
Power mode(s)	P/Q, V/f

2.2.19 EVE (亿纬)

Maker	EVE
Type	MBMU
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	EVE MBMU BMS
System	BMS

2.2.20 FIMER

Maker	FIMER
Type	PVS980-58BC
Interface	Modbus RTU (RS-485)
ASC ESS (7561) protocol	FIMER PVS980-58BC
System	PCS
Power mode(s)	P/Q, Droop

2.2.21 Gold (高特)

Maker	Gold
Type	ESMU
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	Gold BMS
System	BMS

2.2.22 Gotion (国轩)

Maker	Gotion
Type	Gotion BMS
Interface	Modbus RTU
ASC BMS (7681/7682) protocol	Gotion BMS
System	BMS

2.2.23 GPSS

Maker	GPSS
Type	GPSS-240-020K-3P-Cxx
Interface	Modbus TCP
ASC ESS (7561) protocol	GPSS
System	BCU
Power mode(s)	P/Q
Notes	Certificate of compliance

2.2.24 GTZKNE (国投高科)

GTZKNE FX34 BMS

Maker	GTZKNE
Type	FX34
Interface*	Modbus RTU (RS-485) or Modbus TCP
ASC BMS (7681/7682) protocol	GTZKNE FX34 BMS
System	BMS

NOTE * A CAN to Modbus converter is required.

GTZKNE WK-BMS-C

Maker	GTZKNE
Type	WK-BMS-C
Interface*	Modbus RTU (RS-485) or Modbus TCP
ASC BMS (7681/7682) protocol	GTZKNE WK-BMS-C
System	BMS

NOTE * A CAN to Modbus converter is required.

2.2.25 H2

Maker	H2
Type	Enerflow
Interface	Modbus TCP
ASC ESS (7561) protocol	Enerflow
System	BCU
Power mode(s)	P/Q
Notes	Certificate of compliance

2.2.26 Hangzhou Huasu (杭州华塑)

CellCheck CM BMS

Maker	Hangzhou Huasu
Type	CELLCHECK H3G-TA
Interface	Modbus RTU (RS-485)
ASC BMS (7681/7682) protocol	CellCheck CM BMS
System	BMS
Notes	Only for PbAc batteries. The charging and discharging capacity are not available in this protocol. The DEIF controller therefore uses the nominal power.

Huasu S02/03 BMS

Maker	Hangzhou Huasu
Type	HuaSu S02/03 LFP 3-Layer BMS
Interface	Modbus TCP

ASC BMS (7681/7682) protocol	Huasu S02/03 BMS
System	BMS

Huasu S04 BMS

Maker	Hangzhou Huasu
Type	HuaSu S04 LFP 3-Layer BMS
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	Huasu S04 BMS*
System	BMS
Notes	Ethernet port number is 4002. It possible to change the port number on a BMS, ESS and PDS.

NOTE * Previously *Huasu BMS*.

Huasu S06 BMS

Maker	Hangzhou Huasu
Type	HuaSu S06 LFP 3-Layer BMS
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	Huasu S06 BMS
System	BMS

Huasu Single Cluster

Maker	Hangzhou Huasu
Type	Huasu Single Cluster
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	Huasu Single Cluster
System	BMS

2.2.27 HoyCore (青禾)

Maker	HoyCore
Type	HoyCore outdoor liquid-cooling battery system
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC BMS (7681/7682) protocol	HoyCore HC01CUBE
System	BMS

2.2.28 Huawei (华为)

Maker	Huawei
Type	SACU – LUNA
Interface	Modbus TCP
ASC ESS (7561) protocol	Huawei SACU ESS smartlogger
System	BCU
Power mode(s)	P/Q, Droop (VSG)

2.2.29 Jinko (晶科)

Maker	Jinko
Type	PCS 500K
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	Jinko PCS
System	PCS
Power mode(s)	P/Q, V/f

2.2.30 Kehua (科华)

Maker	Kehua
Type	BCS series
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	Kehua BCS-B-HUD Series
System	PCS
Power mode(s)	P/Q, V/f, Droop

2.2.31 Kgooer (科工)

Maker	Kgooer
Type	BCMU
Interface	Modbus RTU
ASC BMS (7681/7682) protocol	KGooer BMS
System	BMS
Notes	KGooer BCMU, single cluster BM

2.2.32 KStar (科士达)

Maker	KStar
Type	GSE series
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC BMS (7681/7682) protocol	KStar GSE 50-630 PCS
System	PCS
Power mode(s)	P/Q, V/f

2.2.33 LFP

Maker	LFP
Type	LiFe Po
Interface	Modbus RTU (RS-485)
ASC BMS (7681/7682) protocol	LFP
System	BMS

Power mode(s)	Not relevant
Notes	The charging and discharging capacity are not available in this protocol. The DEIF controller therefore uses the nominal power.

2.2.34 Lithium Valley

Maker	Lithium Valley
Type	SCU
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC BMS (7681/7682) protocol	Lithium Valley BMS
System	BMS

2.2.35 LS PowerBRiC

Maker	LS PowerBRiC
Type	E-series
Interface	Modbus TCP
ASC ESS (7561) protocol	LS PowerBRiC
System	BCU
Power mode(s)	P/Q, V/f

2.2.36 Matter Energy

Maker	Matter Energy
Type	BCU
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	MatterEnergy PCS
System	PCS
Power mode(s)	P/Q, V/f

2.2.37 Megarevo (迈格瑞能)

Maker	Megarevo
Type	MPS series
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	MEGAREVO MPS
System	PCS
Power mode(s)	P/Q, V/f

2.2.38 Moura

Maker	Moura
Type	Moura BESS LFP (100kW/110kWh)
Interface	Modbus TCP

ASC ESS (7561) protocol	Moura BCU
System	BCU

2.2.39 Narada (南都)

Narada BMS V1

Maker	Narada
Type	NESP and NPFC series
Interface	Modbus RTU (RS-485)
ASC BMS (7681/7682) protocol	Narada BMS V1
System	BMS

Narada BMS V1 w Ctrl

Maker	Narada
Type	NESP and NPFC series
Interface	Modbus RTU (RS-485)
ASC BMS (7681/7682) protocol	Narada BMS V1 w Ctrl
System	BMS

2.2.40 Ningbo SYL (双一力)

Ningbo SYL Golden Sigma

Maker	Ningbo
Type	SYL Golden Sigma - model SU340U170K.
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	Ningbo BMS
System	BMS

Ningbo Golden Sigma

Maker	Ningbo
Type	Ningbo Golden Sigma
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC BMS (7681/7682) protocol	Ningbo BMS
System	BMS

2.2.41 Nomad

Maker	Nomad
Type	12R-1000P-NT
Interface	Modbus TCP
ASC ESS (7561) protocol	Nomad BCU
System	BCU
Power mode(s)	P/Q, V/f, Droop

2.2.42 Northvolt

Maker	Northvolt
Type	VMS
Interface	Modbus TCP
ASC ESS (7561) protocol	Northvolt VMS
System	ESS
Notes	ESS protocol M-Logic custom input 1: Keeps the BCU in Grid Boost mode no matter what is connected to the busbar. Can still be overridden by the set grid mode outputs in M-Logic.

2.2.43 Ocean Batteries

Maker	Ocean Batteries
Type	BAMU
Interface	Modbus RTU (RS-485)
ASC BMS (7681/7682) protocol	HagalOcean PD-003V2 BMS
System	BMS
Notes	Ocean Batteries was formerly known as Hagal Ocean.

2.2.44 Oztek

Maker	Oztek
Type	OZPCS-RS40
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	Oztek OZpcs-RS40
System	PCS
Power mode(s)	P/Q, V/f, Droop

2.2.45 Pixii

Maker	Pixii
Type	PowerShaper
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	Pixii PowerShaper
System	PCS and BCU
Power modes	P/Q

2.2.46 Polarium

Maker	Polarium
Type	SLB48
Interface	Modbus RTU (RS-485)

ASC BMS (7681/7682) protocol	Polarium BMS
System	BMS

2.2.47 PylonTech (派能)

Maker	PylonTech
Type	PowerCube H1/H2
Interface	Modbus RTU (RS-485)
ASC BMS (7681/7682) protocol	PowerCube H1/H2
System	BMS

2.2.48 Rolls Royce

Maker	Rolls Royce
Type	Qinous ESS
Interface	Modbus TCP
ASC ESS (7561) protocol	Qinous
System	BCU
Power mode(s)	V/f, Droop
Notes	Certificate of compliance. Maker was formerly known as Qinous.

2.2.49 Samsung

Maker	Samsung
Type	E1
Interface	Modbus RTU (RS-485)
ASC BMS (7681/7682) protocol	Samsung BMS
System	BMS

2.2.50 Shenzhen Coslight Power Technology (深圳光宇)

Maker	Shenzhen Coslight Power Technology
Type	ESMU
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	Coslight ESMU BMS
System	BMS

2.2.51 Sicon (先控)

Maker	Sicon
Type	EPCS series
Interface	Modbus RTU (RS-485)
ASC ESS (7561) protocol	Sicon PCS

System	PCS
Power mode(s)	P/Q, V/f

2.2.52 Sinexcel (盛弘)

Sinexcel 30P

Maker	Sinexcel
Type	30P
Type	PWS2-30P PWS1-1250/1375/1500/1575/1725KTL
Interface	Modbus TCP
ASC ESS (7561) protocol	SinExcel 30P
System	PCS
Power mode(s)	P/Q, V/f, Droop

Sinexcel PWS1

Maker	Sinexcel
Type	PWS1-50K to 250K Series PWS1-500KTL-EX SINEXCEL
Interface	Modbus RTU (RS-485)
ASC ESS (7561) protocol	SinExcel PWS1*
System	PCS
Power mode(s)	P/Q, V/f, Droop

NOTE * Previously *SinExcel*.

Sinexcel PWS2

Maker	Sinexcel
Type	PWS2 Series
Interface	Modbus RTU (RS-485)
ASC ESS (7561) protocol	SinExcel PWS2 30K
System	PCS
Power mode(s)	P/Q, V/f, Droop*

NOTE * For droop to work for the PWS2, the droop mode must be selected in the ASC using M-Logic (Output > Command Battery > Set mode to Droop).

SinExcel DC/DC PDS

Maker	Sinexcel
Type	PDS1-xxxK
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC PDS (7882/7912) protocol	SinExcel DC/DC PDS*
System	PDS

NOTE * Reads the power of up to 8 DC strings.

2.2.53 Sino Soar (中腾)

Maker	Sino Soar
Type	SP100H
Interface	Modbus RTU (RS-485)
ASC ESS (7561) protocol	Sinsoar SP100H
System	PCS
Power mode(s)	P/Q, V/f

2.2.54 SMA

Maker	SMA
Type	Sunny Island
Interface	Modbus TCP
ASC ESS (7561) protocol	SMA Sunny Island
System	PCS
Power mode(s)	P/Q

2.2.55 Sungrow (阳光)

Sungrow LC100 Utility LFP

Maker	SunGrow
Type	LC100 Utility LFP
Interface	Modbus TCP
ASC ESS (7561) protocol	Sungrow LC100 Utility LFP
System	BCU
Power mode(s)	P/Q, V/f and Droop

Sungrow LC100 Utility LFP v1.12

Maker	SunGrow
Type	LC100 Utility LFP V112
Interface	Modbus TCP
ASC ESS (7561) protocol	Sungrow LC100 Utility LFP v.1.12
System	BCU
Power mode(s)	P/Q, V/f and Droop

Sungrow LC200

Maker	SunGrow
Type	LC200
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	Sungrow LC200
System	BCU
Power mode(s)	P/Q, V/f and Droop

Sungrow LC200 DPS

Maker	SunGrow
Type	LC200 DPS
Interface	Modbus TCP
ASC ESS (7561) protocol	Sungrow LC200 DPS
System	BCU
Power mode(s)	P/Q, V/f and Droop

Sungrow LC200 Multi

Maker	SunGrow
Type	LC200 Multi PCS
Interface	Modbus TCP
ASC ESS (7561) protocol	Sungrow LC200 Multi PCS
System	BCU
Power mode(s)	P/Q, V/f and Droop

Sungrow LC200 Single PCS

Maker	SunGrow
Type	LC200 Single PCS
Interface	Modbus TCP
ASC ESS (7561) protocol	Sungrow LC200 Single PCS
System	BCU
Power mode(s)	P/Q, V/f and Droop

Sungrow local controller

Maker	SunGrow
Type	SunGrow local controller
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	Sungrow STXXXCP-50HV
System	BCU
Power mode(s)	P/Q, V/f
Notes	ESS protocol M-Logic custom input 1: Disables the need for a heartbeat to be sent from the ASC to the BCU.

Sungrow power stack

Maker	Sungrow
Type	PowerStack
Interface	Modbus TCP
ASC ESS (7561) protocol	Sungrow Powerstack ST
System	BCU
Power mode(s)	P/Q, V/f and Droop
Notes	ESS protocol M-Logic custom input 1: Disables the need for a heartbeat to be sent from the ASC to the BCU.

Sungrow SC XXX

Maker	Sungrow
Type	SC XXX (Upper Computer Communication Protocol for PCS (V1.2.1.1)
Interface	Modbus RTU (RS-485)
ASC ESS (7561) protocol	Sungrow PCS
System	BCU
Power mode(s)	P/Q

2.2.56 Sunwoda (欣旺达)

Sunwoda BCMU

Maker	Sunwoda
Type	BCMU
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	Sunwoda BCMU
System	BMS

Sunwoda Main BCMU

Maker	Sunwoda
Type	Main BCMU
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	Sunwoda Main BCMU
System	BMS

2.2.57 Tesla

Maker	Tesla
Type	Tesla Powerpack
Interface	Modbus TCP
ASC ESS (7561) protocol	Tesla PowerPack
System	BCU
Power mode(s)	P/Q, Droop
Notes	An SEL700B relay, acting as a mains breaker, is needed to switch between grid-tied mode and island (droop mode) without a blackout.

2.2.58 TRUMPF

TruConvert AC3025

Maker	TRUMPF
Type	TruConvert AC3025
Interface	Modbus UDP/TCP
ASC ESS (7561) protocol	TRUMPF TruConvert ACDC
System	PCS
Power mode(s)	P/Q, V/f

TruConvert DC1008

Maker	TRUMPF
Type	TruConvert DC1008
Interface	Modbus UDP/TCP
ASC ESS (7561) protocol	TRUMPF TruConvert DCDC
System	PCS
Power mode(s)	Not relevant: Only controls DC power.

2.2.59 Vertiv

Maker	Vertiv
Type	V1EA series
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	Vertiv Custom*
System	PCS
Power mode(s)	P/Q, V/f
Notes	* This is a customer-specific version of the Vertiv PCS.

2.2.60 WEG

WEG BMS

Maker	WEG
Type	WEG BMS
Interface	Modbus TCP
ASC BMS (7681/7682) protocol	WEG BMS
System	BMS

WEG PCS

Maker	WEG
Type	BIW610
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	WEG BIW610 PCS
System	PCS
Power mode(s)	P/Q, V/f

2.2.61 Yingbo (英博)

Maker	Yingbo
Type	Yingbo INPPCS-xxx-0.4/W 50/100kW
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	Yingbo
System	PCS
Power mode(s)	P/Q, V/f

NOTE Multi-PCS control is supported for Yingbo. One PCS acts as the master (the others follow the master). The ASC only communicates with the master PCS.

2.2.62 YUNT PCS (云天)

Maker	YUNT PCS
Type	Mars-125KT
Interface	Modbus RTU (RS-485) or Modbus TCP
ASC ESS (7561) protocol	YUNT PCS
System	PCS
Power mode(s)	P/Q, V/f, Droop

3. Photovoltaic

3.1 Compatible PV systems

Controller	Modbus RTU (RS-485)	Modbus TCP	PV protocol parameter
iE 150 Solar Marine	●	●	7561
ASC 150 Solar	●	●	7561
AGC 150 Hybrid	●	●	17321
ASC-4 Solar	●	●*	7561

NOTE * An external converter is required. This can be supplied by DEIF.

COC = Certificate of compliance

NOTE If different PV inverter types from the same branch use the same SunSpec models, these can often be installed on the same communication bus and support broadcast.

3.1.1 ABB/Fimer

ABB/Fimer	Interface	PV protocol	COC
Pro33	Modbus RTU (RS-485)	ABB PRO	
PVS 50/60	Modbus RTU (RS-485)	SunSpec Generic	
PVS 100/200	Modbus RTU (RS-485)	SunSpec Generic	
PVS 175	Modbus RTU (RS-485)	SunSpec Generic	
PVS 800	Modbus RTU (RS-485)	ABB PVS800	
Trio 5.8-8.0 (ID restricted)	Modbus RTU (RS-485)	ABB TRIO	
Trio 20.0	Modbus RTU (RS-485)	ABB TRIO	●
Trio 27.6	Modbus RTU (RS-485)	ABB TRIO	●
Trio 50.0	Modbus RTU (RS-485)	ABB Trio 50	

3.1.2 CanadianSolar

CanadianSolar	Interface	PV protocol	COC
CSI-110K-T4001A-E	Modbus RTU (RS-485)	Canadian CSI-110K-T4001A-E	

3.1.3 Chint (正泰)

Chint	Interface	PV protocol	COC
SCA14-36 KTL	Modbus RTU (RS-485)	CPS (Chint Power) 14/36kW	
SCA50-60 KTL	Modbus RTU (RS-485)	CPS (Chint Power) 50/60kW	
CPS SCHxxxKTL: 100kW_9Boost_1100V 136kW_12Boost_1100V 250kW_12Boost_1500V	Modbus RTU (RS-485)	CPS (Chint Power) Boost 100-250kW	

3.1.4 CHISAGE (浙江中哲)

CHISAGE	Interface	PV protocol	COC
CE-3P40KEG	Modbus RTU (RS-485)	Eachenergy PV*	
CE-3P50KEG	Modbus RTU (RS-485)	Eachenergy PV*	
CE-3P60KEG	Modbus RTU (RS-485)	Eachenergy PV*	
CE-3P75KEG	Modbus RTU (RS-485)	Eachenergy PV*	
CE-3P80KEG	Modbus RTU (RS-485)	Eachenergy PV*	
CE-3P100KEG	Modbus RTU (RS-485)	Eachenergy PV*	
CE-3P110KEG	Modbus RTU (RS-485)	Eachenergy PV*	

NOTE * Pending new protocol name.

3.1.5 DEIF open

DEIF open	Interface	PV protocol	COC
Inverters using the DEIF open protocol	Modbus RTU (RS-485) or Modbus TCP	DEIF Open	

For this protocol, the ASC is the Modbus server.



More information

For more information, see the **ASC-4 Modbus server tables** or **ASC 150 Modbus server tables**, and the **ASC-4 Modbus server User manual** or **ASC 150 Modbus server User manual**.

3.1.6 Delta (台达)

Delta	Interface	PV protocol	COC
RPI M6A	Modbus RTU (RS-485)	Delta RPI	
RPI M10A	Modbus RTU (RS-485)	Delta RPI	
RPI M15A (unicast only)	Modbus RTU (RS-485)	Delta RPI	
RPI M20A (unicast only)	Modbus RTU (RS-485)	Delta RPI	
RPI M30A	Modbus RTU (RS-485)	Delta RPI	
RPI M50A	Modbus RTU (RS-485)	Delta RPI	
RPI M88H	Modbus RTU (RS-485)	Delta RPI M88H	

3.1.7 Deye (德业)

Deye	Interface	PV protocol	COC
SUN 1.3K-G	Modbus RTU (RS-485)	Deye SUN 30-50k-G03	
SUN 3-6K-G	Modbus RTU (RS-485)	Deye SUN 30-50k-G03	
SUN 4-12K-G05	Modbus RTU (RS-485)	Deye SUN 30-50k-G03	
SUN 4-12K-G05-P	Modbus RTU (RS-485)	Deye SUN 30-50k-G03	
SUN 7-10.5K-G	Modbus RTU (RS-485)	Deye SUN 30-50k-G03	
SUN 15-17K-G03	Modbus RTU (RS-485)	Deye SUN 30-50k-G03	
SUN 18-25K-G04	Modbus RTU (RS-485)	Deye SUN 30-50k-G03	

Deye	Interface	PV protocol	COC
SUN 30-36K-G04	Modbus RTU (RS-485)	Deye SUN 30-50k-G03	
SUN 30-60K-G03	Modbus RTU (RS-485)	Deye SUN 30-50k-G03	
SUN 60-80K-G	Modbus RTU (RS-485)	Deye SUN 30-50k-G03	
SUN 70-110K-G03	Modbus RTU (RS-485)	Deye SUN 30-50k-G03	
SUN 120-136K-G01P3	Modbus RTU (RS-485)	Deye SUN 30-50k-G03	

NOTE For new software version 0603 or later, the Deye PV protocol supports broadcast and modbus ID can be changed.

3.1.8 Each Energy (壹盾)

Each Energy	Interface	PV protocol	COC
EET40K-M1	Modbus RTU (RS-485)	Eachenergy PV	
EET50K-M1	Modbus RTU (RS-485)	Eachenergy PV	
EET60K-M1	Modbus RTU (RS-485)	Eachenergy PV	
EET75K-M1	Modbus RTU (RS-485)	Eachenergy PV	
EET80K-M1	Modbus RTU (RS-485)	Eachenergy PV	
EET100K-M1	Modbus RTU (RS-485)	Eachenergy PV	
EET110K-M1	Modbus RTU (RS-485)	Eachenergy PV	

3.1.9 EVVO

EVVO	Interface	PV protocol	COC
50-70kW	Modbus RTU (RS-485)	EVVO	
1110TL/1600TL/2200TL/3000TL	Modbus RTU (RS-485)	EVVO	

NOTE The EVVO PV protocol does not support broadcast. The protocol only supports Modbus function code 0x06 (single register write) for write telegrams. However, the DEIF controller can use unicast to communicate with multiple inverters.

3.1.10 Fimer

Fimer	Interface	PV protocol	COC
PVS980	Modbus RTU (RS-485)	FIMER PVS980	

3.1.11 Fronius

Fronius	Interface	PV protocol*	COC
Data manager	Modbus RTU (RS-485) or Modbus TCP	SunSpec Generic	
Eco	Modbus RTU (RS-485) or Modbus TCP	SunSpec Generic	
Tauro	Modbus RTU (RS-485) or Modbus TCP	SunSpec Generic	
Symo	Modbus RTU (RS-485) or Modbus TCP	SunSpec Generic	

NOTE * Fronius inverters with firmware 3.7.1-4 and earlier must use the **Fronius before 3.7.1-5** protocol.

3.1.12 Gamesa

Gamesa	Interface	PV protocol	COC
E-series	Modbus TCP	Gamesa E-series	

3.1.13 Goodwe (固德威)

Goodwe	Interface	PV protocol	COC
XS Series: 0.7-3 kW	Modbus RTU (RS-485)	Goodwe DT series	●
DNS Series: 3-6 kW	Modbus RTU (RS-485)	Goodwe DT series	●
MS Series: 5-10 kW	Modbus RTU (RS-485)	Goodwe DT series	●
A-MS Series: 5-9.6 kW	Modbus RTU (RS-485)	Goodwe DT series	●
SDT G2 Series: 4-15 kW	Modbus RTU (RS-485)	Goodwe DT series	●
SDT G2 Series: 17-25 kW	Modbus RTU (RS-485)	Goodwe DT series	●
LVSMT Series: 12-20 kW	Modbus RTU (RS-485)	Goodwe MT series	●
SMT Series: 25-36 kW	Modbus RTU (RS-485)	Goodwe MT series	●
MT Series: 50-80 kW	Modbus RTU (RS-485)	Goodwe MT series	●
HT Series: 73-136 kW	Modbus RTU (RS-485)	Goodwe HT series	●
HT Series: 225/250 kW	Modbus RTU (RS-485)	Goodwe HT series	●

3.1.14 Growatt (古瑞瓦特)

Growatt	Interface	PV protocol	COC
CP100, CP250	Modbus RTU (RS-485)	Growatt CP100-CP250	
CP500, CP630, CP850, CP1000, CP1700, CP2000, CP2520	Modbus RTU (RS-485)	Growatt CP500-CP2520	
MIN 2500TL-X to 6000TL-X MIN 2500TL-XE to 6000TL-XE MID 15KTL3-X to 40KTL3-X MAC 15KTL3-XL to 36KTL3-XL MAC 30KTL3-X LV to 60KTL3-X LV MAC 50KTL3-X MV to 70KTL3-X MV MAX 50KTL3-X LV to 125KTL3-X LV MAX 60KTL3-X MV to 100KTL3-X MV MAX 185KTL3-X HV to 253KTL3-X HV	Modbus RTU (RS-485)	Growatt MAC, MAX and MID series*	
10000UE/12000UE/18000UE/20000UE	Modbus RTU (RS-485)	Growatt UE-series**	

NOTE * *Tx min interval* (parameter 7760) must be at least 0.85 s. Growatt recommends 1 s.

NOTE ** Previously Growatt.

3.1.15 Havells

Havells	Interface	PV protocol	COC
1-40kW	Modbus RTU (RS-485)	Havells 1-40kW*	
50-70kW	Modbus RTU (RS-485)	Havells 50-70kW*	
80-136kW	Modbus RTU (RS-485)	Havells 80-136kW**	

NOTE * For 1-40kW and 50-70kW, the *Tx write fnc* (parameter = ASC-4 Solar: 7564, ASC 150 Solar: 7564, AGC 150 Hybrid: 17324) must be **Single register 0×06**. To use broadcast, the inverter firmware must be at least 2.40. The *RTU broadcast ID* (parameter = ASC-4 Solar: 7515, ASC 150 Solar: 7553, AGC 150 Hybrid: 17313) must be **Enabled** and set to **136**.

NOTE ** For 80-136kW, the *Tx write fnc* (parameter = ASC-4 Solar: 7564, ASC 150 Solar: 7564, AGC 150 Hybrid: 17324) must be **Multiple register 0×10**. To use broadcast, the inverter firmware must be at least 2.40. The *RTU broadcast ID* (parameter = ASC-4 Solar: 7515, ASC 150 Solar: 7553, AGC 150 Hybrid: 17313) must be **Enabled** and set to **0**.

3.1.16 HiQ

HiQ	Interface	PV protocol	COC
Truestring	Modbus RTU (RS-485)	HiQ solar truestring	

3.1.17 Hypontech (海鹏)

Hypontech	Interface	PV protocol	COC
HPS Series*	Modbus RTU (RS-485)	Hypontech PV	
HPT Series*	Modbus RTU (RS-485)	Hypontech PV	

NOTE * Broadcast not supported.

3.1.18 Huawei (华为)

Huawei*	Interface	PV protocol	COC
Smartlogger	Modbus TCP	Huawei smartlogger	
SUN2000-2KTL-L0/-L1	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-3KTL-CNLO/-L0/-L1/-M0/-M1	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-3.68KTL-L10	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-3.8KTL-USLO	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-4KTL-CNLO/-L0/-L1/-M0/-M1	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-4.6KTL-L1	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-4.95KTL-JPLO/-JPL1	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-5KTL-CNLO/-L0/-L1/-M0/-M1/-USLO	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-6KTL-CNLO/-L1/-M0/-M1	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-7.6KTL-USLO	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-8KTL/-M0/-M1/-M2	Modbus RTU (RS-485)	Huawei V.3	

Huawei*	Interface	PV protocol	COC
SUN2000-9KTL-USL0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-10KTL/-M0/-M1/-M2/-USL0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-11.4KTL-USL0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-12KTL/-M0/-M1/-M2	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-15KTL/-M0/-M2/-M3	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-17KTL/-M0/-M2/-M3	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-20KTL/-M0/-M2/-M3	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-22KTL-US	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-23KTL/-M3	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-24.5KTL/-M3	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-24.7KTL-JP	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-25KTL-NAM3/-US	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-28KTL/-M3	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-29.9KTL/-M3	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-30KTL-A/-M3/-NAM3/-US	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-33KTL/-A/-E001/-JP/-NAM3/-NHM3/-US	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-33KTL/-A/-E001/-JP/-NAM3/-NHM3/-US	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-36KTL/-M3/-NAM3/-US	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-40KTL/-JP/-M3/-NAM3/-NHM3/-US	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-42KTL/-M3	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-43KTL-IN-C1/-INM3	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-44KTL-M3	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-45KTL/-US-HV-D0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-50KTL/-C1/-JPM0/-JPM1/-M0/-M3	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-55KTL-HV-D1/-HV-D1-001/-IN-HV-D1	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-60KTL-HV-D1/-HV-D1-001/-M0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-63KTL-JPH0/-JPM0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-65KTL-M0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-70KTL-C1/-INM0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-75KTL-C1	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-90KTL-H0/-H1/-H2	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-95KTL-INH0/-INH1	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-100KTL-H0/-H1/-H2/-INM0/-M0/-M1/-USH0	Modbus RTU (RS-485)	Huawei V.3	

Huawei*	Interface	PV protocol	COC
SUN2000-105KTL-H1	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-110KTL-M0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-125KTL-JPH0/-M0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-168KTL-H1	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-175KTL-H0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-185KTL-H1/-INH0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-193KTL-H0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-196KTL-H0/-H1/-H3	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-200KTL-H2	Modbus RTU (RS-485)	Huawei V.3	
SUN2000-215KTL-H0	Modbus RTU (RS-485)	Huawei V.3	
SUN2000L-2KTL	Modbus RTU (RS-485)	Huawei V.3	
SUN2000L-3KTL/-CN/-CN-4G	Modbus RTU (RS-485)	Huawei V.3	
SUN2000L-3.68KTL	Modbus RTU (RS-485)	Huawei V.3	
SUN2000L-4KTL/-CN/-CN-4G	Modbus RTU (RS-485)	Huawei V.3	
SUN2000L-4.125KTL-JP	Modbus RTU (RS-485)	Huawei V.3	
SUN2000L-4.6KTL	Modbus RTU (RS-485)	Huawei V.3	
SUN2000L-4.95KTL-JP	Modbus RTU (RS-485)	Huawei V.3	
SUN2000L-5KTL/-CN/-CN-4G	Modbus RTU (RS-485)	Huawei V.3	
SUN8000-500KTL	Modbus RTU (RS-485)	Huawei V.3	
SUN2000 8-28KTL	Modbus RTU (RS-485)	Huawei SUN2000 8-28KTL*	
SUN2000 33-40KTL	Modbus RTU (RS-485)	Huawei SUN2000 33-40KTL*	
SUN2000 50-60KTL	Modbus RTU (RS-485)	Huawei SUN2000 50-60KTL*	
SUN2000 55-60KTL	Modbus RTU (RS-485)	Huawei SUN2000 55-60KTL*	
SUN2000 90-105	Modbus RTU (RS-485)	Huawei SUN2000 90-105KTL*	
SUN2000 100-125KTL	Modbus RTU (RS-485)	Huawei SUN2000 100-125M0-M2*	

NOTE If the inverters have the latest software, use the **Huawei V.3** protocol. For older software, you may need to use one of the protocols marked with a star.

3.1.19 Ingeteam

Ingeteam	Interface	PV protocol	COC
SUN 10 TL	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●
SUN 10 TL M	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●
SUN 15 TL	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●
SUN 15 TL M	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●
SUN 20 TL	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●
SUN 20 TL M	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●
SUN 33 TL	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●
SUN 33 TL M	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●
SUN 40 TL M480	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●

Ingeteam	Interface	PV protocol	COC
SUN 100 TL (360V)	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●
SUN 100 TL (380V)	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●
SUN 100 TL (400V)	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●
SUN 100 TL (420V)	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●
SUN 100 TL (440V)	Modbus RTU (RS-485)	Ingeteam 3Play - ABI	●

NOTE Ingeteam 3Play - ABI previously called Ingeteam 3Play.

Ingeteam/Ingecon	Interface	PV protocol	COC
SUN 100 TL	Modbus RTU (RS-485)	Ingeteam 3Play - ABS	
SUN 160 TL M	Modbus RTU (RS-485)	Ingeteam 3Play - ABS	

3.1.20 INVT

INVT	Interface	PV protocol	COC
iMars BG	Modbus RTU (RS-485)	INVT BG series	
XG 15-25kW Three-Phase On-Grid Solar Inverter	Modbus RTU (RS-485)	INVT XG series	
XG 25-40kW Three-Phase On-Grid Solar Inverter	Modbus RTU (RS-485)	INVT XG series	
XG 50-70kW Three-Phase On-Grid Solar Inverter	Modbus RTU (RS-485)	INVT XG series	
XG 100-136kW Three-Phase On-Grid Solar Inverter	Modbus RTU (RS-485)	INVT XG series	

3.1.21 Kaco

Kaco	Interface	PV protocol	COC
Blueplanet 5.0-10.0 TL3*	Modbus UDP/TCP	SunSpec Generic	●
Blueplanet 15.0 TL3*	Modbus UDP/TCP	SunSpec Generic	●
Blueplanet 20.0 TL3*	Modbus UDP/TCP	SunSpec Generic	●
Blueplanet 50.0 TL3	Modbus UDP/TCP	SunSpec Generic	●
Blueplanet 60.0 TL3	Modbus UDP/TCP	SunSpec Generic	●
Blueplanet 87.0 TL3	Modbus UDP/TCP	SunSpec Generic	●
Blueplanet 92.0 TL3	Modbus UDP/TCP	SunSpec Generic	●
Blueplanet 105 TL3	Modbus UDP/TCP	SunSpec Generic	●
Blueplanet 125 TL3	Modbus UDP/TCP	SunSpec Generic	●
Blueplanet 137 TL3	Modbus UDP/TCP	SunSpec Generic	●
Blueplanet 150.0 TL3	Modbus UDP/TCP	SunSpec Generic	●
Blueplanet 155 TL3	Modbus UDP/TCP	SunSpec Generic	●
Blueplanet 165 TL3	Modbus UDP/TCP	SunSpec Generic	●
Powador 18.0-20.0 TL3*	Modbus UDP/TCP	SunSpec Generic	●
Powador 60.0 TL3*	Modbus UDP/TCP	SunSpec Generic	●

NOTE * These models are no longer available.

3.1.22 Kehua (科华)

Kehua	Interface	PV protocol	COC
SPI320K-B-H series	Modbus 485 (Standard) Modbus TCP (Option required)	Kehua SPI	
SPI250K-B-H series	Modbus 485 (Standard) Modbus TCP (Option required)	Kehua SPI	
SPI125K-B series	Modbus 485 (Standard) Modbus TCP (Option required)	Kehua SPI	
SPI33K-B X2 series	Modbus 485 (Standard) Modbus TCP (Option required)	Kehua SPI	
SPI23K-B X2 series	Modbus 485 (Standard) Modbus TCP (Option required)	Kehua SPI	
SPI12K-B X2 series	Modbus 485 (Standard) Modbus TCP (Option required)	Kehua SPI	
SP18000-B X2 series	Modbus 485 (Standard) Modbus TCP (Option required)	Kehua SPI	

3.1.23 Kostal

Kostal	Interface	PV protocol	COC
PIKO IQ	Modbus TCP	SunSpec Generic	
PLENTICORE	Modbus TCP	SunSpec Generic	

3.1.24 Kstar (科士达)

Kstar	Interface	PV protocol	COC
KSG1-60	Modbus RTU (RS-485)	KStar	

3.1.25 LIVOLTEK (利沃得)

LIVOLTEK	Interface	PV protocol	COC
GT1	Modbus RTU (RS-485)	LIVOLTEK SunSpec	
GT3	Modbus RTU (RS-485)	LIVOLTEK SunSpec	

3.1.26 Matter Energy

Matter Energy	Interface	PV protocol	COC
SPI 20k to 160k	Modbus RTU (RS-485) or Modbus TCP	Matter Energy SPI20k-160k	

3.1.27 Meteocontrol

Meteocontrol	Interface	PV protocol	COC
blue'Log XC	Modbus RTU (RS-485) or Modbus TCP	BlueLog XC	

3.1.28 Polycab

Polycab	Interface	PV protocol	COC
50-60kW	Modbus RTU (RS-485)	Polycab 50-60kW	

3.1.29 Power One

Power One	Interface	PV protocol	COC
SGTU1K-100K	Modbus RTU (RS-485)	Power One	

3.1.30 Refusol

Refusol	Interface	PV protocol	COC
8-23K (kW only)	Modbus RTU (RS-485)	SunSpec Generic	
100K	Modbus RTU (RS-485)	SunSpec Generic	

3.1.31 SAJ (三晶)

SAJ	Interface	PV protocol	COC
R5 Series	Modbus RTU (RS-485)	SAJ C6	
R6 Series	Modbus RTU (RS-485)	SAJ C6	
C6 Series	Modbus RTU (RS-485)	SAJ C6	

3.1.32 Schneider

Schneider	Interface	PV protocol	COC
CL 20E	Modbus RTU (RS-485)	Schneider Conext CL 20/25	●
CL 25E	Modbus RTU (RS-485)	Schneider Conext CL 20/25	●
CL 25 NA	Modbus RTU (RS-485)	Schneider Conext CL 20/25	●
CL 30*	Modbus RTU (RS-485)	Schneider CL 30/33/50/60	●
CL 33*	Modbus RTU (RS-485)	Schneider CL 30/33/50/60	●
CL 36E*	Modbus RTU (RS-485)	Schneider CL 30/33/50/60**	●
CL 50*	Modbus RTU (RS-485)	Schneider CL 30/33/50/60	●
CL 60 A/E*	Modbus RTU (RS-485)	Schneider CL 30/33/50/60**	●

NOTE * For the Schneider CL30-50 update, new CL inverters will be introduced, and old ones will be terminated. PV protocol previously *Schneider Conext CL 30/33/50/60*.

NOTE ** Previously *Schneider Conext CL 60*.

3.1.33 Sineng (上能)

Sineng	Interface	PV protocol	COC
SP-320K series	RS-485	Sineng SP320K	

3.1.34 SMA

SMA	Interface	PV protocol	COC
Cluster controller	Modbus TCP	SMA cluster controller	
EDML-10 (SMA Data Manager L)	Modbus TCP	SMA Data Manager*	
EDMM-10 (SMA Data Manager M)	Modbus TCP	SMA Data Manager*	
EDMM-US-10 (SMA Data Manager M)	Modbus TCP	SMA Data Manager*	
EDML-10.A (SMA Data Manager M Lite)	Modbus TCP	SMA Data Manager*	
Core1	Modbus UDP/TCP	SunSpec Generic	
Core2	Modbus UDP/TCP	SunSpec Generic	
FSC	Modbus TCP	SMA FSC	
SHP 75	Modbus TCP	SunSpec Generic	
SMA inverter with firmware v2.82 or earlier	Modbus RTU (RS-485)	SMA SunSpec before v2.82	
Solid Q50-60	Modbus RTU (RS-485)	SMA Solid-Q 50	
Solid-Q PRO 60	Modbus RTU (RS-485)	SMA Solid-Q PRO 60	
STP 5000-12000 TL	Modbus UDP/TCP	SunSpec Generic	
STP 20000-25000 TL	Modbus UDP/TCP	SunSpec Generic	
STP 60	Modbus UDP/TCP	SunSpec Generic	

NOTE * The DEIF controller cannot control the reactive power in the AC output for this protocol. The reactive power must be set up from the SMA Data Manager's web interface.

3.1.35 Sofar Solar (首航)

Sofar Solar	Interface	PV protocol	COC
SOFAR 1000 to 3000TL	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
SOFAR 10 to 20KTL	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
SOFAR 30 to 40KTL	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
SOFAR 50 to 70KTL	Modbus RTU (RS-485)	Sofar Solar 50-70kW*	
SOFAR 75 to 136KTL	Modbus RTU (RS-485)	Sofar Solar 80-136kW	
SOFAR 3 to 6KTLM	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
SOFAR 7.5KTLM	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
SOFAR 3 to 6KTLM-G2	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
SOFAR 10 to 15KTL-G2	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
SOFAR 20 to 33KTL-G2	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
SOFAR 30 to 40KTL-G2	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
SOFAR 50 to 70KTL-G2	Modbus RTU (RS-485)	Sofar Solar 50-70kW*	
SOFAR 1100 to 3300TL-G3	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
SOFAR 3.3 to 12KTL-X	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	

NOTE * Tx write fnc (ASC-4 parameter 7564, AGC 150 parameter 17324) must be **Single register 0x06**. To use broadcast, the inverter firmware must be at least 2.40. *Broadcast ID* (ASC-4 parameter 7515, AGC 150 parameter 17313) must be **Enabled** and set to **136**.

Sofar Solar	Interface	PV protocol	COC
SOFAR 15-24KTLX-G3 series	Modbus RTU (RS-485)	Sofar -G3	
SOFAR 25K-50KTLX-G3 series	Modbus RTU (RS-485)	Sofar -G3	
SOFAR 80KTLX-G3 series	Modbus RTU (RS-485)	Sofar -G3	

3.1.36 SolarEdge

SolarEdge	Interface	PV protocol	COC
SE17.3K	Modbus RTU (RS-485)	SolarEdge	
SE27.6K	Modbus RTU (RS-485)	SolarEdge	
SE33.3K	Modbus RTU (RS-485)	SolarEdge	
SE55.5K	Modbus RTU (RS-485)	SolarEdge	
SE66.6K	Modbus RTU (RS-485)	SolarEdge	
SE82.8K	Modbus RTU (RS-485)	SolarEdge	
SE100K	Modbus RTU (RS-485)	SolarEdge	
SE120K	Modbus RTU (RS-485)	SolarEdge	
PPC	Modbus RTU (RS-485)	SolarEdge PPC	

3.1.37 SolaX Power

SolaX Power	Interface	PV protocol	COC
X3 FORTH	Modbus RTU (RS-485)	Solax X3-FORTH/MEGA G2	
X3 MEGA G2	Modbus RTU (RS-485)	Solax X3-FORTH/MEGA G2	
X3 MIC G2	Modbus RTU (RS-485)	Solax MIC-G2/Pro-G2	
X3 PRO G2	Modbus RTU (RS-485)	Solax MIC-G2/Pro-G2	

3.1.38 Solis (锦浪(海外版))

Solis (Ginlong)	Interface	PV protocol	COC
Grid-tied inverters	Modbus RTU (RS-485)*	Solis (Ginlong)	
Grid-tied inverters	Modbus RTU (RS-485)*	Solis Logger	
Solis Logger NISE-610E	Modbus RTU (RS-485) or Modbus TCP	Solis Logger NISE	

NOTE * Solis broadcast only works with newer Solis software.

3.1.39 Sungrow (阳光)

Sungrow	Interface	PV protocol	COC
COM100E	Modbus RTU (RS-485) or Modbus UDP/TCP	Sungrow Logger 1000	
SunGrow Logger 2000	Modbus RTU (RS-485) or	Sungrow Logger 1000	

Sungrow	Interface	PV protocol	COC
	Modbus TCP/IP		
SunGrow Logger 4000	Modbus RTU (RS-485) or Modbus TCP/IP	Sungrow Logger 1000	
SunGrow Series	Modbus RTU (RS-485)	Sungrow SG series*	

NOTE * In AGC 150 Hybrid, this is *Sungrow SG10_60*.

3.1.40 Thea

Thea	Interface	PV protocol	COC
Thea	Modbus RTU (RS-485)	Thea	

3.1.41 Vacon

Vacon	Interface	PV protocol	COC
Vacon 8000	Modbus RTU (RS-485)	Vacon8000	

3.1.42 Yaskawa

Yaskawa	Interface	PV protocol	COC
PVI 25TL-208	Modbus RTU (RS-485) or Modbus TCP	SunSpec Generic	
PVI 36TL-480-V2	Modbus RTU (RS-485) or Modbus TCP	SunSpec Generic	
PVI 50TL-480	Modbus RTU (RS-485) or Modbus TCP	SunSpec Generic	
PVI 60TL-480	Modbus RTU (RS-485) or Modbus TCP	SunSpec Generic	

3.1.43 ZCS Azzurro

ZCS Azzurro	Interface	PV protocol	COC
AZZURRO 1PH 1100TL-3000TL-V1	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
AZZURRO 1PH 1100-3300TL-V3	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
AZZURRO 1PH 3000-6000-V1	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
AZZURRO 3PH 10KTL-20KTL-V1	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
AZZURRO 3PH 30KTL-40-HV-V1	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
AZZURRO 3PH 3.3KTL-12KTL-V1	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
AZZURRO 1PH 3000-6000-V2	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
AZZURRO 3PH 20KTL-33KTL-V2	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
AZZURRO 3PH 10KTL-15KTL-V2	Modbus RTU (RS-485)	Sofar Solar 1-40kW*	
AZZURRO 3PH 50KTL-70KTL-HV-V1	Modbus RTU (RS-485)	Sofar Solar 50-70kW*	
AZZURRO 3PH 80KTL-LV to 136-HV	Modbus RTU (RS-485)	Sofar Solar 80-136kW	

NOTE * *Tx write fnc* (ASC-4 parameter 7564, AGC 150 parameter 17324) must be **Single register 0×06**. To use broadcast, the inverter firmware must be at least 2.40. *Broadcast ID* (ASC-4 parameter 7515, AGC 150 parameter 17313) must be **Enabled** and set to **136**.

4. Weather stations

4.1 Compatible weather stations and forecast systems

Weather stations

The weather stations are compatible with **iE 150 Solar Marine**, **ASC 150 Solar** and **ASC-4 Solar** (parameter 7661). They are also compatible with **AGC 150 Hybrid** (parameter 17422).

Maker	Type	Interface	ASC Weather prot.
ABB	TRIO VSN800	Modbus RTU (RS-485)	ABBTRIO VSN800
Delta	GHI sensor Modbus	Modbus RTU (RS-485)	Delta Ohm
Kipp & Zonen	RT1 Smart Rooftop Monitoring System	Modbus RTU (RS-485)	Kipp and Zonen RT1
Seven Sensor	Seven Sensor 3S	Modbus RTU (RS-485)	Seven Sensor 3S
Seven Sensor	Seven Sensor 3S-TP GHI-Thermopile Pyranometer	Modbus RTU (RS-485)	Seven Sensor 3S-TP

Forecast systems

The forecast systems are compatible with **ASC-4 Solar**.

Maker	Type	Interface	ASC Forecast prot. (7631)
Reuniwatt	SkyInSight	Modbus TCP	Reuniwatt SkyInSight
SteadySun	SteadyEye	Modbus TCP	SteadySun SteadyEye

5. Power measurements

5.1 Power meters

Power measurements are required in single controller applications, as well as in open PMS applications. **iE 150 Battery Marine, iE 150 Solar Marine, ASC 150 Storage, ASC 150 Solar, ASC-4 Battery and ASC-4 Solar** controllers can receive measurements from compatible power meters, which includes these DEIF power meters:

- **MIB 8000C Multi-instrument** (www.deif.com/products/mib-8000c)
- **MIC-2 MKII Multi-instrument** (www.deif.com/products/mic-2-mkii)
- **MTR-4 Multi-transducer** (www.deif.com/products/mtr-4)

5.2 Compatible power meters

The DEIF power meter system interface is Modbus RTU (RS-485). For ASC-4, you need option H2.8.

Use parameter 7721 to select the meter protocol for DG power, 7723 for PV/ESS power, and 7725 for mains power.

Meter	Meter protocol	P	Q	Breaker feedback	Notes
ABB A43/44	ABB A43/A44	●	●	-	
ABB SACE Emax 2 protocol	ABB SACE Emax 2	●	●	●	
Accuenergy Acuvim-L series	Accuvim-L	●	●	-	
Acrel ADL	Acrel ADL	●	●	●	
Configurable power meter	Configurable power meter*	●	●	●	You can use the USW to set up the controller to use Modbus to read values from your power meter. The controller can read P, Q, and up to four digital inputs.
Diris A40	Socomec Diris A40	●	●	-	
Eastron Smart X96	Eastron Smart X96	●	●	-	
Eastron Smart X96-5G	Eastron Smart X96 with DI	●	●	●	
Eastron SDM630MCT series	Eastron SDM630MCT	●	●	-	
EM6400	Schneider EM6400	●	●	-	
EDMI Genius	EDMI	●	●	-	
EDS MMCT3	EDS-MMCT3-E-C	●	●	-	
iEM3000	Schneider iEM3000	●	-	-	
iEM6400	Schneider EM6400	●	●	-	
Mavolog Pro	Gossen	●	●	-	
MIB 7000	DEIF MIB7000C	●	●	-	This power meter is being phased out.
MIB 8000C	DEIF MIB8000	●	●	●	
MIC-2 MK II	DEIF MIC-2	●	●	●	
MIC (MIC4002)	DEIF MIC4000	●	●	●	This power meter is being phased out.
MIC (MIC4224)	DEIF MIC4000	●	●	●	This power meter is being phased out.

Meter	Meter protocol	P	Q	Breaker feedback	Notes
MTR-3	DEIF MTR-3/4	●	●	-	This power meters is being phased out.
MTR-4	DEIF MTR-3/4	●	●	-	Previously MTR-3.
Multis L40	Socomec Multis L40	●	●	-	
PM2200 and PM5560	Schneider PM5560	●	●	-	
PMU-100	APS PMU-100	●	●	-	
Secure Elite 100/300 series	Secure Elite 100/300 series	●	●	-	Previously Secure Elite XXX series.
Secure Elite 440/500 series	Secure Elite 440/500 series	●	●	-	Previously Secure Elite XXX series.

NOTE * Only available for ASC 150 Solar and ASC 150 Storage.

5.3 Compatible genset controllers

In single controller applications, **iE 150 Battery Marine**, **iE 150 Solar Marine**, **ASC 150 Storage**, **ASC 150 Solar**, **ASC-4 Battery** and **ASC-4 Solar** can get power measurements from a genset controller.

The DEIF power meter system interface is Modbus RTU (RS-485). For ASC-4, you need option H2.8.

Use parameter 7721 to select the meter protocol for DG power.

Use parameter 7725 to select the meter protocol for Mains power.

Meter	Meter protocol	P	Q	Breaker feedback
AGC-4 Mk II	DEIF Genset Control*	●	●	●*
AGC-4**	DEIF Genset Control*	●	●	●*
AGC 150	DEIF Genset Control*	●	●	●*
CAT EMCP 4	CAT EMCP 4	●	●	●
CGC 400	DEIF Genset Control*	●	●	●*
GPC-3	DEIF Genset Control*	●	●	●
Cummins PC 3.x/PCC 3000	Cummins PC 3.x/PCC 3000	●	●	●
DSE 8xxx, 7xxx, 6xxx and 4xxx	DSE 8xxx, 7xxx, 6xxx and 4xxx	●	●	●***
Kohler APM403	Kohler APM403	●	●	●

NOTE * The ASC reads the P, Q, and breaker feedbacks from the DEIF controller over an RS-485 connection.

NOTE ** This genset controller is being phased out.

NOTE *** The breaker feedback must be configured in the DSE controller.